

ARGUS ISDN Manual

Version: valid from 2.60 / **EN**

© **by intec Gesellschaft für Informationstechnik mbH**
D-58507 Lüdenscheid, Germany, 2017

Alle Rechte, auch der Übersetzung, sind vorbehalten. Kein Teil des Werkes darf in irgendeiner Form (Druck, Fotokopie, Mikrofilm oder einem anderen Verfahren) ohne schriftliche Genehmigung reproduziert, vervielfältigt oder verbreitet werden.

All rights are reserved. No portion of this document may be reproduced, duplicated or distributed in any form (print, copies, microfilm or on any other media) without intec's written permission.

1	Introduction	5
2	Configuring accesses	7
2.1	Access wizard	8
2.2	Notice	12
3	Operation on an ISDN Access	14
3.1	Setting the ISDN Interface and Access Mode	14
3.2	Initialization phase followed by a B channel Test	15
3.3	ISDN Settings	18
3.4	Bit Error Rate Test	22
3.5	Supplementary Services Test	32
3.6	Service check	36
3.7	X.31 Test	38
3.8	Call Forwarding (CF)	45
3.9	Automatic Performance of Multiple Tests	50
3.10	Connection	54
3.11	Time Measurement	63
3.12	Managing Multiple Tests on an ISDN Access	66
3.13	The L1 State of an S-Bus Access	71
3.14	Monitor	72
3.15	Leased Lines on an ISDN Access	75
3.16	Level Measuring on an ISDN Access	81
4	Connection for a PRI network	85
4.1	Pin Assignment on the ARGUS (BRI/PRI/E1)	85
5	Operation on a PRI Access	86
5.1	Configuring the PRI Interface and Access Mode Settings	86
	5.1.1 TE Simulation of a Primary Rate Interface	87
	5.1.2 NT Simulation of a Primary Rate Interface	87
5.2	Initialization Phase including B-Channel Test	87
5.3	Configuring the PRI Parameters	89
5.4	Bit error rate Test	94
	5.4.1 Setting the BERT Parameters	95
	5.4.2 BERT start	97
	5.4.3 BERT saving	101
	5.4.4 BERT wait	102
	5.4.5 B-channel loop	103
5.5	Supplementary Services Test	104
	5.5.1 Supplementary Services on DSS1	104
	5.5.2 Error Messages	105
5.6	Service Tests	105
5.7	X.31 Test	106
	5.7.1 Setting the X.31 Parameters	106
	5.7.2 Automatic X.31 Test	110
	5.7.3 Manual X.31 Test	112

5.8	Connection display	114
5.9	Clear down (disconnect) the connection	120
5.10	Connection setup time	122
5.11	The L1 Status of a PRI Access	123
5.12	Monitor	126
5.13	Leased line on a PRI access	129
	5.13.1 Telephony	129
	5.13.2 Bit error rate Test	130
	5.13.3 Configuration: BERT	132
	5.13.4 Loopbox	135
5.14	Managing Multiple Tests on a PRI Access	136
	5.14.1 Starting Several Tests to Run Simultaneously	137
	5.14.2 Switching between Parallel Tests or Connections	139
	5.14.3 End All Currently Running Tests or Connections	140
5.15	Saving numbers in the speed dial memory	141
6	Appendix	142
A)	Acronyms	142
B)	CAUSE-Messages – DSS1 Protocol	147
C)	ARGUS Error Messages (DSS1)	149
D)	Index	151

1 Introduction

When fully equipped, the ARGUS supports a comprehensive range of test functions for not only BRI accesses and POTS, but also for U-interface, E1/PRI, ADSL, VDSL, SHDSL and Ethernet accesses. This manual covers the optional E1/PRI interface.

In addition to TE/NT simulation on a PRI interface, the ARGUS also supports D-channel monitoring on PRI accesses.

Furthermore, it supports tests of digital leased lines including bit error rate tests (BERT) in the D-channel. The MegaBERT expands the bandwidth to 2 Mbit/s - to either 2048 kbit/s (framed) or 1984 kbit/s in time slots 1-31 (2 Mbit unframed). Last but not least, the ARGUS can run a BERT to a remote loopbox or perform an end-to-end measurement to another ARGUS.


ISDN functions

- U-interface (4B3T or 2B1Q) according to ANSI T1.601
- PRI/E1 interface according to ITU-T I.430/431 in TE and NT operation
- D-channel monitoring via BRI and PRI interface
- Testing of BRI and PRI fixed lines (E1, 2 Mbit/s)
- E1-BERT via all B-channels simultaneously (MegaBERT)
- Automatic service and service-feature tests, and much more
- Assessment of ISDN speech quality directly on BRI or U-interface
 - PESQ (ITU-T P.862) + MOSL_Q in conjunction with PESQ server SW

Should you have any further questions, please contact us:

intec Gesellschaft für Informationstechnik mbH
Rahmedestr. 90
D-58507 Lüdenscheid
Tel.: +49 (0) 2351 / 9070-0
Fax: +49 (0) 2351 / 9070-70
www.argus.info/en
support@argus.info

2 Configuring accesses



After powering up, ARGUS displays all configured accesses (up to 100). A default connection is configured for each access type.

The most recently used access is indicated on the display with ●.

ARGUS additionally displays a preview of the selected access settings, see also page 10. The preview window opens after 2 seconds.

<New> Creates an access, see page 8, Fig. 2.

<Edit> Edits an access, see page 8, Fig. 1.



Switches softkey assignment, see page 11.



Switches to main menu.

With the <Filter> softkey, ARGUS lets you filter all pre-configured accesses according to access type and displays this group.


In this example, ISDN is selected.

All relevant accesses are displayed in which ISDN is specified in the configuration.

<All> Display of all possible accesses, see Fig. 1.

<Edit> Edits the selected access profile.


2.1 Access wizard




ARGUS switches to the "Accesses" main menu.

You can now configure the selected access, here PRI, using the access wizard.

The query parameters of the access wizard depend on the selected access, see page 10.



Selection of physical interface (here PRI).
- for PRI, see page 85.



ARGUS switches directly to the access mode settings.

Selection of access mode (here PRI TE).



Continued on next page



ARGUS displays an access name, depending on the settings you made previously (here PRI).

- <Delete>** Deletes access name.
- <Ab>AB>** Entry starts with upper-case letters und will be continued with lower-case letters.
- <AB>12>** Entry of upper-case letters.
- <12>ab>** Entry of numerals 0 through 9 and *, #.
- <12>ab>** Entry of numbers.
- <ab>Ab>** Entry of lower-case letters.




ARGUS displays a summary and a preview of the configuration.

-  Entry of special characters, e. g. @, /, -, ., *, ?, %, =, &, ! etc.
-  Entry of special characters, e. g. _, :, +, # etc.

<Notice> Allows you to make a note, see page 12.

-  Save and quit wizard.
-  Step back.




ARGUS returns to the editing overview of the selected access (here PRI).

You need to quit the access wizard before ARGUS can use the configured access.


Continued on next page





Select PRI.

Press „OK“ to confirm the selected access, here PRI.



ARGUS switches to the ARGUS status display.

<Conig> Opens the Menu „PRI settings“, see page 85.

<Menu> Switches to main menu.


<Start> Starts B channel test.

ARGUS access wizard

The access wizard conducts an individual query depending on the connection. Each parameter queried depends on the respective previous parameters (from left to right).


Access / interface	Access mode	L2 mode
BRI U	TE, NT, Leased line, Monitor	Auto.* ¹ , P-P, P-MP
U	TE, Leased line	Auto.* ¹ , P-P, P-MP
PRI	TE, NT, Leased line, Monitor	-
* ¹ = only for BRI-TE, U-interface-TE		

Sorting the access in the access overview



In order to keep frequently used accesses readily available, ARGUS allows you to put the configured accesses in any individual order.

Switches to softkey assignment.





<↓> The selected access is moved down one place in the list.

<↑> The selected access is moved up one place in the list.

<Delete> Deletes the highlighted access.

2.2 Notice



In the preview next to the selected access, ARGUS also displays a freely editable note.

This note can be up to 28 characters long.

In this example, the note "Sample text" is displayed.

- <Delete> Delete access name.
- <Ab>AB> Entry starts with upper-case letters und will be continued with lower-case letters.
- <AB>12> Entry of upper-case letters.
- <12>ab> Entry of numerals 0 through 9 and *, #.
- <12>ab> Entry of numbers.
- <ab>Ab> Entry of lower-case letters.




Entry of special characters, e. g. @, /, -, ., *, ?, %, =, &, ! etc.



Entry of special characters, e. g. _, :, +, # etc.

Press „OK“ to accept the entered note.



The accepted note is linked with the access profile and is displayed in the preview.

The preview appears approx. 2 seconds after the access is selected.

<Filter> ARGUS switches to the Filter menu, see page 7.

<New> Creates a new access.

<Edit> Edits an access.

The access name can be edited as for notices, see page 12.

3 Operation on an ISDN Access




The voltages on the subscriber line may not exceed 48 VDC (BRI S/T) or 145 VDC (BRI U) and should be free of AC voltage.

3.1 Setting the ISDN Interface and Access Mode

Use the included connection cable to connect either the ARGUS "BRI/PRI/E1" jack to the S-Bus access to be tested or the ARGUS "Line" jack to the U to be tested and then switch the ARGUS on. The ISDN settings are made in the chapter 2 Configuring accesses page 7. In this example the ISDN TE mode was selected.

ARGUS State Display




ARGUS State Display, see page 16.

<Setting> Open the "ISDN settings" menu, see page 18.

<Start> Repeat the B channel test.

Main Menu



The menus, which are available for the type of access under test, are listed in the Main Menu.

 The ARGUS will open the marked menu (in this example, Single tests).

 Select a menu. The selected menu will be marked blue in the display.

 To return to the previous menu (in the example, the State display).

TE simulation

In the Access Menu (see page 14), select the desired simulation mode:

- **TE automatic**

On an S-Bus interface or U interface access, the ARGUS will automatically determined the D channel Layer 2 mode (P-P or P-MP). If the ARGUS determines that the access supports both modes, a configuration menu will open in which you can select the desired Layer 2 mode.

- **TE P-P (point-to-point) or TE P-MP (point-to-multipoint)**

Afterwards, the access and the protocol stack will be initialized in accordance with the selected setting.

NT simulation

In the Access Menu (see page 14), select the desired simulation mode:

- **NT P-P (point-to-point) or NT P-MP (point-to-multipoint)**

Afterwards, the access and the protocol stack will be initialized in accordance with the selected setting.

3.2 Initialization phase followed by a B channel Test

Initialization on a BRI S/T or U -interface access

The ARGUS will begin the initialization after taking over the existing, confirmed settings or new settings for the type of access and mode. Next the ARGUS will setup Layer 1. While it is setting up Layer 1, the "Sync/L1" LED above the display will blink. If the ARGUS cannot setup Layer 1, it will display the message "No net". When the ARGUS is operated on a U interface access, it can take up to 2.5 minutes to activate Layer 1. As soon as Layer 1 is successfully setup, the "Sync/L1" LED will light continuously.

Once Layer 2 has been setup, the "Rx/Tx/L2" LED will light.




If both modes (P-P / P-MP) are found when Layer 2 on the D channel is checked, the mode must be selected manually (see page 15).

If everything has been detected without errors, the ARGUS will display the type and mode of access found. Additionally, a qualitative assessment of the level will be displayed. The ARGUS will automatically determine the protocol (in both TE and NT mode) or use the protocol set manually (see page 19 protocol). On a bilingual access, the ARGUS will use the DSS1 protocol.

The "IP / L3" LED will light after the ARGUS has setup Layer 3. At the same time the ARGUS will start a B channel test and then display the results. If an error occurs in the B channel test (e.g. access is not plugged-in), the ARGUS will display an error message (see appendix). The ARGUS will then idle in the State display:

Example:
ARGUS State Display on a BRI access



Display:

- Type of access (in the example, BRI S/T)

- Access Mode

- NTs** NT Simulation Slave (see L1 page 19)
- NTm** NT Simulation Master L1
- TEs** TE Simulation Slave L1
- TEm** TE Simulation Master L1

- Bus configuration

D channel Layer 2 mode

- P-P** Point-to-point
- P-MP** Point-to-multipoint

- D channel protocol

in the example, DSS1

- The availability of the B channels

- B12** Both channels are available
- B1-** Only B channel 1 is available
- B-2** Only B channel 2 is available
- B--** No B channel is available




If only one B channel is available, this can have an impact on the service check and the testing of the supplementary services.

- Level and voltage evaluation

OK normal	Level/voltage is alright
<<	Level/voltage too low
>>	Level/voltage too high
--	No level/voltage
OK INV	Emergency supply
<Start>	Repeat the B channel test.
<Setting>	Open the "ISDN settings" menu, see page 18.

It must be mentioned again, that the ARGUS only determines the general bus status once when switched on or when the ARGUS first connected. On the other hand, the status of the protocol stacks for Layers 1, 2 and 3 will be continually monitored and displayed.


- ARGUS State Display on a U interface

Display:

- Access type (in the example, BRI U)
- Access mode (in the example, TEs)
- L2 protocol (in the example, DSS1)
- BRI U variant (line coding)
- Voltage when idle

3.3 ISDN Settings

It is possible to configure the following "ISDN Parameters" as needed. The procedure for configuring a parameter will be illustrated with a single example: It is possible to restore the parameters.



The ARGUS takes the marked setting for use as the default and returns to the next higher menu.

ARGUS - Main Menu.

Use the cursor keys to select, e.g. protocol.



Mark the desired protocol. The selected protocol will be marked in blue (in this example, Automatic). The default protocol will be marked in the display by a ●. The ARGUS will use the default protocol for the ISDN connection.



Open the next higher menu without making any changes. The ARGUS will continue to use the default setting.

Setting	Explanation
ISDN:	
L1 permanent?	On a BRI S/T connection in NT mode, Layer 1 (L1) is permanently active. Default setting: No

Protocol	<p>As an alternative to automatic protocol determination, you can also set the Layer 3 D channel protocol manually. If the protocol setting is changed, the ARGUS will save this new setting permanently, i. e. it will use this protocol the next time that it is switched on.</p> <p>ISDN Protocols:</p> <ul style="list-style-type: none"> - Automatic - DSS1 - CorNet-N - CorNet-T (not for the access types "NT P-P" and "NT P-MP") - CorNet-NQ (for the access types "TE P-P" and "NT P-P" only) - QSIG (for the access types "TE P-P" and "NT P-P" only) - VN4 <p>Default setting: Automatic</p>
Alerting mode	<p>You can specify whether, for an incoming call on a S-Bus point-to-point access, the ARGUS should only display the access number without extension or the complete number with extension. When set to "Manual", the ARGUS will display the extension. Incoming calls will be signaled. When the ARGUS accepts a call, it will send the Layer 3 "Alert" message. The digits of the extension that have been sent by this point will be displayed.</p> <p> With the Manual setting, an incoming call must be answered within 20 seconds or it will be lost. Furthermore, you should note that the remote subscriber will not hear a ringing tone.</p> <p>If it is set to "Automatic", the ARGUS will only display the access number without extension or, depending on the configuration of the access in the exchange, it may not display the number called at all.</p> <p>Default setting: Automatic</p>
Clock mode	<p>This parameter sets where the clock will be generated in the case of a S-Bus access. You can either specify that the ARGUS generates the clock (Master) or that it is the slave of a clock generated at the other end (Slave).</p> <p>Setting:</p> <p>In NT mode: Master</p> <p>In TE mode: Slave</p> <p>Leased line: Slave</p> <p>Any change to this setting will not be saved permanently; it will only apply to the current measurement.</p>

<p>BRI termination</p>	<p>You can add terminating resistors to a BRI access.</p> <p>Setting:</p> <p>In NT mode: Terminating resistor switched in</p> <p>In TE mode: No terminating resistor is switched in</p> <p>Leased line: No terminating resistor is switched in</p> <p>Any change to this setting will not be saved permanently; it will only apply to the current measurement.</p>
<p>Call parameters</p>	<p>Four different parameters can be set for (ISDN) calls generated on both the network-side (ARGUS in NT mode) and on the user-side (ARGUS in TE mode):</p> <p>1. Type of number (TON) for the CGN (=CGPN) or CDN (=CDPN) element of a SETUP signal</p> <p> Network-side: Net CGN TON Net CDN TON</p> <p> User-side: User CGN TON User CDN TON</p> <p> Default setting: unknown</p> <p>2. Numbering Plan for the CGN (=CGPN) or CDN (=CDPN) element of a SETUP signal:</p> <p> Network-side: Net CGN NP Net CDN NP</p> <p> User-side: User CGN NP User CDN NP</p> <p>3. CGN/CDN Subaddress CGN/CDN Subaddress Type: User specific and NSAP Default setting: User specific</p> <p>4. UUI (User User Info)</p> <p>*For more information, see Prefix on page 21.</p>
<p>Services</p>	<p>Up to three user-specified services (user spec. 1 to user spec. 3) can be entered and saved. For each "user spec. service", you must enter the info-elements BC, HLC and LLC in hexadecimal (switch with the left softkey). To do so, use the keypad and the A . . F softkey (e.g. to enter a "C", press the softkey three times; for an "F", press it six times).</p>

Call acceptance	<p>If the ARGUS is set to "own MSN/DDI" and is in TE mode on a P-MP access, it will only signal those calls which are placed to the MSN (on a P-P access, the DDI) of the access under test. If set to "all MSN/DDI", the ARGUS signals all calls.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> - the own number must be entered in the speed-dialling memory under "own number" (see "Saving call numbers in the speed-dialling memory" on page 141). - the incoming call must have a destination MSN <p>Default setting: all MSN/DDI</p>
Voice coding	<p>There are two options for coding voice data in a B channel:</p> <ul style="list-style-type: none"> - A-law (Default setting) - μ-law
DTMF / Keypad	<p>DTMF or Keypad setting</p> <p>Default setting: DTMF</p>
CUG Index	<p>Enter the CUG index that the ARGUS should use when testing the CUG (Closed User Group) service.</p> <p>Range: 0 to 32 767</p> <p>Default setting: 148</p>
Keypad	<p>A maximum of three Keypad Infos can be stored. First use the vertical cursor keys to select one of the three available memory locations for Keypad Infos.</p> <p><Edit> Edit the selected Keypad Info. Afterwards, use the keypad to enter the Keypad Info.</p> <p> Save the Keypad Info.</p>
Prefix	<p>Entry of the national or international telephone prefix. The prefix is selected in "Call parameters" under the selection "Type of number", see page 20.</p> <p>National: 0 (Default setting)</p> <p>International: 00 (Default setting)</p>
AOC	<p>Set wheter the NT simulation charging information to be transmitted.</p> <p>Default setting: On</p>

Starting functions with the numeric keys / key combinations

Using the ARGUS keypad, you can start important functions / tests directly, regardless of the menu that the ARGUS is currently showing. If a function is called where the ARGUS expects the entry of a digit, pressing a number key will be interpreted as the expected input. The assignment of functions to the numeric keys can also viewed on the ARGUS display. Open the Main Menu and select "Help" or press number key "1". An overview of the available key combinations can be found in the main manual.

3.4 Bit Error Rate Test

The bit error rate test (BERT = Bit Error Rate Test) is used to check the transmission quality of the access circuit.

As a rule, the network operator will guarantee an average error rate of 1×10^{-7} , in other words in long-term operation 1 bit error in 10 million transmitted bits. A higher bit error rate will be especially noticeable in transmitting data.

The application program detects the errors in the data blocks transmitted and requests that the remote partner send them again, which reduces the effective throughput of the ISDN connection.

In the bit error rate test, the tester establishes an ISDN connection to a remote tester (end-to-end) or calls itself (self call), sends a standardized (quasi-) random number string and compares the received data with that which was sent. The individual bit errors are summed and depending on the test procedure and equipment evaluated in accordance with the ITU Guideline G.821.

During the test, the ARGUS counts the bit errors and after the test is done it calculates the bit error rate and other parameters in accordance with ITU-T G.821.

As a rule, the quality of the network operator's access circuits is quite good. Therefore, no bit errors should occur in a one-minute test. However, if an error occurs, the test should be repeated with a measurement time of 15 minutes to achieve higher statistical precision. The access circuit is heavily distorted, if more than 10 bit errors occur within a test period of 15 minutes.

Contact the network operator or the supplier of the PBX equipment and ask them to test your access circuit.



When used on an NGN (Next Generation Network), where a packet switched connection (e.g. IP) can follow a circuit switched network (e.g. ISDN), the "UDI64k" must be explicitly selected for the BERT. Then the ARGUS will, in accord with RFC 4040, switch to clear mode, deactivate the echo canceler and not use a codec.

The BERT can be performed in three different ways:

1. BERT in an extended call to oneself

A remote number is not needed, since the ARGUS sets up the ISDN connection to itself. In this case, the ARGUS requires two B channels for the test.

2. BERT with a loopbox

A loopbox (e.g. another member of the ARGUS family of testers at the remote end) is required. The test uses one B channel.

3. BERT end-to-end

This test requires a waiting remote tester (e.g. a second ARGUS in the "BERT wait" mode)(see page 30, BERT wait). A bit pattern is sent to this remote tester. Independent of the bit pattern received, the remote tester will use the same algorithm to generate the bit pattern that it sends back. Therefore, both directions are tested independently.

BERT Parameter Configuration

Settings

ARGUS - Main Menu



BERT

The procedure for configuring a parameter will be illustrated with a single example. The default settings can be restored at any time.



BERT time



Enter the BERT time



The ARGUS sets the value entered as the default BERT time and returns to the next higher menu.

Setting	Explanation
BERT:	
BERT time	<p>You can use the keypad to enter measurement times ranging from 1 minute to 99 hours and 59 minutes (= 99:59).</p> <p> If the time is set to 00:00 (= BERT with unlimited measurement time), the BERT will not stop automatically. In this case, the BERT must be terminated manually by pressing the .</p> <p>Default setting: 00:00 (continuous)</p> <p>In the case of an Autom. Test (<i>see chapter 3.9 Automatic Performance of Multiple Tests, page 50</i>) the ARGUS will automatically set this to a value of 1 minute.</p>
Bit pattern S/T/U	<p>This function is used to select the bit pattern to be sent cyclically by the ARGUS to perform a BERT on a S-Bus or U interface access. Several predefined bit patterns are available</p> <p>Default setting: 2¹¹-1</p> <p>Additionally, it is also possible to enter a 16 bit long pattern of your choice in binary: Use the horizontal cursor keys to move the cursor right or left.</p> <p><Delete> Changes the digit before the cursor from 1 to 0</p>
Error level	<p>This is the level used to evaluate whether the BERT had an "acceptable" bit error rate.</p> <p>If the BERT has a bit error rate, which exceeds this error level, the ARGUS will display a "NO" (Not OK) as the test result. Using the keypad, this parameter can be set to any value from 01 (= 10⁻⁰¹) to 99 (= 10⁻⁹⁹).</p> <p>The default threshold (error level) is 10⁻⁰⁶ (1E-06). That means that, in the event that the bit error rate is less than 10⁻⁰⁶ (one error in 10⁶ = 1,000,000 sent bits), the bit error rate test will be evaluated as "OK".</p>
HRX value	<p>Setting the HRX value (Hypothetical reference connection, see the ITU-T G.821). Using the keypad, you can enter a value ranging from 0 to 100 %.</p> <p>Default setting: 15 %</p>

BERT Start

Single tests

ARGUS - Main Menu.

BERT

BERT start

Enter the phone number

Select service

Select B channel

BERT active

```

2^11          B01
synchronous
Sync.time:    00:00:17
LOS:          0
Error:        0

```

BRI

Reset

TM

Error

The speed-dialling memory will now open (see page 141). Enter/dial your own number to perform the BERT in an extended call to oneself (two B channels) Enter/dial a remote number for a BERT to a loopbox (one B channel) or end-to-end.



Scroll through the speed-dialling memory.

Using the cursor keys, select the service which should be used for the BERT.

First press <Delete> and then enter the B channel on the keypad. If you enter an "*", the ARGUS will choose any B channel that is free.

BERT Start

The ARGUS display after the connection has been setup and synchronized in both the send and receive directions:


- The bit pattern and B channel / bit rate used
- The synchronicity of the bit pattern (in this example, synchron)
- Sync. time in h:min:s (time in which the ARGUS can sync to the bit pattern)
- LOS counter: shows the absolute number of synchronization losses. Synchronization is lost at an error rate greater than or equal to 20 % within a period of a second.
- The number of bit errors that have occurred

<Error>	The ARGUS will generate an artificial bit error, which can be used to test the reliability of the measurement (in particular for end-to-end tests).
<TM>	Open the Test Manager, see page 66.
	Restarts the BERT. The test time and number of bit errors will be reset.
or	
<Reset>	
	Stop BERT

If the ARGUS has been so configured and a bit error is detected, this will be signaled by a brief alarm; in the event that the synchronisation is lost, a constant alarm will sound.


After the BERT is over, the ARGUS will display the cause and the location which initiated the disconnect. If the test ran normally, the ARGUS will display "Active clearing" on this line.

BERT results:



Scroll through the results


- The evaluation of the results depends on the error threshold (in this example OK), see page 24.
- Trans. data (transferred data): (K = 1024 bits, k = 1000 bits)
- Sync. time in h:min:s (Time within which the ARGUS can sync to the bit pattern)
- No. LOS (counter) Synchronization is lost at an error rate greater than or equal to 20 % within a period of a second.
- LOS time: Duration of the BERT minus the sync. time (the time in which the ARGUS could not sync to the bit pattern after it had been in sync at least once)
- abs. err: The number of bit errors
- Rel. err: The bit error rate (e.g. $9.7E-07 = 9.7 \cdot 10^{-7} = 0.00000097$)



Display of other characteristic values (in accordance with ITU-T G.821):

All values are given as relative values (in percentages) as well as in absolute figures.

The ARGUS evaluates the measurement results to determine whether they satisfy the threshold limits defined in the CCITT G.821; with consideration of the defined hypothetical reference connection HRX (displaying OK or NO (Not OK)).



Scroll through the results



Return to the previous display

Characteristic values (in accordance with ITU-T G.821)

HRX	Defines the hypothetical reference connection.
EFS	Error Free Seconds: The number of seconds in which no error occurred.
ES	Errored Seconds: The number of seconds in which one or more errors occurred.
SES	Severely Errored Seconds: The number of seconds in which the bit error rate is greater than 10^{-3} . In one second, 64,000 bits are transferred, thus BitErrorRate (BER) = 10^{-3} equates to 64 bit errors.
US	Unavailable Seconds: The number of all sequentially adjacent seconds (at least 10 sec) in which $BER > 10^{-3}$.
AS	Available Seconds: The number of all sequentially adjacent seconds (at least 10 sec) in which $BER < 10^{-3}$.
DM	Degraded Minutes: The number of minutes in which the bit error rate is greater than or equal to 10^{-6} . In one minute, 3,840,000 bits are transferred, thus a BER = 10^{-6} corresponds to 3.84 bit errors (3 errors = OK (no degraded minutes), 4 errors = NO (Not OK) (Degraded Minutes).
LOS	Loss of Synchronize: Synchronization is lost at an error rate greater than or equal to 20% within a period of a second. The absolute number of synchronization losses will be shown.

BERT saving

The ARGUS can store the results of several BERTs. The ARGUS saves the results together with the date, time and call number of the access under test (if this number has been entered as the "own" number in the speed-dialling memory, see page 141) in the next free memory location. If all of the memory locations are used, the ARGUS will request permission to overwrite the oldest test results.

BERT result	
OK	
sent data:	2564kb
sync.time:	00:00:41
Nb. LOS :	0
LOS time :	00:00:00
abs.err.:	0
BRI	
Save	TM More



ARGUS info	
Save test result?	
BRI	
No	Back Yes

Use the keypad to enter the name under which the ARGUS should save the results.

BERT - saving the result



BERT start

BERT wait

In "BERT wait" mode, the ARGUS will wait for the BERT at the remote end. This is required for an end-to-end test.

Single tests

ARGUS - Main Menu.



BERT



BERT wait

Activate "BERT wait"



```
BERT active
2^11          B01
synchronous
Sync.time:    00:00:17
LOS:          0
Error:        0

BRI
Reset  TM  Error
```

The ARGUS first waits for a call and then sets up the connection. During the connection, the received bit pattern will be evaluated while an independent bit pattern will be sent back.

<TM> Opens the Test Manager (see page 66).

For information on the displays shown, see "BERT start" on page 24.



Display BERT results

B channel loop

"B channel loop" mode is required in order to run a bit error rate test using a loopbox (an ARGUS is the loopbox) at the remote end.

Single tests



BERT



B channel loop



B-channel loop

wait active

BRI

TM

Menu

B-channel loop

B01 Telephony ISDN
 from:123
 to : 1234
 TON:Unknown
 NP :unknown
 CR value: 4
 length/flag: 1/1

BRI

TM

Menu

ARGUS - Main Menu.

Activate a "B channel loop"

The ARGUS will wait for a call. Any incoming call (regardless of the service) will be taken immediately. The ARGUS will switch a loop back in the B channel that is specified by the exchange and then send the received bit pattern back to the caller/sender.

<TM> Open the Test Manager (page 66).

<Menu> Open the Main Menu: the "B channel loop" remains active.

From this menu, you can start a second B channel loop connection (this is also possible using <TM>). If you press <TM> (see page 66) the ARGUS will return to the "B channel loop, wait active" display.



Exit the "B channel loop" mode.

Display shown after accepting a call:

- B channel used and service
- The caller's number (from:)
- The number dialled (to:)
- If available: TON, NP, UUS etc.

<TM> Opens the Test Manager (page 66).

<Menu> Open the Main Menu.



Clear down the B channel loop connection; the B channel loop, however, remains active!

3.5 Supplementary Services Test

The ARGUS checks whether the access under test supports supplementary services.

Suppl. service interrogation in DSS1

Single tests



Supplementary Services



Enter own number




Select service



Select B channel



Select test case



ARGUS Main Menu

The speed-dialling memory opens (see page 141).



Scroll through to your own call number (the number of the access under test) or enter it using the keypad.

The ARGUS will test the availability of the supplementary service (in part by placing a call to itself).

Using the cursor keys, select the service which should be used for the supplementary services test.

Enter the B channel on the keypad. The ARGUS suggests the B channel used last. If you enter an "*", the ARGUS will choose any B channel that is free.

The ARGUS will determine whether the selected supplementary service is supported by this access.

Start test

Display the test results:

- + = suppl. service supported
- = suppl. service not supported



Scroll through the results



Close the results display and open the next higher menu

Test	Explanation
TP	The ARGUS tests the TP (Terminal Portability) supplementary service by making a self call.
HOLD	The ARGUS tests the HOLD supplementary service by making a self call.
CLIP	<p>The ARGUS checks, one after the other, whether the 4 supplementary services CLIP, CLIR, COLP and COLR are supported. To do so, the ARGUS will setup as many as three calls to itself.</p> <p>CLIP: Will the calling subscriber's number be displayed at the called subscriber? t = CLIP temporarily available p = CLIP permanently available</p> <p>CLIR: Will the display of calling subscriber's number at the called subscriber be suppressed or is it possible to temporarily suppress the display? If the ARGUS displays an *, it is not possible to determine the availability of the service, since no CLIP has been setup. t = CLIR temporarily available p = CLIR permanently available</p> <p>COLP: Will the call number of the subscriber who answered be displayed on the caller's phone?</p> <p>COLR: Will the display of the call number of the subscriber who answered be suppressed on the caller's phone or is it possible to temporarily suppress the display? If the ARGUS displays an *, it is not possible to determine the availability of the service, since no COLP has been setup.</p> <p> The suppl. services CLIP, CLIR, COLP and COLR will be tested in pairs. If CLIR or COLR is set up permanently, it is not possible to make a clear assessment.</p>
DDI	Can a caller directly dial in to an extension on the PBX access under test?
CF	<p>The ARGUS will check whether the 3 supplementary services CFU, CFB and CFNR are supported.</p> <p>CFU: Can this access immediately forward an incoming call?</p> <p>CFB: Can this access forward an incoming call when it is busy; in other words does it support Call Forwarding Busy?</p> <p>CFNR: Can this access forward an incoming call when it is not answered?</p>

	<p>In the CF test, the ARGUS attempts to set up a call diversion to the call number that is in the speed-dialling memory location for "remote call number 1" (see "Saving call numbers in the Speed-dialling Memory" on page 24). When performing a CF test, the ARGUS will report an error if this location does not contain a valid call number to which it is possible to divert a call.</p>
CW	Does the access under test support call waiting?
CCBS / CCBS-T	Will the access under test automatically recall a remote subscriber if the number called was busy?
CCNR / CCNR-T	Will the access under test automatically recall a remote subscriber if the call was not answered?
MCID	Does the access tested allow identification of malicious callers (call tracing)?
3pty	Does the access under test support a three-party conference call? For this test, you need the assistance of a remote subscriber, whose call number must be entered. A connection is necessary.
ECT	Is an explicit call transfer supported by the access under test? For this test, you need the assistance of a remote subscriber, whose call number must be entered. A connection is necessary.
CUG	The ARGUS then uses a self call to check whether the access under test belongs to a closed user group.
CD	An incoming call will be diverted immediately. This form of call diversion differs from the others in that it is invoked on a call-by-call basis, and is not preconfigured to a specific destination.
AOC	The ARGUS checks whether the charges can be sent to the access under test. The test uses a call to oneself to check both AOC-D (AOC during a call) and AOC-E (AOC at the end of a call).
SUB	A call is made to oneself and answered to check the transfer of the sub-address in both directions. Are sub-addresses supported on the access under test?
UUS	Does the access under test support the transfer of user data?

No Screening	If the caller supports CLIP No Screening (CNS) and the ARGUS is in TE mode, the ARGUS will display all of the connected network-side call numbers. It is also possible to check the CLIP No Screening function by monitoring with the WINanalyse software on a PC.
---------------------	--

Error Messages

If an error occurs during the Supplementary Services Tests or if it is not possible to setup a call, the ARGUS will display the corresponding error code (e.g. 28).

Example: The error code 28 equates to "wrong or invalid number".

In the table below, you will find that this is an error from the network and that it reports that the call number was incomplete or in the wrong call number format (see "ARGUS Error Messages (DSS1)" on page 149).

A few error codes and their meaning:

Description	Cause (from network) DSS1	Cause ARGUS internal
no or another access	—	201, 204, 205, 210, 220
wrong or invalid number	1, 2, 3, 18, 21, 22, 28, 88	152, 161, 162, 199
one or more B channels busy	17, 34, 47	—
wrong service	49, 57, 58, 63, 65, 70, 79	—

3.6 Service check

The ARGUS checks, which of the following services are supported by the access under test:

Service	Name displayed on the ARGUS
Speech	Speech
Unrestricted Digital Information (data telecommunications)	UDI 64kBit
3.1 kHz audio	3.1
7 kHz audio	7 kHz audio
Data transfer with tones & displays	UDI-TA
Telephony	Telephony ISDN
Telefax Groups 2/3	Fax G3
Fax Group 4	Fax G4
Combined text and facsimile communication	Mixed
Teletex Service basis mode	Teletex
International interworking for Videotex	Videotex
Telex	Telex
OSI application according to X.200	OSI
7 kHz Telephony	Telephony 7kHz
Video telephony, first connection	Video telephony 1
Video telephony, second connection	Video telephony 2
Three user-specific services (see, page 20)	User-specified 1 to 3

The test runs automatically.

The ARGUS will make a separate self call to test each of the user-specific services. However, the call will not be answered so no charges will be incurred.

Single tests

ARGUS - Main Menu



Service check



Enter own number

Enter the own (local) number of the access under test or select it from the speed-dialling memory.



Select B channel

The ARGUS suggests the B channel used last. If you enter an "*", the ARGUS will choose any B channel that is free.



Service test starts



There are PBXs that use separate call numbers for incoming and outgoing calls. In this case, for the Service tests, you can enter a “remote” call number that does not match the “own” number that is stored in the ARGUS. If the Service check should extend outside of the local exchange, it is possible to perform the Service check in an end-to-end mode. In this case, you must enter the remote call number for a second terminal device. The ARGUS will then automatically check whether the remote terminal can accept the call under the various services – in other words, whether it is “compatible” with these services. In the test results, the second part (second +, - or *) refers to the answer from the remote exchange.

Test results:

Service check	
Speech	+*162
UDI 64kBit	+*162
3.1 kHz audio	+*162
7 kHz audio	+*162
UDI-TA	+*162
Telephony ISDN	+*162
Fax G3	+*162
BRI	

The ARGUS will display the results of the test once it is done. The ARGUS makes a distinction between outgoing calls (the first +, - or *) and incoming calls (the second +, - or *).

- + = suppl. service supported
- = suppl. service not supported
- * = No definite assessment can be made so an error code is displayed. In such case, it is recommended that you have someone place a call to the access under test using this service.



Scroll through the results



Close the results display and open the next higher menu.

Interpreting the test results:

Display Explanation

- + + The self call functions OK or the remote end can take the call for this service.
- + - The call was sent successfully, however, it was rejected at the remote end due to a lack of authorization.
- An outgoing call with this service is not possible.
- + * The call was sent successfully, the call to the remote end failed (e.g. remote end busy thus no B channel was available for the call back).
- * Wrong number, no B channel available or other error.


If the outgoing call is not successful, it is not possible to make a statement about an incoming call. Therefore, you will never see “- +” or “- **” on the display.

3.7 X.31 Test

The ARGUS will perform a “Manual X.31 Test” or, if desired, an “Automatic X.31 Test”: In the case of an automatic test, the ARGUS will first setup the D channel connection and then an X.31 connection. The ARGUS will then automatically clear the connection and display the results.

In the case of a manual test, the ARGUS will setup a D channel connection and an X.31 connection. The duration of this connection is determined by the user (or the opposing end). For the duration of the connection, the ARGUS will repeatedly send a predefined data packet. The ARGUS will count all of the data packets sent and received and will display (where possible) the contents of the data packets received.

Configuring the X.31 parameters



ARGUS - Main Menu.

The ARGUS stores the parameters of the X.31 Test in the three X.31 profiles.



Mark a profile for editing. The selected profile will be marked blue in the display. The default profile will be marked in the display with a ●. The ARGUS will use the parameters in the current profile for the X.31 Test.



The ARGUS takes over the marked profile as the default and returns to the Settings menu.

The default parameters can be restored at any time.

The ARGUS saves the TEI entered and returns to the next higher menu.

Setting	Explanation
X.31 profile:	Up to three user-defined X.31 profiles can be created. <Edit> The selected profile will be opened for editing.
Packet number	Number of packets sent Range: 0 to 65 000 Default setting: 10
TEI	Entry (from the keypad) of the TEIs (Terminal Endpoint Identifier) to be used in the X.31 test. If you enter **, the ARGUS will automatically select a TEI. Range: min. 0 to a max. of 63 Default setting: ** (automatic)
LCN	Entry (from the keypad) of the LCN (Logical Channel Number) to be used in the X.31 test. Range: 0 to 4095 Default setting: 1
Packet size	Size of the data packets: 16, 32, 64, 128 or 256 bytes. Default setting: 128 Bytes
Agree packet size	Negotiate with the network side (DCE) regarding the data packet size. If the desired data packet size is larger than the default, this parameter should be set to "yes". Default setting: No
Window size	Window size of Layer 3, selection of 1 to 7 packets. Default setting: 2 Packets
Agree window size	Negotiate between the terminal (DTE) and the network (DCE) an agreement regarding the window size. Default setting: No
Throughput	Data throughput in bits/s: 75, 150, 300, 600, 1200, 2400, 4800 or 9600 bits/s. Default setting: 1200 bit/s
Agree throughput	Agree on the data throughput Default setting: No

User data

Content of the user data
- Format setting for the user data
- Entry of the ASCII data

ASCII data

↓

● **ASCII data 1/3**

↓ <Edit>

Enter ASCII data

↓

Save ASCII data

<12>ab>
<ab>AB>

<AB>12>

<Delete>

Use the numeric keypad to enter the ASCII data. When the right softkey is pressed it assumes a different meaning and thus influences the entries made from the keypad (letters or digits):

Entry of the digits 0 to 9 plus * and #

Entry of lowercase characters (e.g. to enter a "C" press the "2" on the keypad three times), plus @, /, -, and .

Entry of the uppercase characters and @, /, - and .

Move the cursor

Delete the character before the cursor

Do not save ASCII data.

Hex data

↓

● Hex data 1/3

↓ **<Edit>**

Enter hexadecimal data

↓

Save hexadecimal data

<Delete>

- Entry of the hexadecimal data:

Select one of the three available memory locations for the hexadecimal data (in this example, the first location 1/3)

Use the keypad to enter the hex value. To enter the values "A...F", use the softkey **<A...F>** (e.g. to enter a "C", press the softkey **<A...F>** three times). To confirm the entry of the hexadecimal characters A to F press **<OK>** (the softkey in the middle changes from **<Delete>** to **<OK>**).

<Delete> Delete the character before the cursor

X Do not save the hexadecimal values.

CUG	Closed User Group. Default setting: No
CUG Index	Coding for Closed User Group Range: min. 0 to 255 max. Default setting: 1
D bit	Local: DCE acknowledges data packets, i. e. flow control on local DTE-DCE path. End-to-end: DTE-DTE flow control Default setting: Local
Facilities	Coding for various supplementary services A maximum of 3 facilities can be stored. For instructions, see User data on page 40.
Profile name	Use the keypad to enter the profile name for the X.31 profile. The ARGUS will later display this name for the profile.


Automatic X.31 Test

D channel

The "automated X.31 Test in D channel" consists of two steps:

First step: The ARGUS tests whether it is possible to access the X.25 service via the D channel on the ISDN access under test. The ARGUS sequentially checks all the TEIs from 0 to 63. All the TEIs with which the X.31 service is possible on Layer 2 will be displayed.

Second step: For each TEI with which X.31 is possible on Layer 2, a "CALL_REQ" packet will be sent and then the ARGUS will wait for an answer. Beforehand, the ARGUS will request the entry of the X.25 access number, which will be saved in speed-dialling memory under X.31 test number. With the entry of the X.25 access number, you can - if you wish - select a logical channel (LCN) other than the default.



Test results

```

X.31 Test
TEI      : 02
Schicht 2: +
Schicht 3: - 13 67
BRI

```

The ARGUS will check whether the X.31 service is available for Layer 3 for the TEIs found in Step 1.

Example: Test results

TEI 02 The first valid TEI is 02.

Layer 2 + First test step was successful
 - First test step was not successful

Layer 3 + Second test step was successful
 - Second test step was not successful


In this case, the ARGUS will display the relevant X.31 cause for the failure (in the example above: 13) and the associated diagnostic code, if there is any (see the Appendix page 150).

If the X.31 service is not supported, the ARGUS will report "X.31 (D) n. impl.".

Manual X.31 Test

D channel

The ARGUS first requests a TEI, an LCN and an X.31 number (the ARGUS uses the values stored in the X.31 profile). If an "*" is entered for the TEI, the ARGUS will automatically determine a TEI. Using the first TEI with which X.31 is possible, the ARGUS will setup a connection.



```

X.31 (D) test
X.31 (D) OutCall
LCN: 1 TEI: 2
to: 123
    
```

BRI



Save X.31 test?

The ARGUS will display the LCN, the TEI, the X.31 number and the negotiated connection parameters.

- <Data> Sends a predefined data packet
- <Statistic> Displays the L1/L2/L3 statistics
- <L2> Scrolls to the L2 statistics
- <L3> Scrolls to the L3 statistics


The X.31 connection will be maintained until the user or the remote end clears it. When the X.31 connection is cleared, the ARGUS will automatically clear the D channel connection.

- <Yes> The ARGUS saves the results.

3.8 Call Forwarding (CF)

CF Interrogation

The ARGUS will check whether a call diversion has been setup in the exchange for the access under test. The ARGUS will show the type of diversion (CFU, CFNR or CFB) and the call diversion's service. The display is limited to a maximum of 10 call diversions. The ARGUS will count any additionally set up call diversions. The ARGUS can clear any call diversion setup in the exchange.



ARGUS - Main Menu.

Start the CF Interrogation. The test can take a few seconds.

Display:

- Type of call diversion (in the example, CFU)
- The type of call diversion will be displayed / number of call diversions found
In this example: Display the first of a total of one call diversion found (01/10)
- The call diversion service
- The number that should be diverted (from:)
- The number to which calls should be diverted (to:)

<Delete> Delete call diversion

Security query

<Yes> Clears the displayed call diversion in the exchange. If this is not possible, the ARGUS will report: "Call diversion not changeable!"

<All> Delete all call diversions.

 Do not delete the call diversion!
Open the Single Tests Menu.




Some PBXs or exchanges do not permit the use of the mechanism used (by the ARGUS) for the interrogation of the call diversions for all MSNs or they return a negative acknowledgement of the interrogation of call diversions, implying that no call diversions have been set up. In the event of a negative acknowledgment, the ARGUS will require that the local MSN is entered. The call diversion interrogation will be repeated MSN-specific. Naturally, in this case, the results of the interrogation of the call diversion only apply for the entered MSN and not for the entire access.

Abbreviations used for the services and service groups on the display:

Bearer Service	Abbreviation
All services	A11
Speech	Spch
Unrestricted Digital Information (data telecommunications)	UDI
Audio 3.1 kHz	A3k1H
7 kHz audio	A7KHz
Telephony 3.1 kHz	Te131
Teletext	TTX
Fax Group 4	FaxG4
Video syntax based	ViSyB
Video Telephony	ViTe1
Telefax Groups 2/3	FaxG3
Telephony 7 kHz	Te17k


CF Activation

Using the ARGUS, call diversions can be setup in the exchange.



CF Delete

The ARGUS can clear selected call diversions setup in the exchange.



3.9 Automatic Performance of Multiple Tests

The ARGUS performs an automatic test series and displays the test results. The required parameters (e.g. measurement time and error level for the BERT, see page 23) should be checked before the automatic test series is begun.


Using the ARGUS WINplus or WINanalyse software, the test results can be saved on a Windows PC. On the PC, WINplus / WINanalyse can be used to generate a comprehensive report that can then be printed, sent by e-mail and/or archived. The ARGUS automatically performs the following sequence of single tests:

On a BRI S/T or U-interface (ARGUS in TE mode)

- Status
- Level measurement
- Service check
- BERT in an extended call to oneself
- Supplementary service test (Suppl.serv.test)
- CF Interrogation (Call Diversions)
- X.31 test


On a BRI S/T or U interface leased line (permanent circuit)

- Level measurement
- BERT in end-to-end mode (e.g. with a loopbox on the remote end)



ARGUS - Main Menu

Select Auto test.



Select the memory location. For each memory location used, the ARGUS will display the name assigned to the memory location (in this example, New result).



Press the  on the numeric keypad to directly access a memory location. A indirection through the main menu is not necessary.



In TE mode:

Enter the "Own number"; on accesses using the DSS1 protocol you must also enter a "remote number".



Select service


(required for Supp.Serv.test and BERT).



During the test sequence, the ARGUS will display the single test currently running.

Start the automatic test

Terminating the test (early):




Interrupt test



Open the next higher menu.

The ARGUS will terminate the test sequence, any test results already gathered will be lost. Any "old" data stored in this memory location from a prior test will be retained.

Skipping individual tests:



Stop current test




In this case, the ARGUS will execute the next single test.

A single test can be skipped: In this example, the ARGUS is currently running a Service check.

Stop the current single test.

Resuming a test:



The ARGUS can resume an interrupted single test: In this example, the ARGUS is running a Service test.



Stop the current single test



The ARGUS repeats the "interrupted" single test (in the example: a Service check).

3.10 Connection

The ARGUS can set up a connection for the following services:


Service	Display
Speech	Speech
Unrestricted Digital Information (data telecommunications)	UDI 64kBit
3.1 kHz audio	3.1 kHz audio
7 kHz audio	7 kHz audio
Data transfer with tones & displays	UDI-TA
Telephony	Tel. ISDN
Telefax Groups 2/3	Fax G3
Fax Group 4	Fax G4
Combined text and facsimile communication	Mixed
Teletex Service basis mode	Teletex
International interworking for Videotex	Videotex
Telex	Telex
OSI application according to X.200	OSI
7 kHz Telephony	7 kHz
Video telephony, first connection	Videotel. 1
Video telephony, second connection	Videotel. 2
Three user-specified services (see, page 20)	User-specified 1 to 3

A headset or the integrated handset can be used as a phone during a telephone connection.

When a connection is set up, pressing the number keys (0-9) or the * or # will generate and send the corresponding DTMF tones.

Overlap sending (outgoing call)

In overlap sending, the digits entered for the call number are sent individually.



ARGUS - Main Menu

<Call no.> Open the call number entry dialog

- The ARGUS will open the Connection display. Besides overlap sending (as shown on the left), one of the following can be selected here
 - En-bloc sending (see page 57)
 - Redialling (see page 58)
 - Keypad dial (see page 62).

Select the service to be used for the connection.

Enter the B channel on the keypad. The ARGUS suggests the B channel used last. Press **<Delete>** first before entering a new B channel. If you enter an *, the ARGUS will choose any B channel that is free. The ARGUS will show whether the B channel is available.

To set up a connection

Enter the call number on the keypad.

Display:

- B channel and service
- The number in the speed-dialling memory under "own number", see page 141 (from:)
- The number dialled (to:)
- Other information depending on the access, e.g. TON and NP

<TM> Start the Test Manager, see page 66.

<VoLume> Set the volume

or Cancel setup




The connection is setup using B channel 1.



Depending on the type of access other information will be displayed.

- Subaddress of the caller (SUB)
- Destination number
- User-User Information (UUI)
- Display Information
- Type of number (TON)
- Numbering plan (NP)
- Units for charges



<TM> Start the Test Manager, see page 66.

<VoLume> Set the volume

- Display Advice of Charges (AOC):

If the charges are not given in units, rather directly as currency, the ARGUS will display the current charges in currency. If, in DSS1, the call charges are not provided in accordance with the DIN ETS 300182 standard, rather in the form of the information element DISPLAY (DSP), the ARGUS will display the DISPLAY message's character string.



Note regarding the entry of the own call number

Separate the extension from the access number with a # (e.g. 02351 / 9070-40 is entered on the ARGUS as: 023519070 #40). For an outgoing call, the ARGUS uses the entire call number (without #) as the number called (CDPN or DAD) and, for the calling number, only the extension (DSS1-CGPN).

A '#' at the beginning of a call number is treated as a valid character. A '#' at the end of the own call number instructs the ARGUS to not send the caller's number for outgoing calls (CGPN or OAD).



Simplified overlap sending using the telephone key



pressed once:

The ARGUS will open the Connection/Overlap window directly regardless of the currently open menu.



depressed again:

A dial tone will be heard and once the call number is entered, the call will be setup.

En-bloc sending (outgoing call)

In en-bloc sending, the ARGUS sends the entire dialling information in one block.

Single tests

ARGUS - Main Menu



Connection

<Call no.> Open the call number entry dialog



En-bloc



Enter the phone number

The speed-dialling memory opens (see page 141). Use the cursor keys to scroll to desired the number or reenter the number on the keypad.



Select service



The ARGUS will open the Outgo. call display, operation like by overlap sending.



B channel select

Enter the B channel on the keypad (for details on entry, see "Overlap sending").



Outgo.call

B01 Telephony ISDN
 from:02351919650
 to :
 CR value: 4
 length/flag: 1/0

BRI

BRI	TM	VoLume
-----	----	--------

For more information on the displays and operation, see Overlap sending page 55.

<TM> Start the Test Manager, see page 66.


<Volume> Set volume



Cancel setup

Redialling (outgoing call) + Last caller (incoming call)

The ARGUS will set up a call using the last number dialled or the number of the last caller.



Incoming Call

An incoming call can be taken at any time even when a test (e.g. a BERT) is in process (see page 67). The ARGUS will signal an incoming call with an audible tone and a message on the display. On a P-MP access, you can use the Call acceptance (see page 21) function to configure the ARGUS to only signal incoming calls which are addressed to the MSN that corresponds to your own call number. This function can only be used when your own call number has been entered into the speed-dialling memory (see page 141) and the incoming call has a destination MSN.

Incom.call	
B01 Speech	
from:02351919640	
to :	
CR value:	4
length/flag:	1/1
BRI	
Reject	Accept

Reject call

Connection	
B01 Speech	
from:02351919640	
to :	
CR value:	4
length/flag:	1/1
BRI	
TM	VoLume

Disconnect

Display:

- B channel used and service
- The caller's number (from:)
- Destination number (to:)
- Other information depending on the access, e.g. TON and NP

The ARGUS will display the complete destination number (DDI), if the Alerting mode is set to manual (see page 19).

Accept call

Depending on the type of access additional information will be displayed (in the example, CR value and length/flag).



The call number of the last incoming call will be saved in the "Last caller" memory location.

<TM> Start Test Manager, see page 66.


<VoLume> Set volume.

The ARGUS displays the cause of the disconnect (see page 60).



Charge information in NT mode:

In NT mode, the ARGUS will – for incoming calls – send advice of charges in accordance with DSS1 as units and as currency (in euros).

Clear (disconnect) the connection



<TM> Start Test Manager, see page 66
 <Volume> Set volume



The ARGUS will display the cause (see the table below) of the disconnect (e.g. Normal clearing) and the location where the cause occurred (e.g. subscriber). Depending on the access, additional information will be displayed (in this example, Units).

The following causes are shown in clear text:


Reason	Display	Explanation
255	Active clearing	Clearing User actively initiated the disconnection
Length 0	Normal clearing	Cause element with Length 0
01	unalloc. number	Signals "No access under this call number"
16	Normal clearing	Normal clearing
17	User busy	The number called is busy
18	No user respond	No answer from the number called
19	Call time too long	Call time too long

21	Call reject	The call is actively rejected
28	Wrong number	Wrong call number format or call number is incomplete
31	Norm. clearing	Unspecified "normal class" (Dummy)
34	No B chan.avail.	No circuit / B channel available
44	Req.chan.unavail	Requested B channel not available
50	Req.fac.not subs	Requested supplementary service (facility) not subscribed
57	BC not authoriz.	Requested bearer capability is not enabled
63	Srv./opt.n.avail	Unspecified for "Service not available" or "Option not available"
69	Req.fac.not impl.	Requested facility is not supported
88	Incompat. Dest.	Incompatible destination
102	Timer expired	Error handling routine started due to time-out
111	Protocol error	Unspecified for "protocol error class"
127	Interworking err	Unspecified for "interworking class"

Other causes are not shown in clear text, rather as decimal codes (see "ARGUS Error Messages (DSS1)" on page 149).

Testing Features via the Keypad

This feature is only relevant on an S-Bus or U interface. Some network operators do not support the standard DSS1 features, rather they expect the user to control the network via so-called keypad command sequences. In these cases, the desired facility is usually activated by entering a series of characters and then sending these characters within a DSS1-specific protocol element. These so-called keypad elements are imbedded in a setup message. Each step is acknowledged either acoustically (handset) or via special protocol elements (cause). These causes are displayed by the ARGUS.




3.11 Time Measurement

The ARGUS measures three different times:

- Connection setup time
- The propagation delay of the data
- The difference between the propagation delays for the data on two B channels.

Connection setup time

The ARGUS places an outgoing call and measures the time between sending the SETUP and receiving the ALERT or CONN. The ARGUS disconnects automatically as soon as the measurement is completed.



ARGUS Main Menu

The speed-dialling memory opens (see page 141). Use the cursor keys to scroll to desired the number or reenter the number on the keypad.

Enter the B channel on the keypad

Perform measurement


Display:

- Connection setup time in seconds
- L3 message received when the connection has been fully setup

If the ARGUS cannot perform the measurement - e.g. because the call number entered was wrong or no B channel is free - the cause will be displayed.

B channel delay

The ARGUS places a call to itself (self call) or to a remote loopbox and measures the propagation delay for the data in the selected B channel. The measurement (continuous measurement) must be terminated manually.



ARGUS Main Menu

The speed-dialling memory opens (see page 141). Use the cursor keys to scroll to desired the number or reenter the number on the keypad.

Enter the B channel on the keypad

Perform measurement

Display

avg: average B channel delay
min: shortest B channel delay
max: longest B channel delay
bit: The average B channel delay in bits (multiples of the time required to send a bit at 64 kbit/s, it takes 15.26 μ s to send a bit).

The measurement will be repeated in cycles (continuous measurement).



Stop measurement, the ARGUS will display the last measurement.

If the measurement cannot be performed (e.g. because the call number entered was wrong or no B channel is free) the ARGUS will display the corresponding cause. If the ARGUS does not receive the data back in the B channel within 13 seconds, it will display the message "No loop".

Interchannel delay

The ARGUS establishes two separate connections to a remote loopbox. The loopbox sends the respective B channel data back on the same channel. The ARGUS measures the propagation delay for the data on each of the B channels and determines the difference between the two propagation delays (interchannel delay). The measurement (continuous measurement) must be terminated manually.

Single tests

ARGUS Main Menu

Time measurement

Interchannel delay

Enter remote number

The speed-dialling memory opens (see page 141).

Use the cursor keys to scroll to desired the number or enter a new number.

Select service

Perform measurement

```

Interchan.delay
avg:    0.13 ms
min:    0.13 ms
max:    0.13 ms
bit:    8
BRI
  
```

avg: average interchannel delay

min: shortest interchannel delay

max: longest interchannel delay

bit: The average interchannel delay in bits (multiples of the time required to send a bit at 64 kbit/s, it takes 15.26 µsto send a bit).

The measurement will be repeated in cycles (continuous measurement).



Stop measurement. The ARGUS will display the last measurement.

If the measurement cannot be performed (e.g. because the call number entered was wrong or no B channel is free) the ARGUS will display the corresponding cause. If the ARGUS does not receive the data back in the B channel within 13 seconds, it will display the message "No loop".

3.12 Managing Multiple Tests on an ISDN Access

The ARGUS can simultaneously start several tests or “connections” independently of each other. As an example, a BERT can be run at the same time that you make a phone call. The individual tests or “connections” use resources.

All of the tests that have been started will be administered by the Test Manager. Using the Test Manager, you can start new tests, switch between tests running in parallel or terminate all of the tests that are currently running.



ARGUS - Main Menu

Open the Test Manager

<TM>
or
 Opens the Test Manager directly in the Single Tests Menu if a connection has already been setup or if the ARGUS is running a test.

Starting Several Tests to Run Simultaneously

Starting a new test or connection during an existing connection

Connection		
B01 Speech		
from:02351919640		
to :		
CR value:	4	
length/flag:	1/1	
BRI		
	TM	Volume

Example:

There is a connection on B channel 1.

Start new one

Single tests

Bit error rate test

BERT active		
2^11	B01	
synchronous		
Sync.time:	00:00:17	
LOS:	0	
Error:	0	
BRI		
Reset	TM	Error

Open the Test Manager (can also be opened by pressing the -key).

Select the desired test (e.g. bit error rate test, BERT).

Start BERT, the connection is still setup.

For information on running a BERT, see page 24.


Open the Test Manager, mark "Outgoing connection".

Outgoing call

Open the Connection display.

3 Operation on an ISDN Access

An example of the display



If a test (or connection) is canceled (or cleared), the ARGUS will return to the Test Manager if there is another test (or connection) running in the background.



Some tests use so many resources that they cannot be run in every combination with other tests. In this case, the ARGUS will display the message "Test not possible at this time".

Test / Connection	Number of times that a test or connection can be started at the same time:	It is possible to change to another test:
Incoming call	2	Yes
Outgoing call	2	Yes
BERT	2	Yes
Loop	2	Yes
Service check	1	No
Suppl.serv.test	1	No
Time measurement	1	No
X.31 test	1	No
CF Interrogation / Active / Delete	1	No
Automatic test	1	No

Switching between Parallel Tests or Connections

This operation will be illustrated using the example of "Accepting an incoming call during a BERT". The ARGUS signals an incoming call both audibly and on the display (see page 54). The incoming call can be accepted without influencing the currently running BERT. If either the "B channel loop" or the "BERT wait" function is active, the call will be accepted automatically.

Incom.call		
B01 Speech		
from:02351919640		
to :		
CR value:	4	
length/flag:	1/1	
BRI		
Reject		Accept

While running a BERT, the ARGUS displays information about an incoming call.

<Reject> Reject the incoming call.
The ARGUS will switch to the BERT.

Accept call
The BERT will continue in the background.

Connection		
B01 Speech		
from:02351919640		
to :		
CR value:	4	
length/flag:	1/1	
BRI		
	TM	Volume

Mark "BERT outgoing".

Switch to BERT.

BERT outgoing		
↓		
BERT active		

The connection remains active in the background, the handset is assigned to the connection.



The handset will be assigned to the appropriate currently active connection. The assignment of the handset to a given connection is also retained in the background.

End All Currently Running Tests or Connections


Test Manager

ARGUS - Main Menu.



Open the Test Manager

<TM> Opens the Test Manager directly in
or the Single Tests Menu if a
connection has already been setup
or if the ARGUS is running a test.




All tests will be terminated and
all connections cleared down.

3.13 The L1 State of an S-Bus Access

The ARGUS displays the current status of Layer 1: i. e. which signal does the remote end receive and which signal does the ARGUS receive?

L1 State

ARGUS - Main Menu



L1 status

TE: info 3
NT: info 4

BRI

New

The ARGUS displays the state of Layer 1 or of the signal, which is currently being sent (Info 0 to Info 4).

- <New> Layer 1 will be setup again
-  Close the display and open the Main Menu.

3.14 Monitor

The ARGUS accepts all of the D channel signals from the S-Bus access and sends these D channel signals over the USB interface to a PC which must be running ARGUS WINplus or WINanalyse. The Bus and Layer 1 are not influenced by the monitoring.

The Monitor settings are made in the chapter 2 Configuring accesses page 7.

Status display

Monitoring is not yet active!



Start monitoring

Monitoring

Durat.: 0:00:04
Signals: 45

BRI Monitor

Listen

The ARGUS displays the recording time in h:min:sec and the number of recorded signals.



Stop monitoring.



Listening-in on voice data

B channel select



Enter the second B channel from the keypad (first press **<Delete>**) or use the cursor keys to select it. The ARGUS will switch the handset to this B channel.

Continuation on next page

Monitoring		
Durat.:	0:00:20	
Signals:	170	
BRI Monitor		
	Mute	

Listening-in on voice data
(Direction: Net --> User) possible.

<Mute> To stop listening

<Talk> Parallel call display while monitoring

The ARGUS searches all of the D channel signals sent for a SETUP. If a SETUP is detected, the <Call> softkey will be displayed.

The ARGUS displays the call parameters of the last SETUP received.

Display:


- Call direction (N -> U for Net -> User)
- B channel used
- Service
- Own number (from:)
- Destination number (to:)

Depending on the type of access additional information will be displayed.

- Sub-address (SUB)
- User-User-Info (UUI)
- DSP messages
- Type of number (TON)
- Numberin Plan (NP)

Display call parameters

Listening-in when monitoring is not active



Monitoring is not active!

It is possible to passively listen-in on the network-side, the terminal-side or both sides.

Enter the B channel from the keypad (first press <Delete>) or use the cursor keys to set it.



Stop listening-in and open the Main Menu.


3.15 Leased Lines on an ISDN Access

Besides dial-up connections to any subscriber, ISDN also supports the use of permanent circuits switched to a specific remote location (leased lines). These leased lines (permanent circuits) are available after setting up Layer 1, in other words after synchronizing both terminals by exchanging HDLC-frames. The location where the clock is generated can be selected (see page 19). A quick and simple test of a leased line can be made by placing or taking a call on a selected B channel. However, for a more precise test, a bit error rate test should be run.



Both ends of the leased line (permanent circuit) must use the same channel.

Telephony



Disconnect

The Leased line settings are made in the chapter 2 Configuring accesses page 7.

<Setting> ISDN parameter configuration, see page 18.

Enter the B channel from the keypad (first press <Delete>) or use the cursor keys to set it.

The ARGUS will display the B channel used and the duration of the leased line (in h:min:sec).

<Volume> Set the volume


<TM> Start the Test Manager, see page 67.
Another connection can be setup.

Alternatively, the connection can be setup via Connection in the Single Tests Menu.


Bit Error Rate Test

There are a number of variants of the bit error rate test: In the simplest case, a B channel loop will be set up at the remote end; for information on parameter settings, see page 23. After selection of the channel to be tested (B channel or D channel), the ARGUS will send the test pattern, receive it back and evaluate it accordingly.

The displays and operation are, in largest part, similar to those of a BERT on a dial-up connection (see page 22, Parameter settings, page 24), however, you need not enter call numbers or select a service.



In the case of a BRI in end-to-end mode (see page 23 and page 30), it is also possible to run a BERT in the D channel with HDLC framing (channel selection: D channel).



First press <Delete> and enter the B channel on the keypad, or use the cursor keys to set it.

BERT Start

During the BERT, the display shows:

- The bit pattern and channel used
- The synchronicity of the bit pattern (in this example, synchron)
- Sync. Time in h:min:s
The time in which the ARGUS can sync to the bit pattern.
- LOS
Synchronization is lost at an error rate greater than or equal to 20 % within a period of a second. The absolute number of synchronization losses will be shown.
- Fault: the bit errors that have occurred.

<Reset> The test time and number of bit errors will be reset.

<TM> Start Test Manager, see page 66.

<Error> Insert artificial bit errors to test the reliability of the BERT.



Stop the BERT
Display the test results.

For information on saving the test results, see page 29.

Loopbox

The ARGUS can be used as a loopbox on a permanent circuit (leased line).

Single tests



Bit Error Rate Test



B channel loop



B channel select



Activate loopbox

ARGUS - Main Menu

Channel selection:

The ARGUS will loop on either one B channel (Channel selection: B channel) or on all B channels and the D channel (Channel selection: All framed).

The ARGUS will display the B channel used and how long the loopbox has been activated (in h:min:sec).




Deactivate the loopbox.

Time Measurement

B channel delay

The ARGUS will measure the delay on the selected B channel. If the ARGUS does not receive the data back in the B channel in about 13 seconds, it will display the message "No loop". The measurement (continuous measurement) must be terminated manually.



ARGUS - Main Menu

First press **<Delete>** and enter the B channel on the keypad, or use the cursor keys to set it.

Perform measurement

Display:

avg: average B channel delay

min: shortest B channel delay

max: longest B channel delay

bit: The average B channel delay in bits (multiples of the time required to send a bit at 64 kbit/s, it takes 15.26 μ s to send a bit).

The measurement will be repeated in cycles (continuous measurement).




Stop measurement, the ARGUS will display the last measurement.

Interchannel delay

The ARGUS will send the B channel data to a loopbox which will then send it back on the same channel. The ARGUS measures the propagation delay for the data on each of the B channels and determines the difference between the two propagation delays (interchannel delay). If the ARGUS does not receive the data back in the B channel in about 13 seconds, it will display the message "No loop".

The measurement (continuous measurement) must be terminated manually.



ARGUS - Main Menu

Perform measurement

Display:

avg: average interchannel delay

min: shortest interchannel delay

max: longest interchannel delay

bit: The average interchannel delay in bits (multiples of the time required to send a bit at 64 kbit/s, it takes 15.26 μ s to send a bit).

The measurement will be repeated in cycles (continuous measurement).




Stop measurement, the ARGUS will display the last measurement.

3.16 Level Measuring on an ISDN Access

Level Measurement on a S-Bus Access

Level measurement – connected line

The ARGUS measures the level of the received useful signal and the phantom feed. The measurement will be updated continuously.



Stop measuring level.
Open the Level measuring menu.

ARGUS - Main Menu

Start measurement

The ARGUS will display the level of the useful signal (Level) and the feed voltage.

Evaluation of the useful signal level:

- << Level is too low
- >> Level is too high
- OK Level is alright
(0.75 V ^{+20%} _{-33%} i.e. from 0.9 V to 0.5 V)

None No level

Evaluation of the feed voltage:

voltage OK Normal feed
Normal voltage (40 V ^{+4,25%} _{-13,75%} i.e. from 41.7 V to 34.5 V)

Voltage OK The (inverted phantom) feed is alright (OK).
Feed voltage

Voltage No feed (Voltage)
None

<R>On> 100 Ω resistor switched in

<R>Off< 100 Ω resistor switched off

<New> Setup Layer 1 again

Level measurement other TE

In TE mode, the ARGUS will measure the level of a terminal connected in parallel. In this case, the ARGUS is passive. Layer 1 must be activated on the terminal. The ARGUS updates its measurement continuously.

Level measurement



Other TE



Level measurement		
Level	1.10 V	
>>		
Other TE		
BRI		
	R>On	



Stop measuring level.
Open the Level measurement menu.

ARGUS - Main Menu

Start measurement

The ARGUS displays the level and an evaluation of the useful signal:

- << Level is too low
- >> Level is too high
- OK Level is in order
(0.75 V ^{+20%} _{-33%} i.e. from 0.9 V to 0.5 V)
- None No level

- <R>On> 100 Ω resistor switched in
- <R>Off> 100 Ω resistor switched off
- <New> Setup Layer 1 again

Level Measurement on a U interface

Measurement of feed voltage on a U interface

Level measurement

ARGUS - Main Menu



U interface feed voltage

Start measurement



Level measuring results

The ARGUS will display the level of the feed voltage. The measurement will be updated continuously.



Stop measuring level.
Open the Level measuring menu.


4 Connection for a PRI network

Since there is no commonly accepted standard for the connections in the 2 Mbit sector, you will be confronted with different forms of connectors depending on the type of terminal and the network termination used.

The ARGUS changes the connector pin assignments automatically in accordance with the mode, TE or NT. Additionally, it is also possible to change the pin assignments manually in the L1-Status menu.

4.1 Pin Assignment on the ARGUS (BRI/PRI/E1)

In TE mode, the ARGUS sends on lines 4 and 5, in NT-Mode on 1 and 2 (see illustration). An adapter cable, which is suitable for the PRI network/system to be tested, can be connected using the RJ45-RJ45 adapter.




PIN	PIN	Function	
		NT	TE
1	1	Tx	Rx
8	2	Tx	Rx
2	4	Rx	Tx
7	5	Rx	Tx

5 Operation on a PRI Access

5.1 Configuring the PRI Interface and Access Mode Settings


Use the included connection cable to connect the ARGUS "BRI/PRI/EI" jack to the access to be tested and then switch the ARGUS on. The PRI settings are made in chapter 2 Configuring accesses page 7. In this example the PRI TE mode was selected.

ARGUS State display



- <Start> Start the B-channel test
- <config> Open the "PRI Setting" menu.
-  Open L1 state
- <X> Switch the pin assignment (will not be displayed until the Level key is pressed)

Main menu



The menus, which are available for the type of access under test, are listed in the main menu.

-  The ARGUS will open the marked menu (in this example, Single tests).
-  Select a menu. The selected menu will be marked blue in the display.
-  To return to the previous menu (in the example, the State display).

5.1.1 TE Simulation of a Primary Rate Interface

In the Access mode menu (see page 86), select the desired simulation mode:

- **TE P-P (point-to-point)**

Afterwards, the access and the protocol stack will be initialized in accordance with the selected setting.

5.1.2 NT Simulation of a Primary Rate Interface

In the Access mode menu (see page 86), select the desired simulation mode:

- **NT P-P (point-to-point)**

Afterwards, the access and the protocol stack will be initialized in accordance with the selected setting.


5.2 Initialization Phase including B-Channel Test

Initialization on a PRI network

As soon as Layer 1 is setup, the "L1 Sync" LED will light continuously. The ARGUS will automatically determine and display, whether or not the PRI access uses CRC4-monitoring. CRC4 monitoring can be switched on or off manually.

The ARGUS will begin to automatically determine the access configuration. After Layer 2 is setup, the "L2" LED will also light.


The ARGUS will, regardless of the mode of operation (TE or NT mode), determine the D-channel protocol and attempt to setup Layer 3.



During this phase, the ARGUS displays the A bit of the remote side and the FAS. The protocol can only be determined when the A bit is not set (+). The FAS (Frame Alignment Signal) indicates whether the ARGUS could correctly synchronize with the incoming 2 Mbit data stream's alternating frame identification word or message word and the, perhaps present, CRC4-superframe structure.

Press the <start> softkey to have the ARGUS begin to test the availability of all 30 B-channels one after the other by occupying the B-channels. If the ARGUS can place a call on a B-channel, it will be assumed that the B-channel is available in both directions; the B-channel test cannot distinguish between alternating and exclusively "outgoing" B-channels. If the connection is rejected, the B-channel will be identified as unavailable. In the case of a cause, which indicates that the B-channel is occupied, the connection will be tried up to two times and, if a connection can still not be setup, it will then be marked as unavailable.

**Example:
The status display on a PRI access**




The ARGUS will display the following:

- Type of access
- Access Mode
- Bus configuration
- D-channel protocol

- The availability of the B-channels
Available B-channels: green circle
is indicated by three rows
of red or green circles.

B-channel 1 is at the upper left
B-channel 30 is at the lower right
In the example, all 30 B-channels are available and can be used for outgoing or alternating connections.
- CRC4-monitoring, A-Bit, FAS

B-channel test – example:



The ARGUS is in TE-Simulation Slave mode.

B-channel 2 and 23 are not available or are busy. This state is indicated in the display by the red circles. Green circles are used to indicate the available B-channels.

If the ARGUS is not properly connected (e.g. incorrect cabling) or the network is not in order, the ARGUS will display "No Net".

5.3 Configuring the PRI Parameters

The following PRI parameters can be configured as needed. The procedure for configuring a parameter will be illustrated with a single example: It is possible to restore the default settings for the parameters (see the ARGUS main Manual).

Configuration



Protocol



● **Automatic**



The ARGUS will use the marked setting as the default and return to the next higher menu.

The ARGUS - Main menu

Use the cursor keys to select, e.g. Protocol.



Mark the desired protocol. The selected protocol will be marked in blue (in this example, Automatic). The default protocol will be marked in the display by a ●. The ARGUS will use the default protocol for the PRI connection.



Open the next higher menu without making any changes. The ARGUS will continue to use the default setting.

Setting	Explanation
Protocol	<p>Instead of allowing the ARGUS to automatically determine the protocol (setting: Automatic), it is also possible to manually set the Layer-3 D-channel protocol. The ARGUS will save the protocol setting permanently, i.e. it will use this protocol the next time that it is switched on.</p> <p>Default setting: Automatic</p>
Alerting mode	<p>You can specify whether, for an incoming call on a PRI point-to-point access, the ARGUS should display only the access number without extension or the complete number with extension. If it is set to "Manual", the ARGUS will display the extension (an incoming call will be signaled. The ARGUS will send the Layer 3 message "Alert" when it accepts the call. The digits of the extension that have been sent by this point will be displayed.).</p> <p> With the Manual setting, an incoming call must be answered within 20 seconds or it will be lost. Furthermore, you should note that the remote subscriber will not hear a ringing tone.</p> <p>If it is set to "Automatically", the ARGUS will only display the access number without extension or, depending on the configuration of the access in the exchange, it may not display the number called at all.</p> <p>Default setting: Automatic</p>
Clock mode	<p>This parameter sets where the clock will be generated in the case of a BRI or PRI access. You can either specify that the ARGUS generates the clock (is Master) or that it is the slave of a clock generated at the other end (Slave).</p> <p>Default setting:</p> <p>NT mode Master TE mode Slave Leased line Slave</p> <p>This setting will not be saved permanently, rather only applies for the current measurement.</p>

<p>PRI termination</p>	<p>Depending on the transmission technique (75 Ohm coaxial-cable or twisted-pair cable with an impedance of 120 Ohms) used, the PRI termination resistor must be selected accordingly.</p> <p>The default setting is country-specific and corresponds to the system most common in the respective country: Germany, Austria, England, the Netherlands, France: 120 Ohm</p> <p>Spain, Italy, Greece: 75 Ohm</p>												
<p>PRI haul mode</p>	<p>The ARGUS can set the sensitivity on a PRI access.</p> <p>By default, "short haul" will be suggested.</p> <p>short haul: Normal sensitivity, i.e. signal reception with cable attenuation of up to ca. -10 dB.</p> <p>long haul: Increased sensitivity, i.e. signal reception with cable attenuation of up to ca. -35 dB. This corresponds to a distance of 1600 m with 22 AWG twisted pair cable.</p> <p>When using greater sensitivity ("long haul" mode) on longer lines, feedback on the line can cause faulty synchronisation.</p>												
<p>Sa5 bits</p>	<p>The ARGUS can set the Sa5 bits on a PRI access. By default, the Sa5 bits are set to 0000.</p> <p> The Sa5 bits have no significance between an NTPM and a PBX system.</p> <p>This setting will not be saved permanently, rather only applies for the current measurement.</p> <table data-bbox="359 1145 947 1246"> <thead> <tr> <th>Sa5 coding</th> <th>Meaning</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0000</td> <td>Network -> Terminal</td> <td>Terminal -> Network</td> </tr> <tr> <td>1111</td> <td>Direction code</td> <td>Ack. for loop command</td> </tr> <tr> <td></td> <td>-----</td> <td>Direction code</td> </tr> </tbody> </table>	Sa5 coding	Meaning	Meaning	0000	Network -> Terminal	Terminal -> Network	1111	Direction code	Ack. for loop command		-----	Direction code
Sa5 coding	Meaning	Meaning											
0000	Network -> Terminal	Terminal -> Network											
1111	Direction code	Ack. for loop command											
	-----	Direction code											

<p>Sa6 bits</p>	<p>The ARGUS can set the Sa6 bits on a PRI access. By default, they are set to 0000. This setting will not be saved permanently</p> <table border="0"> <thead> <tr> <th data-bbox="353 264 460 284">Sa6 coding</th> <th data-bbox="482 264 561 284">Meaning</th> <th data-bbox="745 264 818 284">Meaning</th> </tr> </thead> <tbody> <tr> <td data-bbox="353 320 398 339">0000</td> <td data-bbox="482 320 650 395">Network -> Terminal Setting for normal operation (default)</td> <td data-bbox="745 320 913 395">Terminal -> Network Setting for normal operation, idle (default)</td> </tr> <tr> <td data-bbox="353 400 398 419">1010</td> <td data-bbox="482 427 706 662">Switches a loop in the NTPM. In the permanent circuit mode, a BERT can then be performed using the loop setup there. Important: The ARGUS must be set to "Leased line" even if it is a dialup access!</td> <td data-bbox="745 427 891 443">-----</td> </tr> <tr> <td data-bbox="353 775 398 794">1111</td> <td data-bbox="482 695 706 930">Switches a loop in the LEPM. In the permanent circuit mode, a BERT can then be performed using the loop setup there. Important: The ARGUS must be set to "Leased line" even if it is a dialup access.</td> <td data-bbox="745 802 981 850">AIS on U₂ (incoming side) of the NTPM</td> </tr> </tbody> </table>	Sa6 coding	Meaning	Meaning	0000	Network -> Terminal Setting for normal operation (default)	Terminal -> Network Setting for normal operation, idle (default)	1010	Switches a loop in the NTPM. In the permanent circuit mode, a BERT can then be performed using the loop setup there. Important: The ARGUS must be set to "Leased line" even if it is a dialup access!	-----	1111	Switches a loop in the LEPM. In the permanent circuit mode, a BERT can then be performed using the loop setup there. Important: The ARGUS must be set to "Leased line" even if it is a dialup access.	AIS on U ₂ (incoming side) of the NTPM
Sa6 coding	Meaning	Meaning											
0000	Network -> Terminal Setting for normal operation (default)	Terminal -> Network Setting for normal operation, idle (default)											
1010	Switches a loop in the NTPM. In the permanent circuit mode, a BERT can then be performed using the loop setup there. Important: The ARGUS must be set to "Leased line" even if it is a dialup access!	-----											
1111	Switches a loop in the LEPM. In the permanent circuit mode, a BERT can then be performed using the loop setup there. Important: The ARGUS must be set to "Leased line" even if it is a dialup access.	AIS on U ₂ (incoming side) of the NTPM											
<p>A bit</p>	<p>Using the ARGUS, you can set the A bit on a PRI access. By default, it is preset to A=0 (automatic). This setting will not be saved permanently</p>												
<p>CRC4 mode</p>	<p>CRC4 monitoring can be switched on or off manually. By default, it is preset to CRC4. This setting will not be saved permanently</p>												

<p>Call parameters</p>	<p>Two different parameters can be set for calls generated (on a PRI access) on both the network-side (ARGUS in NT mode) and on the user-side (ARGUS in TE mode):</p> <p>1. Type of number (TON) for the CGN (=CGPN) or CDN (=CDPN) element of a SETUP signal</p> <p>Network-side: Net CGN TON / Net CDN TON</p> <p>Default setting: Automatic</p> <p>2. Numbering Plan (NP) for the CGN (=CGPN) or CDN (=CDPN) element of a SETUP signal</p> <p>Network-side: Net-CGN-NP/ Net-CDN-NP</p> <p>User-side: User CGN NP / User CDN NP</p> <p>3. CGN/CDN Subaddress CGN/CDN Subaddress type: User specific and NSAP Default setting: User specific</p> <p>4. UUI (User User Info)</p>
<p>Services</p>	<p>Up to three user-specific services (user spec.1 to user spec.3) can be entered and saved. The three Info elements, BC, HLC and LLC (switch using the left softkey) must be entered for each user specific service in hexadecimal using the keypad and softkeys <A ... F> (e.g. to enter a C press the softkey three times, to enter an F press it six times).</p>
<p>Call acceptance</p>	<p>If the ARGUS is set to "own MSN/DDI" and is in TE mode on a P-P access, it will only signal those calls which are placed to the DDI of the access under test.</p> <p>If set to "all MSN/DDI", the ARGUS signals all calls.</p> <p>The prerequisite for this is (This setting will be saved permanently): The own call number must be entered in speed-dialing memory under "own number" (see the ARGUS main Manual)</p> <p>Default setting: all MSN/DDI.</p>
<p>Voice coding</p>	<p>Two codes are available for coding voice data in a B-channel (this setting will be reset to the default when the ARGUS is switched off): μ-law and a-law (default setting)</p>

5.4 Bit error rate Test

The bit error rate test (BERT = Bit Error Rate Test) is used to check the transmission quality of the access circuit.

As a rule, the network operator will guarantee an average error rate of 1×10^{-7} , in other words in long-term operation 1 bit error in 10 million transmitted bits. A higher bit error rate will be especially noticeable in transmitting data.

The application program detects the errors in the data blocks transmitted and requests that the remote partner send them again, which reduces the effective throughput of the PRI connection.

In the bit error rate test, the tester establishes a PRI connection to a remote tester (end-to-end) or calls itself (self call), sends a standardized (quasi-) random number string and compares the received data with that which was sent. The individual bit errors are summed and depending on the test procedure and equipment evaluated in accordance with the ITU Guideline G.821.

During the test, the ARGUS counts the bit errors and after the test is done it calculates the bit error rate and other parameters in accordance with the ITU-T G.821 standard.

As a rule, the quality of the network operator's access circuits is quite good. Therefore, no bit errors should occur in a one-minute test. However, if an error occurs, the test should be repeated with a measurement time of 15 minutes to achieve higher statistical precision. The access circuit is heavily distorted, if more than 10 bit errors occur within a test period of 15 minutes.

Contact the network operator or the supplier of the PBX equipment and ask them to test your access circuit.



In the case of an NGN (Next Generation Network), where a packet-switched network segment may follow a circuit switched one, please explicitly select "UDI 64k" as the service for the BERT. Then the ARGUS will, in accord with RFC 4040, switch to clear mode, deactivate the echo canceler and not use a codec.

The BERT can be performed in three different ways:

1. BERT in an extended self call

A remote number is not needed, since the ARGUS sets up the PRI connection to itself. In this case, the ARGUS requires two B-channels for the test.


2. BERT with a loopbox

A loopbox (e.g. another member of the ARGUS family of testers at the remote end) is required. The test uses one B-channel.

3. BERT end-to-end

This test requires a waiting remote tester (e.g. a second ARGUS in the "BERT wait" mode). (see page 102 BERT wait) A bit pattern is sent to this remote tester. Independent of the received bit pattern, the remote tester uses the same algorithm to generate the bit-pattern that it sends back. Therefore, both directions are tested independently.

5.4.1 Setting the BERT Parameters



The ARGUS - Main menu

The procedure for configuring a parameter will be illustrated with a single example: The default settings for the parameters can be restored at any time (see the ARGUS main Manual).

The ARGUS sets the value entered as the default BERT time and returns to the next higher menu.

Setting	Explanation
BERT time	<p>You can use the keypad to enter measurement times ranging from 1 minute to 99 hours and 59 minutes (= 99:59).</p> <p> If the time is set to 00:00 (=BERT with unlimited measurement time), the BERT will not stop automatically. In this case, the BERT must be terminated manually by pressing the .</p> <p>Default setting: 1 minute</p>
Bit pattern PRI	<p>This function is used to select the bit pattern to be sent cyclically by the ARGUS to perform a BERT on a PRI access (see "Bit patt. BRI/U").</p> <p>($2^{15}-1$= default setting).</p>
Error level	<p>This is the level used to evaluate whether the BERT had an "acceptable" bit error rate.</p> <p>If the BERT has a bit error rate, which exceeds this error level, the ARGUS will display a "NO" as the test result.</p> <p>Using the keypad, this parameter can be set to any value from 01 (= 10^{-01}) to 99 (= 10^{-99}).</p> <p>The default threshold (error level) is 10^{-06} (1E-06). That means that, in the event that the bit error rate is less than 10^{-06} (one error in $10^6 = 1,000,000$ sent bits), the bit error rate test will be evaluated as OK.</p>
HRX value	<p>Setting the HRX value (Hypothetical Reference Connections, see the ITU-T G.821)</p> <p>Using the keypad, you can enter a value ranging from 0 to 100%.</p> <p>Default setting: 15 %</p>

5.4.2 BERT start

Single Tests



BERT



BERT start



Enter the phone number



Select service



Select a B-channel



```

BERT active
2^15          B30
synchronous
Sync.time:    00:00:08
LOS:          0
Error:        0
  
```

PRI	Reset	TM	Error
-----	-------	----	-------

The ARGUS - Main menu

The ARGUS opens the speed-dialing memory (see the ARGUS main Manual). Enter/dial your own number to perform the BERT in an extended call to oneself (two B-channels). Enter/dial a remote number for a BERT to a loopbox (one B-channel) or end-to-end.

<↓> Scroll through the speed-dialing
<↑> memory.

Using the cursor keys, select the service which should be used for the BERT.

Enter the B-channel on the keypad (first press <Delete>). If you enter an *, the ARGUS will choose any B-channel that is free.

BERT start

After the connection has been setup and synchronized in both the send and receive directions, the ARGUS will display:


- the bit pattern and B-channel / bit rate used
- Synchronicity of the bit pattern (in the example, synchron)
- Sync.time in h:min:sec (The time in which the ARGUS can sync to the bit pattern)
- LOS-counter: shows the absolute number of synchronisation losses. synchronisation is lost at an error rate greater than or equal to 20 % within a period of a second.
- The number of bit errors that have occurred

<Error>	The ARGUS will generate an artificial bit error, which can be used to test the reliability of the measurement (in particular for end-to-end tests).
<TM>	Opens the Test Manager, see page 136
0-Key or <Reset>	Restarts the BERT. The test time and number of bit errors will be reset.
	Stop the BERT

When a bit error is detected the ARGUS will sound a brief alarm. When synchronisation has been lost, the ARGUS will sound a constant alarm (see the ARGUS main Manual), if one has been configured earlier.


After the BERT is over, the ARGUS will display the cause and the location which initiated the disconnect. If the test ran normally, the ARGUS will display "Active clearing" on this line.

BERT results:



To scroll through the results


- The evaluation of the results depends on the error threshold that you set (in the example, OK).
- sent data (data transferred) (K = 1024 bits, k = 1000 bits)
- sync.time in h:min:sec (The time in which the ARGUS can sync to the bit pattern)
- Nb. LOS (counter) synchronisation is lost at an error rate greater than or equal to 20 % within a period of a second. The absolute number (Nb.) of synchronisation losses will be shown.
- LOS time: Duration of the BERT minus the sync. time (The time in which the ARGUS could not sync to the bit pattern after it had been in sync at least once)
- abs. err.: The number of bit errors
- rel. err: Bit error rate (e.g. 9.7E-07 = $9.7 \cdot 10^{-7} = 0.00000097$)



Display of other characteristic values (in accordance with ITU-T G.821)

All values are given in percentages and absolute values.

The ARGUS evaluates whether the test results satisfy the limits specified in the G.821 under consideration of the reference connection (HRX). (The display will show either OK or NO).



To scroll through the results



Return to the previous display

Characteristic values (in accordance with ITU-T G.821)

- HRX** Defines the hypothetical reference connection
- EFS** Error Free Seconds:
The number of seconds in which no error occurred.
- ES** Errored Seconds:
The number of seconds in which one or more errors occurred.
- SES** Severely Errored Seconds:
The number of seconds in which the bit error rate is greater than 10^{-3} .
In one second, 64,000 bits are transferred, thus BitErrorRate (BER) = 10^{-3} equates to 64 bit errors.
- US** Unavailable Seconds:
The number of all sequentially adjacent seconds (at least 10 sec) in which $BER > 10^{-3}$.
- AS** Available Seconds:
The number of all sequentially adjacent seconds (at least 10 sec) in which $BER < 10^{-3}$.
- DM** Degraded Minutes:
The number of minutes in which the bit error rate is greater than or equal to 10^{-6} .
In one minute, 3,840,000 bits are transferred, thus a BER = 10^{-6} corresponds to 3.84 bit errors (3 errors = NO (no degraded minutes), 4 errors = OK (Degraded Minutes)).
- LOS** Loss of Synchronise:
synchronisation is lost at an error rate greater than or equal to 20 % within a period of a second.
The absolute number of synchronisation losses will be shown.

5.4.3 BERT saving

The ARGUS can store the results of several BERTs. The ARGUS saves the results together with the date, time and call number of the access under test (if this number has been entered as the "own" number in the speed-dialing memory, see the ARGUS main Manual) in the next free memory location. If all of the memory locations are used, the ARGUS will select the oldest test results to be overwritten.

BERT result	
OK	
sent data:	12440kb
sync.time:	00:03:19
Nb. LOS :	0
LOS time :	00:00:00
abs. err.:	0
PRI	
Save	TM More

Store the result

<Yes>

Save as:
New result
10/24 signs
PRI
Last name Delete ab>Ab

Using the numeric keys, enter the name under which the ARGUS should save the results (see the ARGUS main Manual). By default, the ARGUS will use the call number last used as the record name.

Save BERT results

BERT start

5.4.4 BERT wait

In "BERT wait" mode, the ARGUS will wait for the BERT at the remote end which is necessary for an end-to-end test:

Single Tests

The ARGUS - Main menu



BERT



BERT wait

Activate "BERT wait"



BERT active

2^15	B01
synchronous	
Sync.time:	00:00:14
LOS:	0
Error:	0

PRI

Reset	TM	Error
-------	----	-------

The ARGUS first waits for a call and then sets up the connection. During the connection, the received bit pattern will be evaluated and an additional independent bit pattern will be sent.

<TM> Opens the Test Manager (page 136)

For information on the displays shown, see "BERT start" on page 97.



Display BERT results

5.4.5 B-channel loop

“B-channel loop” mode is required in order to run a bit error rate test using a loopbox (an ARGUS is the loopbox) at the remote end.

Single Tests



BERT



B-channel loop



The ARGUS - Main menu

Activate a “B-channel loop”
The ARGUS will wait for a call. Any incoming call (regardless of the service) will be taken immediately. The ARGUS will switch a loop back in the B-channel that is specified by the exchange and then send (loop) the received bit pattern back to the caller/sender.

<Menu> Open the Main menu: the “B-channel loop” remains active. A second B-channel loop connection can be started from this menu or from the **<TM>**. From the **<TM>** (see page 136) the ARGUS will return to the “B-channel loop wait active” display.

<TM> Opens the Test Manager (page 136)



Exit “B-channel loop” mode

Display shown after taking a call:


- B-channel used and service
- The caller’s number (from:)
- The number dialed (to:)
- If available: TON, NP, UUI etc.

<TM> Opens the Test Manager (page 136)

<Menu> Open the Main menu.



Clear down the B-channel loop connection, the B-channel loop, however, remains active!



5.5 Supplementary Services Test

The ARGUS checks whether the access under test supports supplementary services.

5.5.1 Supplementary Services on DSS1

Single Tests



Supplementary Services



Enter own number




Select service



Select a B-channel



Select test case



The ARGUS - Main menu

The speed-dialing memory will open (see the ARGUS main Manual).

< ↓ > Scroll through to your own call number (the number of the access under test) or enter it using the keypad.

The ARGUS will test the availability of the supplementary service (in part by placing a call to itself).

Using the cursor keys, select the service which should be used for the supplementary services test.

Enter the B-channel on the keypad. The ARGUS selects the B-channel used last. If you enter an "*", the ARGUS will choose any B-channel that is free.

Select the supplementary service, which the ARGUS should determine whether it is supported by this access.

Start test

Display the test results:

+ = suppl. service supported
- = suppl. service not supported



To scroll through the results



Close the results display.
Open the next higher menu.

5.5.2 Error Messages

If an error occurs during the Supplementary Services Tests or if it is not possible to setup a call, the ARGUS will display the corresponding error code (e.g. 28).

Example: The error code 28 equates to "wrong or invalid number" (see the ARGUS main Manual).

5.6 Service Tests

The ARGUS checks, which of the following services are supported by the access under test:

Service	Name displayed on the ARGUS
Language	Language
Unrestricted Digital Information (data telecommunications)	UDI 64kbit
Audio 3.1 kHz	3.1kHz audio
Audio 7 kHz	7 kHz audio
Unrestricted Digital Information with Tones & Announcements	UDI-TA
Telephony	Telephony PRI
Telefax Groups 2/3	Fax G3
Fax Group 4	Fax G4
Combined text and facsimile communication	Mixed Mode
Teletex Service basis mode	Teletex
International interworking for Videotex	Videotex
Telex	Telex
OSI application according to X.200	OSI
7 kHz Telephony	Telephony 7kHz
Video telephony, first connection	Video telephony 1
Video telephony, second connection	Video telephony 2
Three user-specific services	User-specified 1 to 3

(see the ARGUS main Manual)

5.7 X.31 Test

The ARGUS will perform a “Manual X.31 Test” or, if desired, an “Automatic X.31 Test”: In the case of an automatic test, the ARGUS will first setup the D-channel connection and then an X.31 connection. The ARGUS will then automatically clear the connection and display the results.

In the case of a manual test, the ARGUS will setup a D-channel connection and an X.31 connection. The duration of this connection is determined by the user (or the remote end). For the duration of the connection, the ARGUS will repeatedly send a predefined data packet. The ARGUS will count all of the data packets sent and received and will display (where possible) the contents of the data packets received.

5.7.1 Setting the X.31 Parameters

Configuration

The ARGUS - Main menu



X.31 profile



● **X.31 profile 1**

The ARGUS stores the parameters for the X.31 in the three X.31 profiles.



Mark a profile for editing. The selected profile will be marked blue in the display. The default profile will be marked in the display with a ●. The ARGUS will use the parameters in the current profile for the X.31 test.



<Edit>



The ARGUS takes over the marked profile as the default and returns to the Settings menu.

TEI



Enter a TEI



It is possible to restore the default settings for the parameters (see the ARGUS main Manual).

The ARGUS saves the TEI entered and returns to the next higher menu.

Setting	Explanation
X.31 profile:	
Packet number	Number of packets sent Default setting: 10
TEI	Entry (from the keypad) of the TEIs (Terminal Endpoint Identifier) to be used in the X.31 test. If you enter **, the ARGUS will automatically select a TEI. Minimum 0 to a maximum of 63
LCN	Use the keypad to enter the LCN (Logical Channel Number) to use in the X.31 test. Default setting: 1
Packet size	The size of the data packets Default setting: 128 Bytes
Agree Packet size	Negotiate with the network side (DCE) regarding the data packet size. If the desired data packet size is larger than the default, this parameter should be set to "yes". Default setting: No
Window size	Window size of Layer 3 Default setting: 2 Packets
Negotiate window size	Negotiate between the terminal (DTE) and the network (DCE) an agreement regarding the window size. Default setting: No
Throughput	Data throughput in bits/sec Default setting: 1200 bit/s
Agree Throughput	Throughput agreed Default setting: No

<p>User data Content of the user data: Format setting of the user data:</p>	
<p>ASCII data</p> <p>↓ </p> <p>● ASCII data 1/3</p> <p>↓ <Edit></p> <p>Enter ASCII data</p> <p>↓ </p> <p>Save ASCII</p>	
<p><12>ab <ab>AB</p> <p><AB>12</p> <p></p> <p><Delete></p> <p></p>	<p>- Entry of the ASCII data</p> <p>Use the cursor keys to select one of the three available memory locations for the ASCII data (in this example, the first location 1/3)</p> <p>Use the numeric keypad to enter the ASCII data. When the right softkey is pressed it assumes a different meaning and thus influences the entries made from the keypad:</p> <p>Entry of the digits 0 to 9 plus * and #</p> <p>Entry of the lowercase characters and @, /, -, and . (e.g. to enter a "c" press the "2" on the keypad three times)</p> <p>Entry of the uppercase characters and @, /, - and .</p> <p>Move the cursor</p> <p>Delete the character before the cursor</p> <p>Do not save ASCII data.</p>
<p>Hex data</p> <p>↓ </p> <p>● Hex data 1/3</p> <p>↓ <Edit></p> <p>Enter hexadecimal data</p> <p>↓ </p> <p>Save</p>	
<p><Delete></p> <p></p>	<p>Entry of the hexadecimal data:</p> <p>Select one of the three available memory locations for the hexadecimal data (in this example, the first location 1/3)</p> <p>Use the keypad to enter the hex value. To enter the values A...F, use the softkey <A...F> (e.g. to enter a C, press the softkey <A...F > three times). To confirm the entry, press <OK> (the softkey in the middle changes from <Delete> to <OK>).</p> <p>Delete the character before the cursor</p> <p>Do not save the hexadecimal values.</p>
<p>D bit</p>	<p>Local: DCE acknowledges data packets, i.e. flow control on local DTE-DCE path</p> <p>End-to-end: DTE-DTE flow control</p> <p>Default setting: Local</p>

Facilities	Coding for various supplementary services A maximum of 3 facilities can be stored.
Profile name	Use the keypad to enter the profile name for the X.31 profile. The ARGUS will later display this name for the profile.

5.7.2 Automatic X.31 Test

D-Channel

The “X.31 Automatic, D-channel” test consists of two steps:

- 1. **Step:** The ARGUS tests whether it is possible to access the X.25 service via the D-channel on the ISDN access under test. The ARGUS checks all of the TEIs from 0 to 63 one after the other. All the TEIs, which support X.31service on Layer 2, will be displayed.
- 2. **Step:** For each TEI with which X.31 is possible on Layer 2, a CALL_REQ packet will be sent and then the ARGUS will wait for an answer. Beforehand, the ARGUS will request the entry of the X.25 access number, which will be saved in speed-dialing memory under X.31 test number. With the entry of the X.25 access number, you can – if you wish – select a logical channel (LCN) other than the default.

Single Tests

The ARGUS - Main menu



X.31 Test



● X.31 profile 1

Select the profile
<Edit> Change to the profile parameters
The parameters can be edited.



Automatic



D-Channel



X.31-Test

current TEI:
09

previous TEI:
08 NOK

PRI

Start test

The start up procedure can take up to 4 minute. The ARGUS will display the currently tested TEI, the previously tested TEI and the results:

OK = X.31 is available for this TEI
NOK = X.31 is not available for this TEI

Test results

```

X.31 Test
TEI      : 02
Layer 2  : +
Layer 3  : - 512
PRI

```

The ARGUS will check whether the X.31 service is available for Layer 3 for the TEIs found in Step 1.

Example: Test results

TEI 02 The first valid TEI is 02.

Layer 2 + 1. Test step was successful
 - 1. Test step was not successful

Layer 3 + 2. Test step was successful
 - 2. Test step was not successful


In this case, the ARGUS will display the relevant X.31 cause for the failure (in the example above: 512) and the associated diagnostic code if there is one.

If the X.31 service is not supported, the ARGUS will report "X.31 (D) n. impl."

5.7.3 Manual X.31 Test

D-Channel

The ARGUS first requests a TEI, an LCN and an X.31 number (The ARGUS uses the values stored in the X.31 profile.). If an "*" is entered for the TEI, the ARGUS will automatically determine a TEI. Using the first TEI with which X.31 is possible, the ARGUS will setup a connection.



The ARGUS – Main menu

Select a profile.

<Edit> Change to the profile parameters
The parameters can be edited.

The ARGUS displays the TEI stored in the X.31 profile. It can be edited from the keypad. If you enter „**“, the ARGUS will automatically select a TEI.

<Delete> Delete the TEI

The ARGUS displays the stored LCN. It is possible to edit the LCN from the keypad.

The ARGUS displays the X.31 number saved in the speed-dialing memory. It can be edited from the keypad.

Setup a X.31 connection.

Continuation on
next page

X.31 (D) test		
X.31 (D) Connection		
LCN:	1	TEI: 2
an: 026240510049922		
PS DCE [Byte]:		
Tx:	128	Rx: 128
WS DCE:		
Tx:	2	Rx: 2
PRI		
	Statistic	Data



Save X.31 (D) test?

The ARGUS will display the LCN, the TEI, the X.31 number and the negotiated connection parameters.

- <Data> Sends a predefined data packet
- <Stat.> Press STAT. to display the L1/L2/L3 statistics.
- <L2> To scroll to the L2 statistics
- <L3> To scroll to the L3 statistics

The X.31 connection will be maintained until the user or the remote end clears it. When the X.31 connection is cleared, the ARGUS will automatically clear the D-channel connection.

- <Yes> The ARGUS saves the results.

5.8 Connection display

The ARGUS can setup a connection for the following services:

Service	Display
Language	Language
Unrestricted Digital Information (data telecommunications)	UDI 64kBit
Audio 3.1 kHz	3.1 kHz audio
Audio 7 kHz	7 kHz audio
Unrestricted Digital Information with Tones & Announcements	UDI-TA
Telephony	Telephony PRI
Telefax Groups 2/3	Fax G3
Fax Group 4	Fax G4
Combined text and facsimile communication	Mixed Mode
Teletex Service basis mode	Teletex
International interworking for Videotex	Videotex
Telex	Telex
OSI application according to X.200	OSI
7 kHz Telephony	Tele. 7 kHz
Video telephony, first connection	Video telephony 1
Video telephony, second connection	Video telephony 2
Three user-specific services	User-specified 1 to 3


(see the ARGUS main Manual)

A headset or the integrated handset can be used as a phone during a telephone connection.

When a connection is set up, pressing the number keys (0-9) or the * or # will generate and send the corresponding DTMF tones.

Overlap sending (outgoing call)

In overlap sending, the digits entered for the call number are sent individually.



The ARGUS - Main menu

- The ARGUS will open the Connection display
Where Overlap sending (such as links) as well as
 - En-block sending (see below)
 - Redialing (see below)
 - Keypad dialing
 are available.

Select the service to be used for the connection.

Enter the B-channel on the keypad. The ARGUS selects the B-channel used last. To enter a new B-channel, first press **<Delete>**. If you enter an *, the ARGUS will choose any B-channel that is free. The ARGUS will show whether the B-channel is available.

Setup the connection
Enter the number on the keypad.
Display:


- B-channel and service
- The number that is stored in the speed-dialing memory under "Own number", see the ARGUS main Manual (from:)
- The number dialed (to:)
- Other information depending on the access, e.g. TON and NP

<TM> Starts the Test Manager (page 136)

<VoLume> Setting the volume

or Cancel setup






The connection is setup using B-channel 1.



Depending on the type of access other information will be displayed.

- Subaddress of the caller (SUB)
- Destination number
- User-User Information (UUI)
- Display Information
- Type of number (TON)
- Numbering Plan (NP)
- Units for charges



Disconnect

<VoLume> Setting the volume

<TM> Starts the Test Manager (see page 136)

Displaying Advice of Charges (AOC)

If the charges are not given in units, rather directly as currency, the ARGUS will display the current charges in currency. If, in DSS1, the call charges are not provided in accordance with the DIN ETS 300182 standard, rather in the form of the information element DISPLAY (DSP), the ARGUS will display the DISPLAY message's character string.



Note regarding the entry of the own call number

Separate the extension from the access number with a # (e.g. 02351 / 9070-40 is entered on the ARGUS as: 023519070 #40). For an outgoing call, the ARGUS uses the entire call number (without #) as the number called (CDPN or DAD) and, for the calling number, only the extension (DSS1-CGPN or 1TR6-OAD). A '#' at the beginning of a call number is treated as a valid character. A '#' at the end of the own call number instructs the ARGUS to not send the caller's number for outgoing calls (CGPN or OAD).



Simplified overlap signaling using the telephone key



depressed:

The ARGUS will open the Connection/Overlap window directly regardless of the currently open menu.



depressed again:

A dial tone will be heard and once the call number is entered, the call will be setup.

En-bloc sending (outgoing call)

In en-bloc sending, the ARGUS sends the entire dialing information in one block.

Single Tests

The ARGUS - Main menu



Connection display



En-bloc sending



Enter the phone number

The ARGUS opens the speed-dialing memory (see the ARGUS main Manual). Use the cursor keys to scroll to desired the number or reenter the number on the keypad.



Select service



The ARGUS will open the Connection display. For more information see overlap sending which is similar.



B-channel select



Enter the B-channel on the keypad (for details on entry, see "Overlap sending").

Connection

```

B01 Telephony ISDN
from:919650
to : 919650
TON:Unknown
NP :unknown
AOC:
Units                1
    
```

PRI

	TM	VoLume
--	----	--------

Start the dialing procedure

For more information on the displays and operation, see overlap sending.



Cancel setup

- <Volume> Setting the volume
- <TM> Starts the Test Manager (page 136)

Redial (outgoing call)

The ARGUS will set up a call using the last number dialed.

The ARGUS – Main menu

Single Tests



Connection display



Redial



Select service




B-channel select



```

Connection
B01 Telephony ISDN
from:919650
to : 919650
TON:Unknown
NP :unknown
AOC:
Units                1
PRI
    
```

	TM	VoLume
--	----	--------



Cancel setup

Enter the B-channel on the keypad. The ARGUS suggests the B-channel used last. To enter a new B-channel, first press **<Delete>**. If you enter an *, the ARGUS will choose any B-channel that is free. The ARGUS will show whether the B-channel is available.

The dialing procedure will begin using the number which was dialed last.

For more information on the displays and operation, see overlap sending.

<Volume> Setting the volume

<TM> Starts the Test Manager
(see page 136)

Incoming Call

An incoming call can be taken at any time even when a test (e.g. a BERT) is in process (see page 137). The ARGUS will signal an incoming call with an audible tone and a message on the display. The function Accept call (see the ARGUS main Manual) can be configured so that, on a P-P access, the ARGUS will only signal incoming calls that are placed to its own call number. This function can only be used when the own call number has been entered into the speed-dialing memory (see the ARGUS main Manual) and the incoming call has a call number.

Incom.call	
B01 Telephony ISDN	
from:	66
to :	11
TON:	Unknown
NP :	unknown
CR value:	16
length/flag:	1/1
PRI	
Reject	Accept

Display:

- B-channel used and service
- The caller's number (from:)
- Destination number (to:)
- Other information depending on the access, e.g. TON and NP

The ARGUS will display the complete destination number (DDI), if the Alerting mode is set to manual (see the ARGUS main Manual).

Reject call

To take the call.

Connection	
B01 Telephony ISDN	
from:	66
to :	11
TON:	Unknown
NP :	unknown
CR value:	16
length/flag:	1/1
PRI	
TM	Volume

Depending on the access, additional information will be displayed (in this example, TON and NP).

<Volume> Setting the volume

<TM> Starts the Test Manager (see page 136)


Disconnect  or 

The ARGUS displays the cause of the disconnect (see page 120).


Charge information in NT mode:

In NT mode, the ARGUS will – for incoming calls – send advice of charges in accordance with DSS1 as units and as currency (in euros).

5.9 Clear down (disconnect) the connection



<VoLume> Setting the volume
 <TM> Starts the Test Manager (see page 136)



The ARGUS will display the cause (see the table below) of the disconnect (e.g. Normal clearing) and the location where the cause occurred (e.g. subscriber). Depending on the access, additional information will be displayed (in this example, Units).

The following causes are shown in clear text:

Reason	Display	Explanation
255	Active clearing	Clearing User actively initiated the disconnection
Length 0	Normal disconnect	Cause element with length 0
01	unalloc. number	No access under this call number
16	Normal disconnect	Normal disconnect
17	User busy	The number called is busy
18	No user respond	No answer from the number called
19	Call time too long	Call time too long
21	Call reject	The call is actively rejected

28	Wrong number	Wrong call number format or call number is incomplete
31	Normal disconnect	Unspecified "normal class" (Dummy)
34	No B-chan.avail.	No circuit / B-channel available
44	Req.chan.unavail	Requested B-channel not available
50	Req.fac.not subs	Requested supplementary service (facility) not subscribed
57	BC not authoriz.	Requested bearer capability is not enabled
63	Srv./opt.n.avail	Unspecified for "Service not available" or "Option not available"
69	Req.fac.not impl.	Requested facility is not supported
88	Incompat. Destination	Incompatible destination
102	Timer expired	Error handling routine started due to time-out
111	Protocol error	Unspecified for "protocol error class"
127	Interworking err	Unspecified for "interworking class"

Other causes will not be displayed in plain text but will instead be shown as decimal numbers (see "CAUSE Messages - DSS1 Protocol" on page 16).

5.10 Connection setup time

The ARGUS places an outgoing call and measures the time between sending the SETUP and receiving the ALERT or CONN. The ARGUS disconnects automatically as soon as the measurement is completed.

Single Tests



Time measuring



Conn. up time




Dial the number



Select service



B-channel select



The ARGUS – Main menu

The ARGUS opens the speed-dialing memory (see the ARGUS main Manual). Use the cursor keys to scroll to desired the number or reenter the number on the keypad.

Enter the B-channel on the keypad.

Perform measurement

Display:

- Connection setup time in seconds
- L3 message received when the connection has been fully setup


If the ARGUS cannot perform the measurement - e.g. because the call number entered was wrong or no B-channel is free - the cause (see the ARGUS main Manual) will be displayed.

5.11 The L1 Status of a PRI Access

The ARGUS displays the Layer 1 alarms and messages, which provide detailed information regarding the state of the PRI access and the transmission line (For further information, see the CCITT/ITU guidelines G.703 and G.704).

The ARGUS - Main menu

L1 state



The ARGUS displays the time that has elapsed since the ARGUS was initially started or it was last reset in minutes and seconds (00:19).

The measurement time and all Layer 1 alarms and messages are updated continuously.

Use the cursor keys to scroll

- <x>** The PRI relay for the Rx/Tx pin assignment will be toggled to its other position, regardless of the state that it was in before. This function is only available in the L1 status menu if there is currently no signal. The state of the relay will remain unchanged when you close the L1 status menu.
 - wires = means that Rx/Tx are normal
 - wires X means that Rx/Tx are inverted
- <RESET>** Reset the History function and all counters.
- <SAVE>** Save results (see the ARGUS main Manual)

OK symbol: +

Error symbol: -

History symbol: ! This indicates that, regardless of the current state of the access (+ or -), an error occurred during the test period.

The meaning of the individual displays:

Signal	The ARGUS has received the correct send signal from the remote end (access or terminal depending on whether operating in TE-Simulation or NT-Simulation mode) and indicates this by displaying a +. If the Rx and Tx are on the usual wires, a "=" will be shown after wires; if they are swapped, an "x" will be shown instead.
FAS	Frame Alignment Signal Indicates whether the ARGUS could correctly synchronize with the incoming 2 Mbit data stream's alternating frame identification word or message word and the, perhaps present, CRC4-superframe structure.
CRC4 det	If CRC4-monitoring is active for the access or the terminal and the ARGUS is able to synchronize itself to the CRC4 superframe, it will indicate this by displaying "CRC det +". If "CRC det -" is displayed together with "Signal +" and "FAS +", this indicates that no CRC4 is active. To prevent power up effects (transients), we recommend that you set the display and counter to a defined initial state with a <Reset>.
Code HDB3	Display the transmission code used (currently set to HDB3)
noA-Bit	The remote end uses the A-Bit to signal whether the circuit is available on their receive side. noA-Bit + means A = 0: Idle state noA-Bit - means A = 1: Return direction is not available
noAIS	Alarm Indication Signal) AIS will be set if a component on the transmission line determines that the signal they have received is faulty (e.g., in the event, that they lose frame synchronisation) and has sent a Time -1 (= AIS) to indicate this. "noAIS = +:" no AIS occurred.
Sa5-Bit (Rx,Tx)	The "Sa5-Bit (Rx)" sent by the ARGUS can be configured in the Configuration menu (See "Sa5 bits" on page 91)
Sa6-Bit (Rx,Tx)	The "Sa6-Bit (Rx)" sent by the ARGUS can be configured in the Configuration menu (See "Sa6 bits" on page 92)
E-Bit	With the two E-Bits, E1 and E2, the remote end will report any CRC4-errors that it finds on its receive side in the first or second.submultiframe (the E-Bit will be set to 0). "E-Bit11+:" if both E-Bits are set to 1, no error occurred "E-Bit11+!:" A CRC4-error was found (indicated by the "!"), however the circuit is in largest part OK (see the E-Bit counter Ecnt or the CRC4 error counter CRCErr)

Ecnt	The E-Bit counter counts the individual E-Bit error messages; i.e. all cases where a faulty CRC4 submultiframe was received (counts at a maximum of 1 kHz)
CRC Err	The CRC4 error counter totals the number of CRC4 submultiframes in which errors were detected.
CRC rel	Shows the CRC4 error rate, in other words, the number of faulty CRC4 frames relative to the total number of CRC4 frames received.
Code Err	Counter for the detected HDB3 transmission code errors
Code rel	Transmission code error rate
Frm. Err	Counter for faulty 2Mbit frames.

When running a MegaBERT unframed in leased line mode, if the menu L1 status is opened (via the -Key or the Test Manager), the display will only show the parameters Signal and noAIS.

5.12 Monitor

The ARGUS accepts all of the D-channel signals from the S-Bus access and sends these D-channel signals over the USB interface to a PC which must be running ARGUS WINplus or WINanalyse. The bus and Layer 1 are not influenced by the monitoring.

Status display

Monitoring is not yet active!



Start monitoring

Monitoring

Durat. 0:00:26
Signals: 3

PRI

Listen

The ARGUS displays the recording time (duration) in h:min:sec and the number of recorded signals.



Stop monitoring.


Listening-in on voice data

B-channel select

Enter the B-channel from the keypad (first press <Delete>) or use the cursor keys to set the B-channel. The ARGUS will switch the handset to this B-channel.



Continuation on next page



Can listen-in on voice data (direction: Network -----> User).

<Quiet> To stop listening

<Call> Parallel call display while monitoring

The ARGUS searches all of the D-channel signals sent for a SETUP. If a SETUP is detected, the <talk> softkey will be displayed.

The ARGUS displays the call parameters of the last SETUP received.

As soon as a change occurs, the ARGUS will send a time-stamped report of the following alarms/states to the PC, which will evaluate them:


- Signal
- FAS
- CRC4det
- A bit
- AIS

The ARGUS will check the following values and counters every second and, in the event of a change, will pass them on the PC:


- Sa5-Bit (Rx)
- Sa6-Bit (Rx)
- E-Bit
- Ecnt
- CRC Err.
- Cod.Err.
- Fram.Err.

Display of the L1 Status in PRI Monitor mode

The L1 status function is only available in PRI Monitor mode. The Layer 1 alarms and messages are presented in several windows and allow detailed assessments of the state of the PRI access and the transmission line (For further information, see the CCITT/ITU guidelines G.703 and G.704).



The ARGUS in the PRI Monitor Mode Monitoring is not active.



Display of the "NT-side parameters"
Use the cursor keys to scroll through the display

<TE> Switch to "L1 status TE"; the "TE-side parameters" will be displayed

<Reset> Reset the History function

 Quit.
The ARGUS will open the Main menu.


5.13 Leased line on a PRI access

Besides dial-up connections to any subscriber, PRI also supports the use of permanent circuits switched to a specific remote location (leased lines). These leased lines (permanent circuits) are available after setting up Layer 1, in other words after synchronizing both terminals by exchanging HDLC-frames. The location where the clock is generated can be selected. A quick test of a leased line can be made by placing or taking a call on a selected B-channel. However, for a more precise test, a bit error rate test should be run.



Both ends of the permanent circuit (leased line) must use the same channel.

5.13.1 Telephony



<Config> Configuring the PRI parameters

B-channel select

Enter the B-channel from the keypad (first press <Delete>) or use the cursor keys to set the B-channel.

Setup the telephone connection.

The ARGUS will display the B-channel used and the duration of the leased line (in h:min:sec).

Disconnect

Continuation on next page

<Volume> Set the volume

<TM> Start the Test Manager (see page 137).
Another connection can be setup.

Alternatively, the connection can be setup via Connection in the Single tests menu.

5.13.2 Bit error rate Test

There are a number of variants of the bit error rate test: In the simplest case, a B-channel loop will be set up at the remote end. Parameter settings (see page 95).

After selection of the channel to be tested (B-channel or D-channel), the ARGUS will send the test pattern, receive it back and evaluate it accordingly.

The displays and operation are, in largest part, similar to those of a BERT on a dial-up connection, you simply need not enter call numbers or select a service.

Single Tests



BERT



BERT start



B-channel (64k)

Continuation on
next page



In the case of a PRI access in end-to-end mode (see page 129), a BERT can be run:

- in the D-channel
- in a B-channel
(Select channel: B-channel (64k))
- in two B-channels
(Select channel: B-channel (128k))
- MegaBERT framed
(optional: in all B-channels and in the D-channel)
- MegaBERT unframed
(optional: all B-channels, the D-channel and time slot 0).

B-channel select**BERT active**

```

2^15          B10+B11
synchron
Sync.time:   00:00:13
LOS:                0
Error:           1

```

PRI

Reset	TM	Error
-------	----	-------

Enter the B-channel from the keypad (first press **<Delete>**) or use the cursor keys to set the B-channel.

Start BERT (128k-BERT)

During the BERT, the display shows:

- The bit pattern and channel / bit rate used
- Synchronicity of the bit pattern (in the example, synchron)
- Sync.time in h:min:sec
The time in which the ARGUS can sync to the bit pattern
- LOS
synchronisation is lost at an error rate greater than or equal to 20 % within a period of a second. The absolute number of synchronisation losses will be shown.
- Error: The bit errors that have occurred.

<Error> Insert artificial bit errors to test the reliability of the BERT.

<Reset> The test time and number of bit errors will be reset.

<TM> Open the Test Manager (see the ARGUS main Manual)




Stop the BERT
Display the test results (see the ARGUS main Manual).

Saving Test Reports
(see the ARGUS main Manual)

5.13.3 Configuration: BERT

The operation is the same for all configurations and will be illustrated with a single example:



Settings for the BERT:

Display Name on the ARGUS	Remark
BERT time	<p>You can enter measurement times ranging from 1 minute (default setting) to 99 hours and 59 minutes (= 99:59).</p> <p> If the time is set to 00:00 (=BERT with unlimited measurement time), the BERT will not stop automatically. In this case, the user must terminate the BERT (by pressing the ).</p>
Bit pattern PRI	<p>This function is used to select the bit pattern to be sent cyclically by the ARGUS to perform a BERT on a PRI access (see "Bit patt. BRI/U").</p> <p>($2^{15}-1$= default setting).</p>

Error level	<p>This is the level used to evaluate whether the BERT had an "acceptable" bit error rate.</p> <p>If the BERT has a bit error rate, which exceeds this error level, the ARGUS will display a "NO" as the test result.</p> <p>Using the keypad, you can enter a value ranging from 01 (= 10^{-01}) to 99 (= 10^{-99}). The default threshold (error level) is 10^{-06} (1E-06). That means that, in the event that the bit error rate is less than 10^{-06} (one error in $10^6 = 1,000,000$ sent bits), the bit error rate test will be evaluated as OK.</p>
HRX value	<p>Setting the HRX value (Hypothetical Reference Connections, see the ITU-T G.821)</p> <p>Using the keypad, you can enter a value ranging from 0 to 100 %.</p>

Setting the MegaBERT bit pattern

Menu



Single Tests



BERT



BERT start



MegaBERT (framed/unfr.)



MegaBERT pattern



The various MegaBERT bit patterns that are available can be called up in "Leased line" mode as follows:

A distinction is made between two types of MegaBERT in the channel selection:

- MegaBERT framed (31 B-channels)
- MegaBERT unframed (32 B-channels)

The ARGUS will save the setting and start the single test.

Menu for selecting the bit pattern to be used for a MegaBERT:

In a BERT, the ARGUS will repeatedly send the following bit pattern.

Display on the ARGUS	Remark
2¹⁵-1	32767-bit pseudo-random test sequence in accordance with ITU-T O.150 5.3 (longest sequence of zeros = 15)
2¹⁵-1 inverted	The ARGUS will send the bit pattern described above inverted.
2²⁰-1/QRSS	1048575-bit pseudo-random test sequence in accordance with ITU-T O.150 5.5 (longest sequence of zeros = 14)
2²⁰-1/QRSS inverted	The ARGUS will send the bit pattern described above inverted.
Constant NULL	The ARGUS will only send nulls (zeros).
Constant ONE	The ARGUS will only send ones.

5.13.4 Loopbox

Single Tests



BERT



B-channel loop



B-channel select



Activate loopbox

The ARGUS can be used as a loopbox on a permanent circuit (leased line).

The ARGUS - Main menu

Select channel:

The ARGUS will loop on either one B-channel (channel selection: B-channel) or all B-channels and the D-channel (channel selection: All framed).

In addition, the channel selection "All unframed" can be select: in which case the ARGUS will loop all B-channels, the D-channel and time slot 0.

The ARGUS will display the B-channel used and how long the loopbox has been activated (in h:min:sec).



Deactivate the loopbox.

5.14 Managing Multiple Tests on a PRI Access

The ARGUS can simultaneously start several tests or “connections” independently of each other. As an example, a BERT can be run at the same time that you make a phone call. The individual tests or “connections” use resources.

All of the tests that have been started will be administered by the Test Manager. Using the Test Manager, you can start new tests, switch between tests running in parallel or terminate all of the tests that are currently running.

The ARGUS – Main menu

Test Manager



Open the Test Manager



<TM> Opens the Test Manager directly or in the Single tests menu if a connection has already been setup or if the ARGUS is running a test.



5.14.1 Starting Several Tests to Run Simultaneously

Starting a new test or connection during an existing connection

Connection	
B01 Telephony ISDN	
from:	66
to :	11
TON:	Unknown
NP :	unknown
CR value:	16
length/flag:	1/1
PRI	
	TM
	Volume

Example:

There is a connection on B-channel 1.

Start new one

Single Tests

Bit error rate test

BERT active	
2^15	B01
synchronous	
Sync.time:	00:00:14
LOS:	0
Error:	0
PRI	
Reset	TM
	Error

Outgoing call

Open the
Connection display.

Open the Test Manager (can also be opened by pressing the "6" on the keypad).


Select desired test
(e.g. bit error rate test, BERT)

Start BERT, the connection is not yet setup.

For information on running a BERT, see page 97

Open the Test Manager.
Mark "Outgoing connection"

An example of the display



If a test (or connection) is canceled or cleared, the ARGUS will return to the Test Manager if there is another test (or connection) running in the background.




Some tests use so many resources that they cannot be run in every combination with other tests. In this case, the ARGUS will display the message "Test not possible at this time".

Test/ Connection display.	Number of times that a test or connection can be started at the same time	Switching to another test is possible
Incoming call	30	Yes
Outgoing call	30	Yes
BERT	2	Yes
Loop	2	Yes
Service tests	1	No
Suppl.serv.test	1	No
Time measurement	1	No
CF Interrogation / Active / Clear	1	No

5.14.2 Switching between Parallel Tests or Connections

This operation will be illustrated using the example of "Accepting an incoming call during a BERT".


The ARGUS signals an incoming call both audibly and on the display (see page 114). The incoming call can be accepted without influencing the currently running BERT. If either the "B-channel loop" or the "BERT wait" function is active, the call will be accepted automatically.




BERT is running.

While running a BERT, the ARGUS displays information about an incoming call.

<Reject> Reject the incoming call. The ARGUS will open the BERT display.



Accept the call. The BERT will continue in the background.



Mark "BERT outgoing".

Switch to BERT.




The connection remains active in the background, the handset is assigned to the connection.



The handset will be assigned to the currently active connection. The assignment of the handset to a given connection is also retained in the background.

5.14.3 End All Currently Running Tests or Connections

The ARGUS - Main menu



Open the Test Manager

- <TM> Opens the Test Manager directly
- or
-  Opens the Test Manager in the Single tests menu if a connection has already been setup or if the ARGUS is running a test.

5.15 Saving numbers in the speed dial memory

You can save ten 24-digit numbers in the speed dial memory.



The own number of the test access must be entered in the first speed dial slot (display shows own number); this is important in particular for the automatic services test on ISDN accesses). In the speed dial menu, you can jump to the end of the list by moving up one slot from the top entry.

You can store remote numbers in the slots "Remote numbers 1 to 8". In the slot "X.31 test number", ARGUS expects the X.25 access number for the X.31 test (see page 248).

Settings



Numbers



Entering a number



ARGUS saves the number and switches to the next higher level menu.

ARGUS in Main Menu



Scroll down to the desired speed dial slot. Enter the number using the keypad.

<Delete>

Deletes the space when the cursor is behind the last character, otherwise deletes the character under the cursor.



Switches to the next higher-level menu without saving the number.



When entering the own number with and extension (operating ARGUS on a PBX), note the following: The extension is separated from the number using a "#". For outgoing calls, ARGUS uses the entire number (without "#") as the destination address (CDPN resp. DAD) and the number after the "#", i.e. the extension, as the sender address (CGPN resp. OAD). A "#" at the beginning of a number is treated as a valid digit.

Example: 02351/9070-40 is entered as 023519070#40.

If the number ends with "#", later calls are made without CGPN resp. OAD. This is important for some PBXs.

6 Appendix

A) Acronyms

	Zeichen
1TR6	Signalling protocol (D-channel protocol) for national ISDN of the former German national PPT (Bundespost)
2B1Q	2 binary 1 quaternary - line code
3PTY	Three party service
4B3T	4 binary 3 ternary - a modified monitored sum 43-code (MMS43)
	A
A3k1H	Audio 3.1 kHz
A7kHz	Audio 7 kHz
A-Bit	Alarm Bit
AIS	Alarm Indication Signal
AMP	Argus measurement report
AOC	Advice of charge
AOC-D	Advice of charge Charging information during the call
AOC-E	Advice of charge Charging information at the end of the call
APL	("Anschlusspunkt Linie") Service termination point
ASCII	American Standard Code for Information Interchange.
Avg	Average
AWS	("Anrufweilerschaltung") Call forwarding (1TR6)
	B
BC	Bearer Capability
BERT	Bit Error Rate Test
BRI	Basic Rate Interface (in Germany the S ₀ interface)
	C
CCBS	Completion of calls to busy subscriber
CCNR	Call complete no response
CD	Call deflection
CDN	see also CDPN
CDPN	Called Party Number
CF	Call Forwarding
CFB	Call Forwarding Busy
CFNR	Call Forwarding No Reply
CFU	Call Forwarding Unconditional
CLIP	1. Calling Line Identification Presentation 2. Clipping

CLIR	Calling Line Identification Restriction
CNS	CLIP-no screening
CONN	CONNect Message
CR	Call reference
CRC	Cyclic Redundancy Check
CT	Call transfer
CUG	Closed User Group
CW	Call waiting
	D
DAD	Destination address (1TR6)
D-Bit	Data Bit
dB	Decibel
DCE	Data Communication Equipment
DDI	Direct Dialling In (dialling in to an extension directly)
DE	German
DFU	("Datenfernübertragung") Remote data transmission
UDI	Unrestricted Digital Information (data telecommunications)
UDI-TA	Unrestricted Digital Information with Tones & Announcements
DIN	Deutsches Institut für Normung e. V.
DISC	DISConnect message
DM	Supplementary services (Dienstmerkmal)
DSS1	Digital Subscriber Signalling System No. 1
DTE	Data Terminal Equipment
DTMF	Dual Tone Multi Frequency
DTU	Data Transmission Unit
	E
E1	Primary Rate Interface (PRI)
EAZ	("Endgeräteauswahlziffer") Local calling number (1TR6)
E-Bit	Error-Bit
Ecnt	E-Bit Counter
ECT	Explicit call transfer
E-DSS1	European Digital Subscriber Signalling System Number 1
EFS	Error Free Seconds
ES	Errored Seconds
ETSI	European Telecommunications Standards Institute
	F
FAS	Frame Alignment Signal
Fax G3	Fax Group 3
Fax G4	Fax Group 4
	G
GBG	("Geschlossene Benutzer Gruppe") Closed user group

GmbH	German Limited Liability Company
H	
HDB3	High Density Bipolar of order 3
HDLC	High-Level Data Link Control
HEX	Hexadecimal value
HLC	High Layer Compatibility
HOLD	Call hold
HRX value	Hypothetical reference connection
HTTP	Hyper-Text Transfer Protocol
HVT	("Hauptverteiler") Main distribution frame (MDF)
I	
INFO	INFORMATION Message
ISDN	Integrated Services Digital Network
ITU	International Telecommunication Union
K	
KVZ	("Kabelverzweiger") Cable branch box
L	
L1	Layer 1 in the OSI reference model
L2	Layer 2 in the OSI reference model
L3	Layer 3 in the OSI reference model
LAPD	Link access procedure for D-channels
LCN	Logical Channel Number
LED	Light-Emitting Diode
LEPM	Line End for Primary Multiplex (Rate Interface)
LLC	Low Layer Compatibility
LOS	Loss of synchronisation
LOSWS	Loss of sync word seconds
M	
m	Meter
MCID	Malicious call identification
MegaBERT	Mega Bit Error Rate Test
Modem	Modulator-demodulator
MSN	Multiple Subscriber Number
N	
NGN	Next Generation Network
NP	Numbering Plan
NOK	Not OK
NSAP	Network Service Access Point
NT	Network Termination
NTBA	Network termination for ISDN basic rate access
NTPM	Network Termination Primary Multiplex

	O
OAD	Origination address (1TR6)
OSI	Open Systems Interconnection
	P
PABX	Private automatic branch exchange
PC	Personal Computer
PESQ	Perceptual evaluation of speech quality (ITU-T P.862)
P-P	Point-to-point
P-MP	Point-to-Multipoint
PRI	Primary Rate Interface (German S _{2M} interface)
PSI	Program Specific Information
PWR	Power
	Q
QRSS	Quasi Random Signal Sequence
	R
REL	RELease message
REL ACK	RELease ACKnowledge message
REL COMPL	RELease COMPLete message
RJ	Registered jack (standardised socket)
Rx	Receive
	S
Sa	Vertical transmission channels
SES	Severely Errored Second
SIN	Service indicator (1TR6)
Spch	Speech
SUB	Subaddressing
SUSP	SUSPend message
	T
TAL	("Teilnehmeranschlussleitung") Subscriber line
TDT	Time and date table
TE	Terminal Equipment
TEI	Terminal Endpoint Identifier
Tel31	Telephony 3.1 kHz
Tel7k	Telephony 7 kHz
TM	Test Manager
TON	Type of Number
TTX	Teletext
Tx	Transmit
	U
U_{2an}	U ₂ Interface
U-interface	Basic Rate Interface (U-Interface access)

US	Unavailable Second
USB	Universal Serial Bus
UUI	User-User-Info (UUI)
UUS	User-to-user signalling
	V
ViSyB	Video Syntax Based
ViTel	Video-Telephony
	X
X.25	ITU-T X.25 Protocol Standard
X.31	ITU-T X.31 Protocol Standard
	Z
ZWR	See SRU

B) CAUSE-Messages – DSS1 Protocol

Dec.	Cause	Description
01	Unallocated (unassigned) number	No access under this call number
02	No route to specified transit network	Transit network not reachable
03	No route to destination	Wrong route or routing error
06	Channel unacceptable	B channel for the sending system not acceptable
07	Call awarded and being delivered in an established channel	Call awarded and connected in an already existing channel (e.g., X.25 virtual switched connection)
16	Normal call clearing	Normal clearing
17	User busy	The number called is busy
18	No user responding	No terminal equipment answered (Timer NT303 / NT310 time-out)
19	No answer from user (user alerted)	Call time too long
21	Call rejected	Call rejected (active)
22	Number changed	Call number has been changed
26	Non-selected user clearing	Incoming call not awarded to this terminal
27	Destination out of order	Destination / access out of order
28	Invalid number format (address incomplete)	Wrong call number format or call number incomplete
29	Facility rejected	Requested service is rejected
30	Response to status inquiry	Response to status inquiry
31	Normal, unspecified	Unspecified for "normal class" (Dummy)
34	No circuit / channel available	No circuit / B channel available
38	Network out of order	Network not operational
41	Temporary failure	Network is temporarily not operational
42	Switching equipment congestion	Switching equipment is overloaded
43	Access information discarded	Access information could not be transferred
44	Requested circuit / channel not available	Requested circuit / B channel is not available
47	Resources unavailable, unspecified	Unspecified for "resource unavailable class" (Dummy)
49	Quality of service unavailable	The requested quality of service is not available
50	Requested facility not subscribed	Requested service attribute not subscribed
57	Bearer capability not authorized	The requested bearer capability is not enabled
58	Bearer capability not presently available	The requested bearer capability is not currently available
63	Service or option not available	Unspecified for "service unspecified or option not available class" (Dummy)
65	Bearer capability not implemented	Bearer capability is not supported
66	Channel type not implemented	Channel type is not supported
69	Requested facility not implemented	Requested facility is not supported
70	Only restricted digital information bearer capability is available	Only limited bearer capability is available

79	“Service or option not implemented, service or option unspecified, option not implemented class” (Dummy)	Unspecified
81	Invalid call reference value	Invalid call reference value
82	Identified Channel does not exist	Requested channel is invalid
83	A suspended call exists, but this call identity does not	The call identity entered is the wrong one for the parked call
84	Call identity in use	The call identity is already in use
85	No call suspended	No call has been parked
86	Call having the requested call identity has been cleared	The parked call has been cleared
88	Incompatible destination	Incompatible destination
91	Invalid transit network selection	Invalid format for the transit network identifier
95	Invalid message, unspecified	Unspecified for "invalid message class" (Dummy)
96	Mandatory information element is missing	The mandatory information element is missing
97	Message type non-existent or not implemented	This type of message is in this phase not permitted, not defined or not supported
98	Message not compatible with call state or message type non-existent or not implemented	In this phase, the message is not permitted, not defined or not supported
99	Information element non-existent or not implemented	In this phase, the content of the information element is not permitted, not defined or not supported
100	Invalid information element contents	Invalid content in information element
101	Message not compatible with call state	Message not valid in this phase
102	Recovery on timer expired	Error handling routine started due to time-out
111	Protocol error, unspecified	Unspecified for "protocol error class" (Dummy)
127	Interworking, unspecified	Unspecified for "interworking class" (Dummy)

C) ARGUS Error Messages (DSS1)

ERROR Number	Cause	Description
0	Network	The network is not in a state defined for DSS1. This may, however, occur in connection with normal clearing on a PBX.
1 to 127	Network	DSS1 causes
150	ARGUS	An error occurred during the supplementary service test. Frequent cause: no response from network
152	ARGUS	The CF-Test was started with the wrong own number.
153	ARGUS	No HOLD is available, but HOLD is required to test the supplementary service (ECT, 3pty).
154	ARGUS	CLIR or COLR could not be tested, since CLIP or COLP is not available
161	ARGUS	The party called did not answer within the prescribed time (approx.10 sec)
162	ARGUS	A call was setup to a remote subscriber, instead of being setup – as was expected – to your own number.
163	ARGUS	The Auto-Test could not setup a connection and therefore the AOC-D supplementary service could not be tested.
170	ARGUS	During the Suppl.services test, a call came in without a B channel (call waiting). Therefore, it was not possible to accept the call and test.
199	ARGUS	A call number was entered.
200	ARGUS	Internal error
201	ARGUS	Network did not confirm acceptance of the call (CONN sent, no CONN_ACK received from network)
204	ARGUS	a) Layer 2 connection has been cleared down b) No response to SETUP c) Layer 2 connection could not be setup
205	ARGUS	Reestablish the Layer 2 connection
206	ARGUS	The selected B channel is already busy.
210	ARGUS	No response to the clear-down (REL sent, no REL_CMP/ REL_ACK received from network)
220	ARGUS	Remote end signaled that it is in State 0.
245	ARGUS	Keypad sent via ESC, but no response was received from network
250	ARGUS	FACility was sent, but no response was received from network

X.31 Test – Error messages

X.31 Causes

0 to 255	Network	See ISO 8208: 1987(E) Table 5- Coding of the clearing cause field in clear indication packets, page 35
257	ARGUS	No answer from network (to a CALL-REQUEST or a CLEAR-REQUEST)
258	ARGUS	Unexpected or wrong answer from network (no CALL-CONNECTED or CLEAR-INDICATION as answer to CALL-REQUEST)
259	ARGUS	The network has indicated in a DIAGNOSTIC message that the logical channel is invalid. Origin: No (=1) or a wrong LCN was set.
512	ARGUS	It was not possible to determine an internal or external cause. Origin: Layer 2 could not be setup or remote end does not support X.31
65535	ARGUS	The X.31 Layer 3 test was not performed. The error can only occur in a test log.

X.31 Diagnostic (only for a cause less than 256)

0 to 255	Network	See ISO 8208: 1987(E) Figure 14a page 121 Figure 14b page 123 et seq. And/or CCITT Recommendation X.25, Annex E
-----------------	---------	--

D) Index

Numerics

7 kHz Telephony 105

A

A-Bit 87, 92, 124

Access 85

 ISDN 14

 S-Bus 15

 U-interface 15

Access Mode 86

Access number 90, 116

Access wizard 8

Acronyms 142

Advice of Charges (AOC) 116

AIS 124

Alarm 98

a-law 93

Alerting mode 90, 119

Appendix 142

ARGUS State display 86, 88

AS 100

ASCII 108

Attendant 103

Audio 3.1 kHz 105, 114

Audio 7 kHz 105, 114

B

B-channel loop 103

B-channel Test 87

BERT 95, 133

BERT characteristic values 100

BERT HRX value 96

BERT results 99

BERT Settings 96

BERT start 97

BERT time 96, 132

BERT wait 95, 102

BERT-saving 101

Bit error rate 99, 133

Bit error rate test 94, 103, 129

Bit error rate test, error level settings 133

Bit errors 98

Bit pattern 95, 97, 102, 103, 131, 132, 134

Bit pattern PRI 96

BRI/PRI/E1 14, 86

Bus configuration 88

C

Cable attenuation 91

Call acceptance	93, 103, 119
Call Forwarding	114
Call numbers	115, 122
Call parameter	93
Caller's number	116
Causes	120
Charge information in NT mode:	119
Clear mode	94
Clear text	120
Clearing down	120
Clock generation	90, 129
Clock mode	90
Coaxial cable	91
Configuring accesses	7
Connection display	114, 115
Connection setup time	122
Constant alarm	98
Contact	5
CRC4	124, 125
CRC4 mode	92
CRC4 monitoring	87, 88, 92, 124

D

D bit	108
Data throughput	94
Data transferred	99
Date	101
D-channel protocol	88
DDI	93
Default	89, 95
Dial tone	116
Direct Dialling In (Extension)	90, 116
Display Information	116
Display of charges	116
Display of the B-channels on a PRI access	88
Displaying Advice of Charges (AOC)	116
Displays	124
Code Err	125
Code HDB3	124
Code rel	125
CRC Err	125
CRC rel	125
CRC4 det	124
E-Bit	124
Ecnt	125
FAS	124
Frm. Err	125
noA-Bit	124
noAIS	124
Sa5-Bit (Rx,Tx)	124

Sa6-Bit (Rx,Tx)	124
Signal	124
DM	100
DSS1	104
DTMF signal	114
Duration	123, 126

E

E-Bit	124
Echo canceler	94
EFS	100
En-bloc sending	115, 117
Enter own number	97, 115, 116, 119
Error Code	105
Error level	96, 133
Error Messages	104
Error rate	94, 97
Error symbol	123
ES	100

F

FAS	87, 124
Fax Group 4	105, 114
Filter	7

H

Handset	114, 126
HDB3	125
HDLC frames	129
Headset	114
Hexadecimal	93
History function	123, 128
History symbol	123
HRX	27, 99, 100
HRX value	96, 133

I

Impedance	91
Incoming Call	119
Info element	93
Insert bit errors	131
Interchannel delay	122
Introduction	5
ISDN	14
Access mode	16
Alerting mode	19
Anschluss-Modus	14
AOC	21
ARGUS State display	14
B channel delay	64
B channel loop	31
BERT characteristic values	28

BERT HRX value	24
BERT results	27
BERT Settings	24
BERT wait	30
Bit error rate test	22
Bit Error Rate Test on a Leased Line	76
BRI termination	20
Bus configuration	16
Bus status	17
Call acceptance	21
Call Forwarding	45
Call parameters	20
CAUSE Messages	149
CF Activation	48
CF Delete	49
CF Interrogation	45
Charge information in NT mode	60
CLIP No Screening	34
Clock mode	19
Connection setup time	63
CUG Index	21
D channel protocol	16
Description of the Supplemental Service	33
Display Advice of Charges (AOC)	56
DSS1	32, 147
DTMF / Keypad	21
Emergency supply	17
En-bloc sending	57
Error Messages	149
Incoming Call	59
Interchannel delay	65
Keypad	21
L1 permanent?	18
L1 state	71
Last caller	58
Leased Line	75
Leased Line Loopbox	77
Leased Line Time Measurement	78
Level and voltage evaluation	17
Level measurement	81
Line resistor	20
List of services	36
Managing multiple tests	66
Meaning of the LEDs	15
Monitor	72
NT Simulation	15
Overlap sending	55
own call number	56
Passive listening-in	74
Performing Several Tests Simultaneously	50

Prefix	21
Protocol	19
Redialling	58
Repeat B channel test	14
Select the interface	14
Service check	36
Service test results	37
Services	20
Settings	18
Setup the connection	54
Supplementary Services Test	32
Supplementary Services Tests - error messages	35
TE simulation	15
Telephony on a leased line	75
Test Manager	31, 66
Testing features using the keypad	62
The availability of the B channels	16
Time measurement	63
Type of access	16
Voice codec	21
X.31 Configuration	39
X.31 D-channel	42
X.31 Error Messages	150
X.31 Test	38
K	
Keypad dial	115
L	
L1 state	125, 128
Language	105, 114
Layer 1 alarm	123, 128
Layer 1 status	123
LCN	107
Leased line	125, 129
BERT - Configuration	132
Bit error rate test	130
Loopbox	135
Telephony	129
List of Services	105
Listening-in	126
Long haul	91
Loop	103
Loopbox	95, 97, 103
LOS	100, 131
LOS counter	97
LOS time	99
M	
Main menu	14
Managing multiple tests	123
Master	90

Measurement time	94, 96
MegaBERT	125, 130, 133
Memory location	101
Microphone	114
Mixed Mode	105, 114
Monitor	126
Multiple tests	136

N

Negotiation of the data packet size	107
Negotiation of the window size	107
Next Generation Network	94
Notice	12
NT Simulation	87
Numbering Plan	93, 116
Numbers	101, 116

O

OK symbol	123
OSI	105, 114
Overlap sending	115

P

Packet number	107
Packet size	107
Parallel Call	127
Pin assignment	85, 123
Precision	94
PRI haul mode	91
PRI Monitor	128
PRI relay	123
PRI termination	91
Protocol	90
Protocol recognition	87, 90

Q

Quit all the currently running tests.	140
--	-----

R

Receiver inset	114
Redial	115, 118
Reference connection	96, 99, 100, 133
Remote number	97
Repeat B channel test	15
RFC 4040	94
Rights	2
Ringing tone	90

S

Sa5 bits	91, 124
Sa6 bits	92, 124
Saving Call Numbers	34
S-Bus	14, 15
Self call	94, 95, 97, 104

Service tests	105
Services	93, 105
SES	100
Setting the BERT Parameters	95
Setting the PRI Parameters	89
Setup the connection	114, 115
Short haul	91
Simplified overlap sending	116
Slave	90
Speed dial memory	141
Speed-dialing memory	93, 97, 101, 104, 115, 117, 119, 122
Starting Several Tests to Run Simultaneously	137
Subaddress	93, 116
Supp.Serv.test	104, 105
Supplementary Service Test - Error Messages	104
Supplementary Services	104
Supplementary Services Test	104
Switch pin assignment	86
Switching between Parallel Tests	139
Synchronicity	131
Synchronisation loss	97, 99, 131

T

TE Simulation	87
TEI	107
Telefax Groups 2/3	105, 114
Telephone connections	114
Telephone key	116
Telephony	105, 114
Teletex	114
Telex	105, 114
Termination resistor	91
Test Manager	98, 102, 103, 115, 116, 117, 118, 119, 120, 123, 129, 131, 136
Test time	98, 131
The availability of the B-channels	88
The extension module's initialization phase	87
The number of bit errors	99
Threshold	96
Time	101
Time measuring	122
Time stamp	127
Transmission code	124
Transmission quality	94
Type of number	93, 116

U

U-interface	14, 15
Units for charges	116
Unrestricted Digital Information (data telecommunications)	105, 114
Unrestricted Digital Information with Tones & Announcements	105, 114
US	100

USB interface	126
User data	108
User-specific services	93, 105
User-to-User Information	116
UII (User User Info)	93

V

Video Telephony	105, 114
Videotex	105, 114
Voice coding	93
Volume	115, 116, 117, 118, 119, 120, 129

W

WINanalyse	126
Window size	107
WINplus	126
Wires	123

X

X.25	110
X.31	
Facilities	109
Profile name	109
Test results	111
Throughput	107
Throughput agreed	107
X.31 parameters	106
X.31 profile	106, 107
X.31 Test	106
X.31 test	
automatically	110
manual	112

Z

µ-Law	93
-------------	----