

ARGUS 44 Manual

(This manual applies for ARGUS44s beginning with
serial number 3000)

© by intec Gesellschaft für Informationstechnik mbH
D-58507 Luedenscheid, Germany, 2005

Alle Rechte, auch der Übersetzung, vorbehalten. Kein Teil des Werkes darf in irgendeiner Form (Druck, Fotokopie, Mikrofilm oder einem anderen Verfahren) ohne schriftliche Genehmigung reproduziert, vervielfältigt oder verbreitet werden.

All rights are reserved. No portion of this document may be reproduced, duplicated or distributed in any form (print, copies, microfilm or on any other media) without intec's written permission.

Version: 3.20

1	Introduction	7
2	Safety Instructions	11
3	Technical data	12
4	Operation - a brief guide	13
5	Menu Hierarchy	17
6	Start-Up	21
7	Setting the type of access	28
7.1	Operation on a U-interface access (optional)	29
8	Select the Access Mode	30
8.1	Level measurement on a BRI or U-Interface ..	30
	8.1.1 TE-Simulation mode	30
	8.1.2 NT-Simulation mode (optional)	30
	8.1.3 Permanent circuit	31
	8.1.4 Monitor	35
8.2	Operation on a POTS (analog) access	37
	8.2.1 POTS terminal	37
	8.2.2 POTS monitor	38
9	ADSL Tests	39
9.1	The ARGUS in Access Mode	41
	9.1.1 Physical test (ADSL line test)	43
	9.1.2 Ping test	50
	9.1.3 Trace Route - Test	56
	9.1.4 Download Test	61
	9.1.5 VPI/VCI scan test	67
	9.1.6 ATM OAM ping test	70
	9.1.7 OAM loop	73
	9.1.8 FTP upload test	75
	9.1.9 ATM BERT	79
9.2	The ARGUS in Modem Replacement Mode ...	82
	9.2.1 Physical test (ADSL line test)	84
	9.2.2 Bridge mode	84
	9.2.3 Router Mode	87
9.3	The ARGUS in PC Replacement Mode	90
10	Tests on an ISDN Access	93
10.1	Test the Supplementary Services	93
	10.1.1 Suppl.serv.test for the 1TR6 protocol	93
	10.1.2 Suppl.service interrogation in DSS1	94
	10.1.3 Error messages	98
10.2	Service check	99
10.3	Bit error test	103
	10.3.1 Start BERT	105

10.3.2 BERT - saving	108
10.3.3 Displaying the stored results	110
10.3.4 Bert wait	111
10.3.5 B-channel loop	112
10.4 X.31 Test	113
10.4.1 Automatic X.31-Test	113
10.4.2 Manual X.31 Test	118
10.5 CF Interrogation	121
10.6 CF - Activation	123
10.7 CF - Delete	124
10.8 MSN Interrogation (only BRI with DSS1)	125
10.9 Time measuring	126
10.9.1 Connection setup time	126
10.9.2 Time measurement: B-channel delay	128
10.9.3 Time measurement: Interchannel delay .	129
11 Connection	132
11.1 Setting up an ISDN connection	132
11.2 Clearing down an ISDN connection	139
11.3 Operation on a POTS (analog) access	141
12 Test Manager	144
12.1 Simultaneously Starting Several Tests	145
12.2 Switching Between Tests	148
12.3 Cancel All	148
13 Automatic Test	149
13.1 Automatic Start test on a BRI access	152
13.2 Display saved results	155
13.3 Sending the results of a tests to a PC	158
13.4 Deleting the results of a test	159
13.5 Sending the results of all tests to a PC	160
14 Level Measuring	161
14.1 Level measuring on a BRI access	161
14.2 Level measuring on a POTS access	163
15 The L1 status of a BRI access	164
16 Configuration	165
16.1 Trace/Remote	165
16.2 Configuring ADSL profiles	166
16.3 Configuration: ISDN	179
16.4 Configuration: BERT	184
16.5 Configuration: POTS	187
16.6 Configuration: X.31 profile	190
16.7 Configuration: ARGUS	194
16.8 Saving Call Numbers	197

16.9 Reset	199
17 Accu servicing	203
18 Testing Features with the Keypad	205
19 Appendix	207
A) ADSL Acronyms	207
B) Vendor identification numbers	208
C) CAUSE-Messages – DSS1 Protocol	211
D) CAUSE-Messages – 1TR6 Protocol	213
E) ARGUS Error Messages	215
F) Error message: ADSL connection	217
G) Error message: PPP connection	218
H) Error message: Download test	220
I) General Error Messages	224
J) ARGUS Messages - Script Errors	225
K) ARGUS Messages - Routing Rules	225

1 Introduction

The **ARGUS 44** is a compact combi-tester for ADSL, ISDN (U-interface optional) and POTS.

It can be used to measure all of the relevant up and downstream line parameters and presents a graphic display of the bit distribution, depending on the version, for both ADSL-over-Pots and ADSL-over-ISDN.

The ARGUS 44 is also a comprehensive ISDN tester complete with a D-channel monitor. When used on a 2-wire interface, it supports high-impedance monitoring with voltage measurement (with an automatic check for interference voltage).

On POTS accesses, the ARGUS 44 can also simulate a POTS terminal.

An optional IP ping function and an Ethernet interface with an Ethernet through-mode can be added to enable the ARGUS 44 to also test Internet connections. With these, the tester can exchange data packets with Internet providers to determine the transmission quality of Internet connections. The option(s) extend the testers with support for a whole range of additional test functions, which include among others a trace-route function for displaying all of the routers involved and ADSL data throughput tests for the TFTP and http protocols. A TCP/IP dump includes the IP data and thus permits the user to perform an IP protocol analysis.

If you use the ARGUS on a BRI in an ISDN system whose specifications deviate from the (DIN ETS 300 102) standard (e.g. some networked PBXs), you must take these manufacturer-specific modifications into account. In such cases, please contact the distributor of your ISDN PBX for assistance.

An overview of some important ARGUS functions:

- **ADSL Test**

Displays the connection's most important upstream/downstream parameters.

Displays the upstream/downstream ATM cell errors and - in conjunction with an Alcatel ATU-C - bit error statistics

Displays the maker of the ATU-C.

Optional: Trace route test

Optional: Download test
Optional: ATM OAM ping test
Optional: VPI/VCI scan test
Optional: Ethernet / LAN extension
Optional: OAM loop
Optional: FTP upload
Optional: ATM BERT

- **Protocol Recognition and B-Channel Test**

After you select the operation mode, the ARGUS will automatically determine the protocol used by the access under test and will then test the availability of the B-channels.

- **Telephony Function**

Can a telephone call be placed from this access to every other number and/or can this access receive a call?

- **Automatic ISDN Service Check**

Does the tested access support connections with the most important services, such as, ISDN telephone service, Group 4 - Facsimile or data transmission at 64 kbit/s etc.?

- **Bit Error Tests - BERT (evaluation in accordance with**

 - G0.821**

Performs a BERT in an extended call to itself via a loopbox or in end-to-end operation. The ARGUS will, if needed, handle the loopbox function itself.

- **Automatic Supplementary Services Test**

The ARGUS automatically tests the supplementary services made available by the exchange.

- **Leased Line Tests – tests permanent circuits with BERT and speech**

 - **Automatic detection of the MSN of the access under test**

 - **Automatic and Manual X.31 Test**

- **CF Interrogation**

The ARGUS will check, whether a call diversion has been setup on the access under test. The ARGUS can setup or clear down call diversions in the exchange.

- **D-channel monitoring on the Basic Rate Interface**

All of the D-channel signals are captured and passed to the serial interface.

When passively monitoring, the ARGUS does not affect Layer 1.

- **Layer 1 and Bus Feed Test**

Measures and evaluates the phantom feed and the levels of the ISDN send and receive signals of the NTBA or PBX.

- **Testing Features with the Keypad**

Supports manual tests in the so-called keypad mode. If the network supports this feature, the user can send a command sequence and can then test service features in a dialog.

- **POTS (analog) Functionality**

Tests CLIP and other Caller-ID services in accordance with ETS 300 659/778.

- **POTS - Line Monitoring (passive listening-in)**

- **POTS - Voltage and Polarity Measurement**

- **The Access Acceptance Report**

When the ARGUS is linked to a PC via the serial interface, it is, as an example, possible to create and print a comprehensive test report on the PC.

Should you have any further questions, please contact us:

intec Gesellschaft für Informationstechnik mbH

Rahmedestr. 90

D-58507 Luedenscheid

Germany

Tel.: +49 (0) 2351 / 9070-0

Fax: +49 (0) 2351 / 9070-70

www.argus.info

support@argus.info

2 Safety Instructions

The ARGUS may only be used with the included accessories. Usage of other accessories may lead to erroneous measurements and may even cause damage to the ARGUS and the connected installation.

The ARGUS is only to be used in accordance with the instructions in this documentation. Any other usage may result in bodily injury and destruction of the ARGUS.


- To prevent electrical shocks or damage to the ARGUS, do not connect it to lines with voltages in excess of 100 V!
- Never attempt a measurement with the case open!
- The ARGUS is not watertight. Protect the ARGUS from exposure to water!
- Before replacing the battery(see page 16 Replacing the accumulators), disconnect all the test leads and switch the ARGUS off.

Make certain that the polarity is correct when connecting the batteries!

3 Technical data

Dimensions / Weight	Inputs / Outputs
Height 229 mm	1 RJ45 for BRI, ADSL or analog (POTS)
Width 72 mm	
Depth 35 mm	1 jack for an external power supply
Weight 350 g (without accumulators and protective case)	1 RJ-11 for the serial interface
Keypad	
21 Keys	1 RJ-45 10BaseT Ethernet (optional)
LCD display	Temperature Ranges
LCD display with switchable background lighting	Ambient-temperature: 0 °C to +50 °C
4 lines with 16 characters	Operating temperature: -5 °C to +55 °C
Memory	Power Supply
EEPROM Non-volatile memory: 16 K Byte	NiMH rechargeables or 9 V, plug-in power supply
Flash program memory: 2 Mbyte	
S-RAM: 512 Kbytes	
with the optional IP test function an additional	
Flash program memory: 4 Mbyte	
SDRAM: 16 Mbyte	

4 Operation - a brief guide



Power Key:



- Switch the ARGUS ON
- To start up again after a power down
- to switch on the display backlighting
In battery mode to save power, the backlighting will switch off automatically after 5 seconds.
- To switch the ARGUS OFF
(must be pressed somewhat longer)



Confirmation key:

- Select menu or continue



Menu control:

- Open the menu list
- Scroll through lists
- Select a menu
- Select a function in an open menu



Telephony

- Pickup or hang up
- Simplified overlap signalling: press the telephone key twice.



Layer 1 measurement:

start the Layer 1 measurement
(Level/Voltage)



Number Pad:

- Entry of the digits 0...9 and of the special characters *, # (e.g. the call number or numerical entry in a function)
- Direct function call



Softkeys:


The function of the 3 softkeys varies with the situation. The current function of each softkey is shown in the highlighted fourth line of the display.

Connectors on the end:



- **9 V-**

Connection for the external power supply.
If the plug-in power supply is connected, the ARGUS will disconnect the accumulators and, when it is switched off, the ARGUS will automatically recharge the accumulators (see Page 203).
- **Line**

 Pin Assignment
3/4/5/6 **BRI**
7/8 **POTS, ADSL**

 - Connection for a BRI network
 - Connection for a POTS (analog network)
 - Connection for the ADSL network
- **10BaseT (optional Ethernet/LAN extension)**
 - Connection to the PC's network card via the X-crossed patch cable
(Access mode: **PC-ARGUS-ADSL** (modem replacement or through mode))
 - Connection to the Ethernet interface of the ADSL modem via the 1:1 patch cable
(Access mode: **ARGUS-Modem-ADSL** (PC replacement mode))
- **V.24**
 - Serial interface to connect a PC

Replacing the accumulators

The battery compartment for the three accumulators (rechargeable batteries) is located on the back of the case. Unscrew the screws to remove the cover of the case and insert the accumulators in accordance with the polarity marking.

Use only the accumulators included in the package. The current state of the charge will (if the ARGUS is not connected to the power supply) be displayed graphically.

In the LCD display, a battery symbol will begin to blink, when there is still approximately 15 minutes reserve. During this period, it is possible that there may be audible interference and in rare cases even malfunctions (see "Accu servicing" on page 203.).

Power Down


In accu/battery operation, if the ARGUS is idle for 15 minutes, it will automatically switch to the power-down mode (power-down).


The ARGUS will remain in power-down mode until the Power-Key is pressed again.

Reasonably enough, the ARGUS will **not** enter power-down mode during a test (e.g. Loopbox) or when it is in Trace mode.


As an alternative, it is possible to operate the ARGUS using the included power supply. If the ARGUS is connected to the plug-in power supply, it will automatically disconnect the accumulators and will - reasonably enough - not enter power-down mode.

5 Menu Hierarchy






Management of multiple, simultaneous and independent tests/connections



The ARGUS will automatically execute the test sequence and save the results in its internal Flash



Menu L1 Status

The ARGUS displays the current status of Layer 1 on the BRI access:

Menu Configuration

*The ARGUS can be configured to suit your special requirements.
The parameters are clearly organized in submenus (e.g. the ISDN parameters are in the ISDN submenu)
The default (factory) settings can be restored by selecting "Reset".*

Trace/Remote	page 165
ADSL profile	page 166
- Physic. line	
- Protocol	
- PPP	
- PPTP	
- Ping	
- Trace route	
- Download	
- VPI/VCI scan	
- ATM OAM ping	
- FTP upload	
- ATM BERT	
- ATM	
- LAN	
- WAN	
- Router	
- DNS Server	
- Profile name	
ISDN	page 179
- L1 permanent?	
- Protocol	
- Alerting mode	
- Clock mode	
- BRI termination	
- Call parameter	

	- Services	
	- Call accepted	
	- Voice coding	
	- DTMF / Keypad	
	- Dest. no. MSN	
BERT		page 184
	- BERT duration (time)	
	- Error level	
	- HRX value	
	- Bit pattern	
POTS		page 163
	- POTS dial	
	- POTS CLIP	
	- DTMF parameter	
	- FLASH time	
Unit:		page 194
	- Menu language	
	- LCD contrast	
	- Date / Time	
	- Baud rate	
	- Alarm	
	- Software option	
Call numbers		page 197
Reset		page 199

Menu		
Accu servicing		
	Charging	page 203
	Discharging	page 203

6 Start-Up

Using the included cable, connect the ARGUS to the access to be tested.

Power Key: Switch the ARGUS on.

```

ARGUS44 3.1 D
Setting OK?
ARGUS-ADSL
  NO      YES
  
```

The ARGUS displays the access and mode parameters which were last selected.

Displayed in the first line:

The software version number: 3.0 and country code (in the example d = Deutschland)

The state of the accumulator charge (if it is not connected to the plug-in power supply)

Displayed in the third line:

Type of access: ADSL, BRI or POTS

Operating mode: TE = TE Simulation
 NT = NT Simulation (optional)
 Perman.swit.
 Monitor
 Terminal (only on a POTS
 (analog) access)

Access modus ARGUS-ADSL
 ADSL: PC-ARGUS-ADSL (optional)
 ARGUS-MODEM-ADSL (optional)

Bus configuration: P-P = point-to-point
 P-MP= point-to-multipoint


Displayed in the fourth line:

The fourth line displays the current assignment of the three softkeys below.

The ARGUS is in largest part operated with the two ↓ ↑ - Keys, the confirmation key ✓ and the three softkeys.

On the following pages, only the softkey's meaning in the respective context is shown - enclosed in brackets < > , e.g. < NO>.


The softkeys $\langle \checkmark \rangle$ and $\langle \downarrow \rangle$ serve the same functions as the \checkmark confirmation key and the \downarrow arrow key on the ARGUS keypad.



Using the $\downarrow \uparrow$ -Keys or the $\langle \downarrow \rangle$ softkey, select the physical access corresponding to that of the access under test.

The **Access Mode** menu will open automatically (see Chap. 8 page 30).

Example - on an ADSL access:



Initializing the ARGUS:

- Operating the ARGUS on a BRI or U-Interface access (optional):

The ARGUS will first setup Layer 1. While Layer 1 is being setup, LED Sync over the display will blink. If the ARGUS cannot setup Layer 1, it will display the message "No Net".

As soon as Layer 1 is successfully setup, the Sync LED will light continuously.

When the ARGUS is operated on a U-interface access, it can take up to 2.5 minutes to activate Layer 1.

Once Layer 2 has been setup LED L2 will light.



If both modes (P-P / P-MP) are found when Layer 2 on the D-channel is checked, the mode must be selected manually (see Page 30).

If everything has been correctly detected, the ARGUS will display the access type (S0, a/b, ADSL) and access mode (TE, NT). Additionally, a qualitative assessment of the level will be displayed.

The ARGUS will automatically determine the protocol (in both TE and NT mode) or use the manually selected protocol (see on page 179 "Configuration: ISDN"). On a bilingual access, the ARGUS will use the DSS1 protocol.

LED L3 will light after the ARGUS has setup Layer 3.

At the same time the ARGUS will start the B-channel test.


The results will be displayed on the ARGUS. If an error occurs in the B-channel test (e.g. access is not plugged-in), the ARGUS will - depending on the class of error - either repeat the initialization or show an error message ((see page 215 ARGUS Error Messages)).

The ARGUS will then idle in the Status display.

Status display example:



```
ARGUS44Pi BRI
B12 Level: OK
TEs P-MP DSS1
MENU RESTART
```



```
ARGUS44Pi BRI
->Single tests
Test manager ↓
← ↓ ✓
```

The ARGUS displays the type of access (BRI), the availability of the B-channels (B12), a level evaluation (OK), the access mode (TEs), the bus configuration (P-MP) and the protocol (DSS1). If you press the <RESTART> softkey, the B-channel test will be repeated.

The ARGUS in its Main menu

The test found that it is a BRI multiple device access using the DSS1 protocol

Shown on the second line in the display:

The availability of the B-channels:

B12 both channels are available
B1- only B-channel 1 is available
B-2- only B-channel 2 is available
B-- no B-channel available



If only one B-channel is available, this can have an impact on the service check and the testing of the supplementary services.

Level evaluation on a BRI:

OK the level is in order
<< the level is too low
>> the level is too high
-- no level

Shown on the third line in the display:

Access Mode:

TEs = TE Simulation Slave Mode (see Page 181)

TEm = TE Simulation Master Mode

NTs = NT Simulation Slave Mode (optional)

NTm = NT Simulation Master Mode (optional)

Shown for the bus configuration (D-channel Layer 2 mode):

P-P = point-to-point


P-MP = point-to-multipoint

It must be mentioned again, that the ARGUS only determines the general bus status once when switched on or when the ARGUS first connected.

On the other hand, the status of the protocol stacks for Layer 1, 2 and 3 will be continually monitored and displayed.

- Operating the ARGUS on a POTS access

The following will be displayed:


**- Operating the ARGUS on an ADSL access**

ARGUS - Main menu**Status display**

```

ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START


```

Main Menu

In the Main menu, you can scroll through the available menus with the <↓> key:

BRI access (U-interface optional)	POTS access	ADSL access
Single Tests	Single Tests	Single Tests
Test Manager	Automat.Tests	Automat.Tests
Automat.Tests	Level Measuring	Level Measuring
Level Measuring	Configuration	Configuration
L1 Status	Access	Access
Configuration	Accu servicing	Accu servicing
Access		
Accu servicing		

With the <✓>, you can open the menu currently marked with the → (in the example Single Tests).



Using the numeric keys to start a function:

Using the digit keys, you can start important ARGUS functions directly, regardless of the currently active menu level.

Numeric key 2 Start Service Test

Numeric key 3 Start Supplemental Service Test

Numeric key 4 Start Auto. Test

Numeric key 6 Start Test Manager

Numeric key 7 Entry of your own and remote
call numbers in the speed-dialing memory

Numeric key 8 Trace ON/OFF

Numeric key 9 Start Bit Error Rate Test (BERT)



If a function is called where the ARGUS expects the entry of a digit, pressing a number key will be interpreted as the expected input.

7 Setting the type of access

If the parameters displayed at power on are not accepted, the Access menu will open automatically.

However, you can also open the Access menu at any time from the Main menu.

In the Access menu, the user must select the type of physical access to which the ARGUS is connected. When the ARGUS is restarted, the settings used last will be suggested as the default.

Status display

```
ARGUS44Pi BRI
B12 Level: OK
TEs P-MP DSS1
MENU RESTART
```

If you press the **<RESTART>** softkey, the B-channel test will be repeated.

Open the **Main menu**

```
ARGUS44Pi BRI
+Access
-----↓
← ↓ ✓
```

Using the **<↓>** select the **Access menu**

Open the **Access menu**

```
Access:
+ADSL
S-Bus interfac↓
← ↓ ✓
```

Using the **<↓>** select the type of access (e.g. ADSL)

Confirm the access

```
Access mode:
+ARGUS-ADSL
ARGUS-MODEM ↓
← ↓ ✓
```

The **Access Mode** menu will open automatically.

The following applies for all displays: If you press the **< ↶ >**, the ARGUS will return to the previous display.

7.1 Operation on a U-interface access (optional)

To test a U-interface access, the ARGUS is connected to the U-interface access using the U-interface adapter.


```
Access:
→S-Bus interface
POTS interface↓
←  +  ✓
```

As the physical access, select **BRI** in the Access menu.

```
Access mode:
→TE automatic
TE P-P ↓
←  +  ✓
```

The Access Mode menu will open automatically: In the case of a U-interface access, you must choose - as Access Mode - TE Automatic, TE P-P, TE P-MP or permanent circuit.

Connection of the ARGUS to a U-interface access:



What the LED on the U-Interface Adapter indicates:

- LED is red: not activated, e.g. cable not connected correctly
- LED flashing slowly - once per second - (green/red):
U-interface is activated;
the ARGUS, however, is deactivated
- LED flashing quickly - twice per second - (green/red):
ARGUS activated,
U-interface still deactivated
- LED is green: everything correct

8 Select the Access Mode



The Access Mode menu is **not** selectable from the Main menu.


It opens automatically once the physical access is selected in the Access menu.

8.1 Level measurement on a BRI or U-Interface

8.1.1 TE-Simulation mode

TE automatic

On a BRI or U-interface access, the ARGUS will automatically determine the D-channel Layer 2 mode (PP or P-MP). If the ARGUS determines that the access supports both modes, the following Configuration menu will open:



Using the <↓>, select the desired **L2 mode**.

Confirm the selected L2 mode



The ARGUS will return to the Main menu.

TE P-P or TE P-MP

Afterwards, the access and the protocol stack will be initialized in accordance with the selected setting. The ARGUS will then jump to the Main menu.

8.1.2 NT-Simulation mode (optional)

NT P-P or NT P-MP

Afterwards, the access and the protocol stack will be initialized in accordance with the selected setting. The ARGUS will then jump to the Main menu.

8.1.3 Permanent circuit

```

Access mode:
→Permanent swit.
-----↓
←      ↓      ✓

```

With the <↓>, select
Permanent switch.

Access mode
confirmed

```

ARGUS44Pi BRI
          Level: OK
FVs
      MENU START

```

The ARGUS is now switched
to Permanent circuit mode
(the display shows FV
[Festverbindung]) and will
open the Status display.

Besides dial-up connections to any subscriber, ISDN also supports the use of permanent circuits switched to a specific remote location.

These permanent circuits are available after setting up Layer 1, in other words after synchronizing both terminals by exchanging HDLC-frames.


The location where the clock is generated can be selected (see page 181 Clock mode).

As a quick test of a permanent circuit, you can simply call the opposite end using a selected B-channel.

However, for a more revealing test of a permanent circuit, you should perform a bit error rate test.

Both ends of the permanent circuit must use the same channel.

Telephony on permanent circuits

The function can be started with the -Key or via the selection **Phone / connec.** in the **Single tests** menu (see page 132 Connection).

After the B-channel for the permanent circuit is selected, the telephone connection will be setup automatically:



```
Permanent switch
Telephony B 01
Durat. 13:45:59
ABORT TM
```



```
ARGUS44pi BRI
Level: OK
FUs
MENU START
```

The ARGUS displays the B-channel used (e.g. B01) and the duration of the permanent circuit.

Use the **< TM >** softkey to start the Test Manager (see Page 144)

Terminate the permanent circuit

The ARGUS will open the Status display

BERT on permanent circuits

A number of variations are possible in testing permanent circuits with the bit error rate test.

In the simplest case, a B-channel loop will be set up at the remote end.

Start the BERT from the Single tests **menu / Bit error test submenu / BERT start** (see page 105 Start BERT). After selection of the channel to be tested (B-channel or D-channel), the ARGUS will send the test pattern, receive it back and evaluate it accordingly.

The displays and operation are, in largest part, similar to those of a BERT on a dial-up connection (see page 103 Bit error test), you simply need not enter call numbers or select a service.

In the case of a BRI access in end-to-end mode (see "Bit

error test" on page 103 and on page 111 "Bert wait"), it is also possible to run a BERT in the D-channel.

In this case, the channel select window will open:

```
Channel select
→B-channel (64k)
B-channel (128k↓
ABORT + ✓
```

With the <↓>, select the channel



```
B channel select
Active B ch.: 2
Ch.available !
← DEL ✓
```

Confirming a B-channel (e.g 64k)

Enter the B-channel on the keypad.




```
BERT 2^15 B02
15:45:42 3
synchron LOS: 5
ABORT TM ERROR
```

Confirm the selected channel and start the BERT.

The ARGUS will display

- the channel / bit rate used (e.g. B02)
- the remaining test time in Hours: Minutes: Seconds (e.g. 15:24:12)
- the bit errors that have occurred (e.g. 3)
- Synchronicity of the bit pattern (synchron)
- the LOS-counter (e.g. 5)
- .



BERT stop

Use the <ERROR> softkey to insert artificial bit errors to test the reliability of the BERT.

Use the <TM> softkey to start the Test Manager (Page 144).

Once it is over, the ARGUS will display the results of the BERT (see "Start BERT" on page 105.).

Loopbox with a permanent circuit

A loopbox can be setup for the permanent circuit by selecting in the **Single tests** menu / **Bit error test** submenu / the **B-channel LOOP** (see Page 112).

The Channel select window will open:

When selecting a B-channel, the B-channel select window will open in which you must enter the desired B-channel. If "All framed" is selected, both B-channels and the D-channel will be looped.

```
Channel select
→B-channel
  All framed ↓
ABORT ↑ ✓
```

Activate loopbox

The ARGUS will display the channel used (B01) and the amount of time (h:min:sec) that the Loopbox has been active.

```
Permanent switch
Loopbox active01
Durat. 0:45:59
ABORT TM
```

Loopbox stop

Switching from permanent circuit mode

Using the <↓> select the **Access** menu

```
ARGUS44Pi BRI
→Access
-----↓
← ↑ ✓
```

Using the <↓>, select the desired access.

```
Access:
→S-Bus interface
POTS interface↓
← ↑ ✓
```

Using the <↓>, select the desired Access mode (e.g. TE automatic).

```
Access mode:
→TE automatic
TE P-P ↓
← ↑ ✓
```

Confirm the selected access mode

The ARGUS will open the Status display

```
ARGUS44Pi BRI
B12 Level: OK
TEs P-MP DSS1
MENU RESTART
```

8.1.4 Monitor

The ARGUS accepts all of the D-channel signals from the BRI access and sends these D-channel signals over the serial interface to a PC which must be running ARGUS WINplus or WINAnalyse. Neither the S-Bus nor Layer 1 are influenced.

```
Access mode:
→Monitor
Permanent swit↓
←      ↓      ✓
```

Using the <↓>, select **Monitor**.

Confirm the selected access mode

```
ARGUS44Pi BRI
Level: OK
Monitor
MENU START
```

The ARGUS evaluates the level on the NT-side: OK, << (too low), >> (too high), _ (no level)

Start monitoring

The Trace LED lights.

```
Monitoring
Signals:      25
Time:        00:02:59
ABORT LISTEN
```

The ARGUS displays the number of recorded signals (e.g. 25) and the recording time in h:min:sec.

Select < ABORT >: Stop monitoring.

Listening-in on voice data

The B-channel select dialog will open:

Enter the B-channel. The ARGUS will switch the handset to this B-channel.

It is now possible to listen to the voice data (in the direction Network ---> User).

```
B channel select
Active B ch.: 2
Ch.available !
←      DEL      ✓
```

Listening-in

Parallel call display while monitoring

```
Monitoring
Signals: 25
Time: 00:02:59
ABORT LIST. CALL
```

While monitoring, the ARGUS will search all of the D-channels signals sent for a SETUP. If a SETUP is detected, the <CALL> softkey will be displayed.

Display the call parameters of the last SETUP received.

```
N -> U FaxG3
125670 B01
to: 02351901720↓
← → SIGNAL
```

The ARGUS displays the call direction (**Net -> User**), the service (e.g. FaxG3), the own number (e.g. 125670), the channel used (e.g. B01) and the destination number (e.g. 02351 901729).

Display of other parameters: Sub-address (SUB) , User-User-Info (UII), DSP messages (if existent), Type of Number (T.O.N) , Numbering Plan (NP).

```
N -> U FaxG3
TON: unknown ↓
NP: unknown ↓
← → SIGNAL
```

```
Monitoring
Signals: 25
Time: 00:02:59
ABORT LIST. CALL
```

8.2 Operation on a POTS (analog) access

```
Access:
→POTS interface
-----↓
←  +  ✓
```

Using the <↓>, select **POTS interface**.

Confirm the access

```
Access mode:
→POTS terminal
POTS monitor ↓
←  +  ✓
```

Using the <↓>, select the **Access mode** menu.

With the <✓>, confirm the selected **Access mode**.

8.2.1 POTS terminal

The Argus behaves like a POTS (analog) terminal.

```
ARGUS44Pi POTS
Voltage: 35.5V
-----
MENU TALK
```

If you press <MENU>, the ARGUS will return to the Main menu.

Setup the connection

See Page 141

```
POTS telephony
to: 02351907070
-----
CLEAR MEM R
```

8.2.2 POTS monitor

Essentially, the POTS (analog) monitor provides a high impedance tap that does not influence the interface. You can listen to the line with the integrated handset without having the ARGUS send on the interface.

```
ARGUS44Pi POTS
Voltage: 36,3V
Monitor
MENU START
```

The ARGUS displays the voltage level on the line when it is "on hook" (not busy).

Start monitoring

```
POTS mon. U: U
02351907070
DTMF: 2345678 ↓
ABORT DEL.
```

The ARGUS displays the voltage (when "off hook"), the number of the caller (if CLIP is supported) and the DTMF characters dialed by both telephone subscribers and the SMSs received (optional).

Any received DTMF-characters will be appended to the line, which will shift left for each character once it is full.

Monitoring
stop

An incoming call will be signalled acoustically.

Press the ↓-Key to display additional information, if available on the access (e.g. advice of charges).

Press to clear the display.

9 ADSL Tests

The ARGUS supports a variety of access types:

ARGUS ADSL: Connection of the ARGUS directly to the ADSL access (before or after the splitter). The ARGUS replaces both the modem and the PC.

PC-ARGUS-ADSL (optional): Insertion of the ARGUS between the ADSL access and the PC. The ARGUS replaces the ADSL modem (Modem replacement mode).

ARGUS-MODEM (optional): Connection of the ARGUS to the ADSL modem. The ARGUS replaces the PC (PC replacement mode).

Depending on the access mode selected (and the protocol), the following ADSL tests are supported:

Access mode	
ARGUS-ADSL (PC-Modem replacement mode)	<ul style="list-style-type: none"> - Physical test - Ping test - Trace route test - Download test - VPI/VCI scan - ATM OAM ping - OAM loop - FTP upload - ATM BERT
ARGUS-MODEM (PC replacement mode)	<ul style="list-style-type: none"> - Ping test - Trace route test - Download test - FTP upload
PC-ARGUS-ADSL (Modem replacement mode)	<ul style="list-style-type: none"> - Physical test - Bridge mode - Router mode

The ARGUS displays the results during the test.

If desired, the ARGUS will save the test results (even if the test is aborted) together with the date and time in its internal Flash memory.

The saved results can later be sent to a PC or viewed on the display.

The ARGUS supports the following ADSL modes (depending on the national variant and the installed options)

ADSL Mode	Standard
- Annex B (DT)	T-DSL (UR2)
- Annex B (ETSI)	ETSI DTS
- Annex A auto	automatic Annex A detection
- ANSI T1.413	ANSI T1.413.2
- G.Lite	ITU-T G.992.2
- G.DMT	ITU-T G.992.1



We must point out that the ARGUS records and stored data (e.g. in tracing IP data). The user must comply with the statutory regulations governing the collection and storage of such data and his obligation to give notice in this connection.


9.1 The ARGUS in Access Mode

Access Mode: ARGUS-ADSL

Using the ADSL 2-wire connection cable, the ARGUS is connected directly to the ADSL access (either before or after the splitter). In this case, the ARGUS replaces both the modem and the PC.

In the ARGUS-ADSL access mode, the following tests can be performed:

- **Physical test**
- **Ping test**
- **Trace route test**
- **Download test**
- **VPI/VCI scan test**
- **ATM OAM ping**
- **OAM loop**
- **FTP upload**
- **ATM BERT**



Setting the device to the ARGUS-ADSL access mode:


```
ARGUS44Fi BRI
->Access
-----↓
↑ + ✓
```

In the Main menu, use the <↓> to select the **Access** menu.

```
Access:
->ADSL
S-Bus interfac↓
↑ + ✓
```

Using the <↓>, select ADSL.

The Access mode menu will open automatically.



Using the <↓>, select **ARGUS-ADSL**.

If you press the <←>, the ARGUS will return to the previous display.

The ARGUS will open the Status display



The ARGUS will display the selected access mode, ARGUS-ADSL, and the DC voltage on the access interface.



If the ARGUS is not yet active, you must first select a test and start it. (see the next pages).

9.1.1 Physical test (ADSL line test)

The ARGUS will setup an ADSL connection and determine all of the relevant ADSL line parameters.

The ARGUS displays the results during the test and saves them in the internal Flash memory when the test is finished or aborted.

Parameter settings:

In the physical test, the ARGUS uses the following parameters that are saved in the ADSL profile (see Page 166):

- Physic. line: ADSL mode, Link-up time, Rated value, SNR margin DS, Shutdown mode

The ARGUS
Status display

If you press **Menu**, the ARGUS will open the Main menu. Press **<START>** to open the ADSL profile menu

Using the **<↓ >**, select the **Single tests** menu.


Open the Single tests menu

Using the **<↓ >**, select **Physical test**.

The ADSL profile window will open.

Using the **<↓ >**, select ADSL profile.

If you press on **<EDIT>**, the ARGUS will open the settings menu for the profile. In this menu, you can adjust the parameters of the selected profile to suit the respective test situation (see "Configuring ADSL profiles" on page 166).



The ARGUS synchronises itself with the DSLAM.

While the ARGUS is attempting to setup the ADSL connection, the "SYNC" LED will flash .

The ARGUS displays the current setup time (in the example: 35 seconds) and the ADSL mode (e.g. G.DMT).

```

Wait for act.
Test time: 35s
G.DMT
ABORT TRACE
    
```

Display trace data

The ARGUS records and displays the commands, which are received or sent by the ADSL modem and modem status:

- <= command from ARGUS
- > = command from modem
- = modem status

Using the <↓>, scroll through

```

Online 01/03
- Modem idle
< Open ↓
← → TIME
    
```

Display timestamp

Time that the command was received

```

Online 01/03
- Modem idle
10:25:00:000 ↓
← →
    
```

If you press the <↶>, the ARGUS will return to the previous display.

If the connection is not successfully setup within a specific time (a maximum of 2 periods of 4 minutes = "Time out") or if an error occurs during the setup, the ARGUS will display a corresponding error message (see "Error message: ADSL connection" on page 217):

```

Test failed
Cause:
Uncomp.linecon.
← TRACE NEW

```

Press < **TRACE** > to have the ARGUS display the recorded trace data.
If you press < **NEW** > the ARGUS will make another attempt to setup the ADSL connection.

```

Test result
Save?
NO YES

```

The ARGUS saves the recorded trace data in its internal Flash memory (Page 149).

```

Start another
test?
NO YES

```

A new test can be started afterwards without reinitializing the ADSL test software.

```

Single tests
→Physical test
Pins ↓
← + ✓

```

Once the connection has been setup (Sync LED ON constantly), the ARGUS will determine the ADSL line parameters.

After the period set for the test has elapsed (see "Link-Up Time" on page 168), the ARGUS will automatically clear down the connection (unless: the test time has been set to "continuous", in which case the test must be terminated manually by pressing < **ABORT** >).

The ARGUS will display the already determined results during the test.

Once the test is over, the ARGUS will automatically open the results display:

```
Showtime
G.DMT
Elapsed:0:00:09↓
← TRACE GRAPH
```

The test has run for 9 seconds.
 Use the <↓>-Key to scroll through the results.
 Use the <↑>-Key to scroll back.
 Press on <TRACE> to view the trace data.
 Press <GRAPH> to view the bit distribution (Page 49)

↓-Key

```
Test result
G.DMT
Elapsed:0:00:13↓
← TRACE GRAPH
```

Viewing the results

The ARGUS displays the ADSL mode (in this example G.DMT) and the current duration of the test.

↓-Key

```
Test result
Rated val. comp.
d: OK u: OK↓
← TRACE GRAPH
```

Rated value comparison:

The rated value, which was set for the bit rate, is compared with the rate actually achieved (see Page 168)
 d: Downstream
 u: Upstream

↓-Key

```
Test result
ATM (int.) [Kb/s]
d: 7616 u: 928↓
← TRACE GRAPH
```

ATM:

Actual usable ATM data rate in kBit/s for downstream and upstream. The ARGUS will indicate which mode is configured in DSLAM (Interleaved or Fast Mode) by appending either "int." (for interleaved) or "fast" (for Fast Mode).

↓-Key

```
Test result
Attain.ATM [Kb/s]
d: 5800 u: 480↓
← TRACE GRAPH
```

Attainable ATM

This is the theoretically attainable ATM data rate in kBit/s.

↓-Key

↓

```

Test result
Rel.capacity [%]
d: 85 u: 100↓
← TRACE GRAPH

```

Relative Capacity Occupation

Displays the upstream and downstream line load.

↓-Key

```

Test result
Line rate [Kb/s]
d: 7616 u: 928↓
← TRACE GRAPH

```

Line Rate

This is the gross data rate, which is calculated from the bits/tonne spectrum. In contrast to the ATM data rate, this value also includes the overhead for the ATM header, additional framing bits and checksums.

This value is always higher than the ATM data rate!

↓-Key

```

Test result
SNR margin [dB]
d: 23.5 u: 31.0↓
← TRACE GRAPH

```

Noise margin (SNR margin)

Signal-to-noise ratio in dB for the upstream / downstream transmission

The SNR margin or Noise margin - is a measure (in dB) of how much additional noise the transmission can withstand and still achieve a BER (Bit Error Rate) of 10^{-7} .

↓-Key

```

Test result
Out.power [dBm]
d: 19.0 u: 12.0↓
← TRACE GRAPH

```

Output power

The output power in dBm for the upstream and downstream transmission

↓-Key

```

Test result
Attenuation [dB]
d: 38.0 u: 25.5↓
← TRACE GRAPH

```

Attenuation

The line's attenuation in dB over the entire line for upstream and downstream transmissions

↓-Key

↓

```
Test result
FEC (int.)
f: 40 n: 53↓
← TRACE GRAPH
```

Forward Error Correction

The FEC shows the number of transmission errors corrected by using the ATM cell checkbytes.

f (far): Errors that the DSLAM has detected and informed the ARGUS.


n (near): Errors which were detected by the ARGUS in the blocks it received.



```
Test result
CRC (int.)
f: 0 n: 0↓
← TRACE GRAPH
```

Cyclic Redundancy Check


The superframe checksum sent from the opposing end does not match the one calculated locally. Possible cause: Fault on the line.



```
Test result
HEC (int.)
f: 112 n: 92↓
← TRACE GRAPH
```

Header Error Checksum


The HEC shows the number of ATM cells with bad header checksums.



```
Test result
ATM cell count
Rx: 150↓
← TRACE GRAPH
```

ATM Cell count

Counter for the sent (Tx) and received (Rx) ATM cells




```
Test result
Vendor far: TSTC
Version: 2↓
← TRACE GRAPH
```

Vendor far

The hexadecimal ID number for the manufacturer of representation (see "Vendor identification numbers" on page 208)


SW version on the ATU-C side
(Only returned in ANSI mode)






Bit distribution

i.e. bits transported per carrier frequency
 (y-axis: bits per carrier frequency (tones);
 x-axis: carrier frequency)
 Based on the bit distribution, it is possible to detect line disturbances (e.g. HDB3, HDSL, RF.....)




↓-Key




Return to the ADSL line parameters

e.g. Vendor far




Close the results display

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory (see Page 149).



Press <EDIT> to edit the parameters of the displayed ADSL profile (see Page 166)



Any ADSL test desired can be started without reinitializing the ADSL test software.


9.1.2 Ping test

In the Ping test, the ARGUS checks whether it is possible to setup a connection to an Internet Service Provider (ISP) via the DSLAM and ATM network: The ARGUS sends a test packet to a predefined IP address (remote site) and then waits for a packet in reply.

Based on the received packet, it is possible to evaluate the ATM network availability and delay. It is also possible to determine the network's maximum data packet size.

The following parameters (which are stored in the ADSL profile, see Page 166) are required for the Ping test:

Protocol independent parameters



Ping - Parameter

- IP address:
Address of remote site
- Number of pings:
Number of test packets sent by ARGUS
- Pause:
Pause between sending two test packets
- IP packet size:
Size of the test packet
- Fragmentation:
Sets the fragmentation of the test packet
(see "Ping:" on page 171)



PPP parameters

- User name for the Internet connection
- Password
(see "PPP:" on page 170)



Protocol dependent parameters

Protocol	PPPoE / PPPoA	IPoA / EoA
Parameter	ATM - VPI / VCI - Encapsulation	ATM - VPI / VCI - Encapsulation
	PPP - User name - Password	
	ADSL mode	ADSL mode
		WAN: - IP mode (Static IP) - own IP address - IP network mask - remote IP address
		DNS server: - DNS Server 1 - DNS Server 2

Starting a Ping test:

```
ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START
```

ARGUS displaying Status

The ARGUS will return to the Main menu.

```
ARGUS44Pi ADSL
→Single tests
Automatic test↓
←  ↓  ✓
```

Using the <↓>, select the **Single tests** menu.

Open the Single tests menu

```
Single tests
→Ping
Traceroute ↓
←  ↓  ✓
```

Using the <↓>, select **Ping test**.

The list of ADSL profiles will open.

```
ADSL Profile
*ADSL Profile 1
ADSL Profile 2↓
← EDIT ✓
```

Using the <↓>, select an ADSL profile.
(The default profile is marked with an "*".)

If you press on <EDIT>, the ARGUS will open the settings menu for the profile. In this menu, you can change the parameters (see "Configuring ADSL profiles" on page 166).

Confirm selection of profile.


```
ADSL line
Initializing ✓
G.DMT
ABORT
```

Initializing the ARGUS

```
User name
83910235190700#0
0010t-online.de
ABORT DEL 3b>AB
```

At first, the ARGUS will display the user name stored for the ADSL profile.


If necessary, change the user name (for instructions, see Page 170)



```
Password
*****
ABORT DEL 3b>AB
```

If you change the user name, you must enter the password again (see Page 170).

The changes are placed in temporary storage. The ADSL profile is not modified.




```
IP address 1/10
*www.argus.info
0. 0. 0. ↓
← EDIT ✓
```

The ARGUS displays the IP address stored in the ADSL profile.

To select the IP address for the Ping, use the <↓> (The default address is marked with an "*".)

Press <EDIT> if you want to change the IP address. (see Page 171).



```
Ping test
Initializing
ABORT ADSL
```

```
Showtime
G.DMT
Elapsed:0:00:09↓
← TRACE GRAPH
```

Ping test

```
Ping test
Sent: 5/6
Received: 5/6
ABORT ADSL
```

```
Ping test
Sent: 10
Received: 10↓
← ADSL NEW
```

↓-Key

```
Ping test
Repeated: 0
CS Error: 0↓
← ADSL NEW
```

↓-Key

```
Ping test
Error: 0
Min [ms]: 1,1↓
← ADSL NEW
```

↓-Key

Initialising the test software
 Press the <ADSL> or Level-Key to display the ADSL mode, ADSL line parameters (scroll through with the ↓-Key), trace data (<TRACE>), bit distribution (<Graphic>).
 The ARGUS will start the Ping test

During the test, the ARGUS will display the current number of test packets sent and the number of packets received in reply.
 Depending on the access mode and protocol, the LAN, WAN, PPP and ATM statistics will also be displayed (scroll through with the ↓-Key)
 If you press <ADSL>, the ADSL line parameters will be displayed.
 Press <ABORT> to cancel the test. The ARGUS will display the results collected thus far and will inquire whether to save them.

Once the test is over, the ARGUS will automatically open the results display:
 The ARGUS will display

- Number of packets sent
- Number of packets received
- Number of packets sent again
- Checksum errors
- Faulty received packets
- Min packet round-trip delay
- Max packet round-trip delay
- Average packet round-trip delay
- Statistics.

```
Ping test
Max [ms]: 18,1
Ave [ms]: 3,84
┌─ ADSL NEW
```

Press the <ADSL> or Level-Key to display the ADSL mode, ADSL line parameters. (see Page 43). Press <NEW> to start a new Ping test.

```
Ping test
Save?
NO IP>PC YES
```

Saving a Ping test

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory. (see “Automatic Test” on page 149 and Display saved results on page 155)

```
TCP dump upload
File: 1/1
Progress: 33%
ABORT.
```

The ARGUS will send the trace file to the connected PC, which must be running WINplus or WINanalyse. The data will be saved in the standard "libpcap" format and can be decoded with a freeware tool, such as Etherreal. (In the example, 33% of the data was already uploaded to the PC.)

```
Start another
test?
ADSL profile 5
NO EDIT YES
```

Press <EDIT> to edit the parameters of the displayed ADSL profile (see “Configuring ADSL profiles” on page 166)

```
Single tests
→Physical test
Ping ↓
┌─ ── ✓
```

Any ADSL test desired can be started without reinitializing the ADSL test software.

Ping Test – Error messages

```
Ping test
Error:
No PPP connec.
  ↩  ADSL  NEW
```

If an error occurs, the ARGUS will stop the test and display an error message.

Press <NEW> to start a new Ping test.


For a description of the error messages, please see the appendix.

9.1.3 Trace Route - Test

In a Trace Route test, the ARGUS sends a test packet and then displays a list of all of the network nodes (hops) and their response times on the way to the destination address. This information can then be used to precisely locate delays in the network.

The following parameters (which are stored in the ADSL profile, see Page 166) are required for the Trace Route test:

Protocol independent parameters



- IP address:
IP address of the destination node
- Maximum hops:
Maximum number of network nodes, traversed on the route
- Probes:
Number of attempts to reach a network node
- Timeout:
Maximum time to wait for an answer from a network node
(see "Traceroute:" on page 172)

Protocol dependent parameters

Protocol	PPPoE / PPPoA	IPoA / EoA
Parameter	ATM - VPI / VCI - Encapsulation	ATM - VPI / VCI - Encapsulation
	PPP - User name - Password	
	ADSL mode	ADSL mode

		WAN:
		- IP mode (Static IP) - own IP address - IP network mask - remote IP address
		DNS server:
		- DNS Server 1 - DNS Server 2

Trace Route Test - starting

```
ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START
```

ARGUS displaying Status

The ARGUS will return to the Main Menu

```
ARGUS44Pi ADSL
*Single tests
Automatic test↓
← ↓ ✓
```

Using the <↓>, select the **Single tests** menu.

Open the Single tests menu

```
Single tests
*Traceroute
Download ↓
← ↓ ✓
```

With the <↓>, select **Traceroute**

The list of ADSL profiles will open.

```
ADSL profile
*ADSL profile 1
ADSL profile 2↓
← EDIT ✓
```


Using the <↓>, select an ADSL profile (The default setting is marked with an "*").

If you press <EDIT>, the ARGUS will open the settings menu for the profile. In this menu, you can change the parameters (see "Configuring ADSL profiles" on page 166).


```
ADSL line
Initializing ✓
G.DMT
ABORT
```

Initializing the ARGUS

```
User name
83910235190700#0
0010t-online.de
ABORT DEL 3b>AE
```



```
Password
*****
ABORT DEL 3b>AE
```




```
IP address 1/10
*www.argus.info
0. 0. 0. ↓
← EDIT ✓
```



```
Traceroute test/
Initializing
ABORT ADSL
```

Trace route test

```
Traceroute test/
2 -1 : 0.022s
192.168. 4.253
ABORT ADSL
```



At first, the ARGUS will display the user name stored for the ADSL profile.

Change the user name if necessary (for instructions, please see Page 170)

If you change the user name, you must enter the password again (see Page 170). The changes are placed in temporary storage. The ADSL profile is not modified.

The ARGUS displays the IP address stored in the ADSL profile.

To select the IP address for the Ping, use the <↓> (The default address is marked with an "*".)

Press <EDIT> if you want to change the IP address. (see Page 171).

Initialising the test software
The Traceroute test will start automatically after the initialisation.

The ARGUS displays the current hop and probe (2 -1: 2nd hop and 1st probe), the current response time of the hop to the current probe (0.022 seconds) and the IP address of the current hop (in the example: 192.168.4.253).

Depending on the access mode and protocol, the LAN, WAN, PPP and ATM statistics will also be displayed (scroll through with the ↓-Key)

Press <ABORT> to cancel the test. The ARGUS will display the results of the test thus far

and inquire whether to save them.

```
Showtime
G.DMT
Elapsed:0:00:09↓
← TRACE GRAPH
```

Display of the ADSL mode, ADSL line parameters... (see Page 43)

At the end of the test, the ARGUS will display the test results:

```
Traceroute test
1 -av: 0.005s
192.168. 4.253↓
← ADSL NAME
```

The ARGUS displays all of the hops and the average response time (calculated for all probes) and - depending on the access - the LAN, WAN, PPP and ATM statistics.

In this example: 1st hop (1 - av) with the average response time of 0.005sec (1 -av) and the IP address 192.168.4.253

Use the ↓-Key to scroll through the results.

Press <NAME> to display the IP address of the hop as a name (if possible).

```
Traceroute test
Save?
NO IP>PC YES
```

Traceroute result - saving

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory.

(see "Automatic Test" on page 149 and Page 155)

```
TCP dump upload
File: 1/1
Progress: 33%
ABORT.
```

The ARGUS will send the trace file to the connected PC, which must be running WINplus or WINanalyse.

The data will be saved in the standard "libpcap" format and can be decoded with a freeware tool, such as



Etherreal.
(In the example, 33% of the data was already uploaded to the PC.)

Press <EDIT> to edit the parameters of the displayed ADSL profile (see "Configuring ADSL profiles" on page 166)

Any ADSL test desired can be started without reinitializing the ADSL test software.

9.1.4 Download Test

In the Download test, the ARGUS will attempt to download data from a web site or file. The Argus will display the current download rate and once the test is over the average speed (g.g. in the case of multiple download attempts).

The following parameters (which are stored in the ADSL profile, see Page 166) are required for the Download test:

Protocol independent parameters

```
ADSL profile
+Download
UPI/UCI scan ↓
← + ✓
```

- Number:

How often the data from "Source" address should be downloaded

```
Download
+Numbers
Addresses ↓
← + ✓
```

- Address:

First select the type of "Source" address:

HTTP (Websites or files) or FTP (files)

Afterwards, you can enter a "Source" address as a URL (see "Download :" on page 173)

```
Addresses
*HTTP
FTP ↓
← + ✓
```



If an alias www address is entered as the "Source" address (e.g. www.argus.info/web/download/software/Software32.ZIP), the ARGUS will "only" load the HTML pages during the Download test (in the example ca. 600 bytes). The ARGUS does not evaluate the HTML code, so any link to a "true" www address (e.g. www.isdntester.com) will be ignored. In this case, the ARGUS will not display an error message since the "Source" address specified will have been loaded without error. When entering the "Source" address make certain that you use the correct notation (e.g. www.isdntester.com/web/download/software/Software32.ZIP), otherwise the ARGUS will report an Error 301 (Moved Permanently) or Error 404 (Not Found).



In the case of a Download test of less than 10 seconds, it is not possible to accurately determine the transmission speed.

Protocol dependent parameters

Protocol	PPPoE / PPPoA	IPoA / EoA	
Parameter	ATM - VPI / VCI - Encapsulation	ATM - VPI / VCI - Encapsulation	
	PPP - User name - Password		
	ADSL mode	ADSL mode	
			WAN: - IP mode (Static IP) - own IP address - IP network mask - remote IP address
			DNS server: - DNS Server 1 - DNS Server 2

Download test - starting

```

ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START

```

ARGUS displaying Status

```

ARGUS44Pi ADSL
*Single tests
Automatic test↓
← + ✓

```

Using the <↓>, select the **Single tests** menu.

Open the Single tests menu

```

Single tests
*Download
VPI/QCI scan ↓
← + ✓

```

With the <↓>, select **Download**.

Open the list of ADSL profiles.

```

ADSL profile
*ADSL profile 1
ADSL profile 2↓
← EDIT ✓

```

Using the <↓>, select an ADSL profile.

The parameters in the selected profile will be used in the Download test.

Press <EDIT> to edit the profile (see Page 166)

```


ADSL line
Initializing ✓
G.DMT
ABORT

```

Initializing the ARGUS


```
User name
83910235190700#0
0010t-online.de
ABORT DEL 36>AB
```

At first, the ARGUS will display the user name stored for the ADSL profile. If necessary, change the user name (for instructions, see Page 170)



```
Password
*****
ABORT DEL 36>AB
```

If you change the user name, you must enter the password again (see Page 170). The changes are placed in temporary storage. The ADSL profile is not modified.



```
Addresses
*HTTP
FTP
ABORT DEL 36>AB
```

Use the ↓-Key to select the type of "Source" address (in the example, HTTP)



```
HTTP address 1/3
*argus.info
ABORT EDIT ✓
```

The ARGUS displays the address stored in the profile. Use the ↓-Key to select an address to serve as the "Source" address (The default setting is marked with an "*"). Press <EDIT> if you want to change the address.




```
Download test
Initializing
ABORT ADSL
```

Initialisation of the test software

Download test

```
Download test
1/3
073% 360kb/s↓
ABORT ADSL
```

The Download test will start automatically. The ARGUS displays the following during the test: In the example, the first download of a total of three attempts (1/3) is shown. 73% of the data has already been loaded. The current download rate is 360 kBits per second.




```
Download test /
080% 360kb/s
1,92 MB 2,40 M↓
ABORT ADSL
```

Thus far 1.92 MB has been downloaded. The total file size is 2.4 MB.

Use the ↓-Key to scroll down to view how long the download has been in process.

(in h.min.sec:msec) and the time remaining until it will be done.

Depending on the access mode and protocol, the LAN, WAN, PPP and ATM statistics will also be displayed (scroll through with the ↓-Key)

**Download test
Result**

```
Download test
ava: 323.38kb/s
min: 20.00kb/s↓
← ADSL NEW
```

```
Download test
Save?
NO IP>PC YES
```

```
Start another
test?
ADSL profile 5
NO EDIT YES
```

At the end of the test, the ARGUS will automatically display the result.

The ARGUS will display

- the achieved average speed of the download process (323.38 kb/s)
- the minimum download rate (20.00 kb/s)
- the max download rate
- size of the file downloaded
- the average time for a download
- statistics

(scroll with the ↓ -Key).

Press <NEW> to start a new Download test (without reinitialising).

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory.

(see "Automatic Test" on page 149 and Page 155)

Press <IP>PC> to upload the trace file to the PC.

The data will be saved in the standard "libpcap" format

and can be decoded with freeware tools, such as Etherreal.

Press <EDIT> to edit the parameters of the displayed ADSL profile

(see "Configuring ADSL profiles" on page 166)

Any ADSL test desired can be started without reinitializing the ADSL test software.

9.1.5 VPI/VCI scan test

In the VPI/VCI scan test, the ARGUS checks which VPI/VCI combinations are active on the access under test: The ARGUS will send a test packet for each of the possible VPI / VCI combinations and wait for a packet in response.

The following parameters (which are stored in the ADSL profile, see Page 166) are required for the VPI / VCI scan test:

VPI/VCI scan test parameters:

```
ADSL profile
→VPI/VCI scan
  ATM OAM ping ↓
  ←  →  ✓
```

- VPI:
Sets the limits of the VPI range checked by the ARGUS.

```
VPI/VCI scan
→VPI
  VCI ↓
  ←  →  ✓
```

- VCI:
Sets the limits of the VCI range checked by the ARGUS.

```
VPI range:
Start: 0
End: 8
ABORT DEL ✓
```

- Number of pings:
Sets the number of test packets to be sent by the ARGUS.

- Timeout:
Sets the maximum time to wait for a response from an ATM network node.

(see "VPI/VCI scan:" on page 174)

VPI/VCI scan test - starting

```
ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START
```

ARGUS displaying Status

```
ARGUS44Pi ADSL
→Single tests
Automatic test↓
← ↓ ✓
```

Using the <↓>, select the **Single tests** menu.

```
Single tests
→VPI/VCI scan
ATM OAM Ping ↓
← ↓ ✓
```

Using the <↓>, select **VPI/VCI Scan**.

```
ADSL Profile
*ADSL profile 1
ADSL profile 2↓
← EDIT ✓
```

Open the list of ADSL profiles.

Using the <↓>, select an ADSL profile.

The parameters in the selected profile will be used in the VPI/VCI scan test.

Press <EDIT> to edit the profile (see Page 166)

```
ADSL line
Initializing ✓
G.DMT
ABORT
```

Initializing the ARGUS

```
VPI / VCI scan✓
Initializing
ABORT ADSL
```

Initialisation of the test software


VPI/VCI scan test

```
VPI / VCI scan\
VPI: 2
VCI: 32
ABORT ADSL
```

The VPI/VCI scan test starts automatically.

The ARGUS will display the currently tested VPI/VCI combination.

Depending on the access mode and protocol, the LAN, WAN, PPP and ATM statistics will also be displayed (scroll through with the ↓-Key)



```

Showtime
G.DMT
Elapsed:0:00:09↓
← TRACE GRAPH

```

Select <ABORT> : The test will be cancelled, the ARGUS will display the results collected thus far and will inquire whether to save them.

Display the ADSL mode, ADSL line parameters... (see Page 43).

```

VPI / VCI
8 / 48
← ADSL NEW

```

Once the test is over, the ARGUS will automatically open the results display:

The ARGUS will display the VPI/VCI combinations that are active on the access under test and the statistics (scroll through using the ↓-Key) .

Press <NEW> to start a new test.





```

VPI / VCI scan
Save?
NO YES

```

VPI/VCI scan results - saving

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory (see "Automatic Test" on page 149 and Page 155).

```

Start another
test?
ADSL Profile 5
NO EDIT YES

```

Press <EDIT> to edit the parameters of the displayed ADSL profile

(see "Configuring ADSL profiles" on page 166)

Any ADSL test desired can be started without reinitializing the ADSL test software.

9.1.6 ATM OAM ping test


In the ATM OAM ping test, the ARGUS checks the availability of individual ATM network nodes or an ATM subnet.

The following parameters (which are stored in the ADSL profile, see Page 166) are required for the ATM OAM ping test:

```
ADSL profile
→ATM OAM ping
FTP upload ↓
← + ✓
```

- VPI: Entry of the VPI

- VCI: Entry of the VCI



```
ATM OAM ping
→VPI/UCI
Count of pings ↓
← + ✓
```

- Number of pings:
Number of test packets that the ARGUS sends

- Timeout:
Maximum time to wait for answer from an ATM network node



```
VPI/UCI
VPI:1
UCI:32
ABORT DEL ✓
```

- OAM cell type

(see "ATM OAM ping:" on page 174)

Start ATM OAM ping test

```
ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START
```

ARGUS displaying Status

```
ARGUS44Pi ADSL
->Single tests
Automatic test↓
← ↓ ✓
```

Using the <↓>, select the **Single tests** menu.

```
Single tests
->ATM OAM Ping
OAM loop ↓
← ↓ ✓
```

Using the <↓>, select **ATM OAM ping test**.

```
ADSL Profile
*ADSL profile 1
ADSL profile 2↓
← EDIT ✓
```

Open the list of ADSL profiles.

Using the <↓>, select an ADSL profile.

The parameters in the selected profile will be used in the ATM ping test.

Press <EDIT> to edit the profile (see Page 166)

Initializing the ARGUS

```
ADSL line
Initializing ✓
G.DMT
ABORT
```

Initialisation of the test software

```
ATM OAM Ping ✓
Initializing
ABORT ADSL
```

The ATM OAM ping test will start automatically.

The ARGUS will display the current number of test packets sent and packets received in response.

ATM OAM ping test

```
ATM OAM Ping ✓
Send: 6
Receive: 5
ABORT ADSL
```

Depending on the access mode and protocol, the LAN, WAN, PPP and ATM statistics will also be displayed (scroll through with the ↓-Key)

↓

```

Showtime
G.DMT
Elapsed:0:00:09↓
← TRACE GRAPH
    
```

Press <ABORT> to cancel the test. The ARGUS will display the results collected thus far and will inquire whether to save them.

display the ADSL mode, ADSL line parameters... (see Page 43).

```

ATM OAM Ping
Send:      10
Receive:   10↓
← ADSL NEW
    
```

Once the test is over, the ARGUS will automatically open the results display: The ARGUS will display

- Number of packets sent
- Number of packets received
- Number of packets lost
- Min packet round-trip delay
- Max packet round-trip delay
- Average packet round-trip delay
- LAN, WAN, PPP and
- ATM statistics.

↓-Key

```

ATM OAM Ping
Lost:      0
Min [ms]: 148,0↓
← ADSL NEW
    
```

(Scroll through with the ↓-Key.)

Press <NEW> to start a new ATM OAM ping test.

```

ATM OAM Ping
Save?
NO      YES
    
```

ATM OAM ping results saving

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory (see "Automatic Test" on page 149 and Page 155).

```

Start another
test?
ADSL profile 5
NO  EDIT  YES
    
```

Press <EDIT> to edit the parameters of the displayed ADSL profile (see Page 166)

Any ADSL test desired can be started without reinitializing the ADSL test software.

9.1.7 OAM loop

In this mode of operation, the ARGUS loops all OAM cells of the remote end.

```
ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START
```

Status display

```
ARGUS44Pi ADSL
→Single tests
Automatic test↓
←  ↓  ✓
```

Using the <↓>, select the **Single tests** menu.

```
Single tests
→OAM loop
FTP upload ↓
←  ↓  ✓
```

Using the <↓>, select **OAM loop**.

```
ADSL profile
*ADSL profile 1
ADSL profile 2↓
←  EDIT  ✓
```

Using the <↓>, select the ADSL profile
.Press <EDIT> to edit the profile (see Page 166)

```
ADSL line
Initializing ✓
G.DMT
ABORT
```

Synchronisation with the DSLAM and initialisation of the test software

```
OAM loop
Active!
Elapsed00:12:11
ABORT ADSL
```

OAM loop active.

The duration of the OAM loop will be displayed in hr:min:sec.

Use <ADSL> display the ADSL line parameters... (see Page 43).

Select <ABORT> to stop the OAM loop.

```
Start another
test?
ADSL profile 5
NO  EDIT  YES
```

Press <EDIT> to edit the parameters of the displayed ADSL profile (see Page 166)

Any ADSL test desired can be started without reinitializing the ADSL test software.

9.1.8 FTP upload test

In the FTP upload test, the ARGUS sends the data in a file to a server.

The Argus will display the current upload rate and once the test is over the average speed (g.g. in the case of multiple upload attempts).

Three user-defined "Server Profiles" can be created for the FTP upload test (see Page 174) :

Protocol independent parameters



- Destination:
Entry of the server address
- Filename:
The filename under which file sent will be saved on the server
- File size
The size of the file sent in bytes
- User name for the FTP server
- Password for the FTP server
- Number
Number of uploads



Editing the parameters




In the case of an upload test of less than 10 seconds, it is not possible to accurately determine the transmission speed.

Protocol dependent parameters

Protocol	PPPoE / PPPoA	IPoA / EoA
Parameter	ATM - VPI / VCI - Encapsulation	ATM - VPI / VCI - Encapsulation
	PPP - User name - Password	
	ADSL mode	ADSL mode

		WAN:
		- IP mode (Static IP) - own IP address - IP network mask - remote IP address
		DNS server:
		- DNS Server 1 - DNS Server 2

FTP upload test - starting



```
User name
83910235190700#0
0010t-online.de
ABORT DEL ab>AB
```

✓-Key

```
Password
*****
ABORT DEL ab>AB
```

✓-Key

FTP upload test

```
Ftp upload /
1/3
025% 128kb/s↓
ABORT
```

↓-Key

**Further
test results**

The ARGUS will display the user name stored for the ADSL profile.

If necessary, change the user name (for instructions, see Page 170)

If you change the user name, you must enter the password again (see Page 170).

The changes are placed in temporary storage. The ADSL profile is not modified.

After successfully initialising the test software, the FTP upload test is started automatically.

The ARGUS displays the following during the test:

In the example, the first upload of a total of three attempts (1/3) is shown. 25% of the data has already been sent.

The current upload rate is 5.62 Mbits per second.

Use the ↓-Key to scroll down to view the byte currently being sent, the total file size, how long the transfer has been in process (in hr:min:sec:msec) and the remaining time for the transfer.

Depending on the access mode and protocol, the LAN, WAN, PPP and ATM statistics will also be displayed (scroll through with the ↓-Key)

```
Ftp upload
LAN ETH packets:
Rx:1422 Tx:2180↓
← ADSL NEW
```

At the end of the test, the ARGUS will open the results display.

The ARGUS will display

- the achieved average speed of the Uploads (in kb/s)
- the minimum upload rate (in kb/s)
- the maximum upload rate
- the size of the file sent
- the average time for an upload
- statistics

(scroll with the ↓ -Key).
Press <NEW> to start a new upload test (without reinitialising).

```
Ftp upload
Save?
NO IP>PC YES
```

FTP upload - saving

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory (see "Automatic Test" on page 149 and Page 155)
Press <IP>PC >to upload the trace file to the PC.
The data will be saved in the standard "libpcap" format and can be decoded with a freeware tool, such as Etherreal.

```
Start another
test?
ADSL profile 5
NO EDIT YES
```

Any ADSL test desired can be started without reinitializing the ADSL test software.

Editing the parameters

9.1.9 ATM BERT

The ATM BERT (Bit Error Rate Test) serves to check the transmission quality of the ADSL line. In an ATM BERT, the ARGUS sets up an ADSL connection and sends a bit pattern via a virtual ATM channel that must be looped at the remote end.

The ARGUS compares the data received with the known data sent.

During the test, the ARGUS counts the bit errors and after the test is done it calculates the bit error rate as well as other characteristic values (see Page 105). In addition the ARGUS displays ATM cell statistics.

Protocol independent parameters (see Page 175):

- Duration of the BERT (default setting = 1 minute)
- ADSL mode
- VPI / VCI: Configuration of the virtual channel and the virtual path in the ATM cells
- Bit pattern: Selection of the bit pattern
- Error level: Level used to evaluate the "acceptable" bit error rate
- HRX value
- data rate (upstream)

ATM BERT - starting

```
ARGUS44Pi
ARGUS-ADSL
Voltage: 75.5V
MENU START
```

Status display

```
ARGUS44Pi ADSL
→Single tests
Automatic test↓
← + ✓
```

Using the <↓,>select the **Single tests** menu.

```
Single tests
→ATM BERT
-----↓
← + ✓
```

Using the <↓ > , select **ATM BERT**.

```
ADSL profile
*ADSL profile 1
ADSL profile 2↓
← EDIT ✓
```

Using the <↓>, select the ADSL profile.
Press <EDIT> to edit the profile (see Page 166)

```
ADSL line
Initializing ✓
G.DMT
ABORT
```

Synchronisation with the DSLAM and initialisation of the test software

ATM BERT

```
ATM BERT ✓
00:42:31 0
synchron LOS: ↓
ABORT ADSL ERROR
```

After successfully initialising the test software, the ATM BERT is started automatically.

During the test, the display shows:

Remaining test time in hr:min:sec, bit errors (in this case 0), synchronicity of the bit pattern, LOS-counter
Use the ↓-Key to scroll to the ATM statistics

Using <ERROR> generates a bit error artificially.

0 -Key: Restarts the BERT. The test time and number of bit errors will be reset.


```

ATM BERT
Result: 2048Kb
3 1,4E-06 OK↓
← ADSL NEW

```

↓-Key

```

Statistics:
ATM cells:
Rx: 39k Tx: 40k↓
← ADSL NEW

```

```

ATM BERT
Save?
NO YES

```

```

Start another
test?
ADSL profile 5
NO EDIT YES

```

After the test is completed, the ARGUS will display the following test results:

Transferred data in KBit (e.g. 2048 KB, K= 1024* bits),

The number of bit errors (e.g.3),

The bit error rate (e.g. $1.4E-06 = 1.4 \cdot 10^{-6} = 0.0000014$),

The evaluation of the results depends on the error threshold (in this case, OK).

Use <ADSL> display the ADSL mode,

ADSL line parameters... (see Page 43).

Use <NEW> to start a new ATM BERT.

Use the ↓ -Key to scroll to other results:

ATM cells (Rx: received cells, Tx: sent cells) OAM cells, User VCC, CRC32 errors , AAL5 PDVs, unmapped cells, VCI unm., VPI unm.

ATM BERT - saving

Press <YES> to have the ARGUS save the result in the first available record in the Flash memory (Page 149 and Page 155).

Press <EDIT> to edit the parameters of the displayed ADSL profile

(see Page 166)

Any ADSL test desired can be started without reinitializing the ADSL test software.

9.2 The ARGUS in Modem Replacement Mode


Access Mode: PC-ARGUS-ADSL (optional)

The ARGUS is connected to the PC with the (x-crossed) Ethernet cable and to the ADSL access with the black ADSL cable (Ethernet-LAN extension).

In this case, the ARGUS replaces the ADSL modem.

In the PC-ARGUS-ADSL access mode, the following tests can be performed:

- **Physical test (ADSL line test)**
- **Bridge mode**
- **Router mode**



Setting the device to the PC-ARGUS-ADSL access mode

```

ARGUS44Pi BRI
→Access
-----↓
←  +  ✓

```

In the Main menu, use the <↓> to select the **Access** menu.

```

Access:
→ADSL
S-Bus interfac↓
-----↓
←  +  ✓

```

Open the **Access** menu

Using the <↓>, select ADSL.

```

Access mode:
→PC-ARGUS-ADSL
-----↓
←  +  ✓

```

The Access Mode menu will open automatically:

PC-ARGUS-ADSL

the ARGUS will jump to the status display

```

ARGUS44Pi
PC-ARGUS-ADSL
Voltage: 75.5V
MENU START

```

The ARGUS displays the access mode and DC voltage on the access under test.



If the ARGUS is not yet active, you must first select a test and start it (see the following pages).

9.2.1 Physical test (ADSL line test)


The ARGUS will setup an ADSL connection and determine all of the relevant line parameters (see “Physical test (ADSL line test)” on page 43).

The following parameters must be set in the ADSL profile for the physical test (see “Configuring ADSL profiles” on page 166):


- Physic. line: ADSL mode, Link-up time, Rated value, SNR margin DS, Shutdown mode

9.2.2 Bridge mode

In Bridge mode, the ARGUS acts like an ADSL modem, i.e. the ARGUS passively passes all packets from the Ethernet side to the ADSL access (and vice versa). In this case, the PC is responsible for setting up the connection.



Setting the parameters:



In addition to the physical parameters (Physic. line), Bridge mode also requires that the two ATM parameters

- VPI/VCI (Page 176) and
- Encapsulation (Page 176)

be set.

Bridge mode - setting:

```

ARGUS44Pi
PC-ARGUS-ADSL
Voltage: 75.5V
MENU START

```

Status display

```

ARGUS44Pi ADSL
→Single tests
Automatic test↓
←  +  ✓

```

Using the <↓>, select the **Single tests** menu.

```

Single tests
→Bridge mode
Router mode ↓
←  +  ✓

```

Open the **Single tests** menuUsing the <↓>, select **Bridge mode**.

```

ADSL Profile
*ADSL profile 1
ADSL profile 2↓
←  EDIT  ✓

```

Using the <↓>, select an **ADSL profile**.

Press <EDIT> to modify the parameters.

```

ADSL line
Initializing ✓
G.DMT
ABORT

```

Initializing the ARGUS

```

Bridge mode
Initializing ✓
ABORT ADSL

```

Initialising the software

```

Bridge mode
Active!
Elapsed00:15:21
ABORT ADSL

```

Press the <ADSL> or Level-Key to display the ADSL mode, ADSL line parameters... (see "Physical test (ADSL line test)" on page 43).

Deactivate Bridge mode.

```
Bridge mode
Aborted
ABORT IP>PC
```


Use <IP>PC> to download the two trace files (LAN and WAN side) to the PC.

The data will be saved in the standard "libpcap" format and can be decoded with a freeware tool, such as Etherreal.

9.2.3 Router Mode

In Router mode, the ARGUS replaces not only the modem but also the router. In this case, several PCs (connected via a hub/switch) can access the connection to the network provider.

The network IP addresses can either be assigned statically or the ARGUS can serve as a DHCP server and assign IP addresses to the connected PCs.



Protocol dependent parameters

Parameter settings in an ADSL profile, see Page 166

Protocol	PPPoE / PPPoA	IPoA / EoA
Parameter	ADSL mode	ADSL mode
	ATM: - VPI / VCI - Encapsulation	ATM: - VPI / VCI - Encapsulation
	PPP: - User name - Password	
	LAN: - IP mode - own IP address - IP network mask	LAN: - IP mode - own IP address - IP network mask - IP mode - DHCP server - DHCP timeout

	<p>WAN:</p> <ul style="list-style-type: none"> - IP mode (Static IP) - own IP address - IP network mask - remote IP address - DHCP timeout
	<p>DNS server:</p> <ul style="list-style-type: none"> - DNS Server 1 - DNS Server 2

Router mode - setting:

```
ARGUS44Pi
PC-ARGUS-ADSL
Voltage: 75.5V
MENU START
```

Status display: The ARGUS displays the access mode and the DC voltage on the access under test.

```
ARGUS44Pi ADSL
*Single tests
Automatic test↓
← + ✓
```

Use the <↓> to select the **Single tests** menu.

```
Single tests
*Router mode
-----↓
← + ✓
```

Using the <↓ >, select **Router mode**.

```
ADSL profile
*ADSL profile 1
ADSL profile 2↓
← EDIT ✓
```

Using the <↓ >, select the **ADSL profile**. Press <EDIT> to modify the parameters.

```
ADSL line
Initializing ✓
G.DMT
ABORT
```

Initialising the ARGUS


```
Router mode
Initializing
ABORT ADSL
```

Initialising the software

```
Router mode
Active!
Elapsed00:11:48
ABORT ADSL
```

Press the <ADSL> or Level-Key to display the ADSL mode, ADSL line parameters... (see "Physical test (ADSL line test)" on page 43).

Deactivating Router mode

```
Router mode
Aborted
ABORT IP>PC
```

Use <IP>PC> to download the two trace files (LAN and WAN side) to the PC.


The data will be saved in the standard "libpcap" format and can be decoded with a freeware tool, such as Etherreal.

9.3 The ARGUS in PC Replacement Mode

Access Mode: ARGUS-MODEM (optional)

In PC replacement mode, the ARGUS serves as a replacement for the PC and is connected to the ADSL modem's Ethernet interface with the Ethernet cable (blue) (Ethernet-LAN extension).


Connection to the modem:



ADSL profile settings:

- Protocol: PPPoE
- PPP parameters: User name and Password


Connection to the router/modem:



ADSL profile settings:

- Protocol: IP
- LAN: IP mode, own IP address (Static IP), IP netmask (Static IP), Gateway-IP (Static IP under PPOE and PPPoA)
- DNS server: DNS Server 1 (Static IP under PPOE), DNS Server 2 (Static IP under PPOE)


Connection to a PPTP router/modem:



ADSL profile settings:

- Protocol: PPTP
- PPTP: IP address of the PPTP modem
- PPP: User name and Password


Connection to PC via IP



ADSL profile settings:

- Protocol: IP
- LAN: IP mode, own IP address (Static IP), IP netmask (Static IP), Gateway-IP (Static IP)
- DNS server: DNS Server 1, DNS Server 2

Connection to IP network




ADSL profile parameter settings:

- Protocol: IP
- LAN: IP mode, own IP address (Static IP), IP netmask (Static IP), Gateway-IP (Static IP)
- DNS server: DNS Server 1, DNS Server 2

In the ARGUS-MODEM access mode, the following tests can be performed:

- Ping test (see Page 50)
- Trace route test (see Page 56)
- Download test (see Page 61)
- FTP upload test (see Page 75)

ARGUS-MODEM access mode settings



10 Tests on an ISDN Access

10.1 Test the Supplementary Services

The ARGUS checks whether the access under test supports supplementary services in 1TR6 or DSS1 protocol.

10.1.1 Suppl.serv.test for the 1TR6 protocol

```
ARGUS44Pi BRI
→Single tests
Test manager ↓
←  +  ✓
```

Using the <↓> in the Main menu, select the **Single tests** menu

Open the **Single tests** menu

```
Single tests
→SUPP.serv.test
Service test ↓
←  +  ✓
```

Using the <↓>, select **Suppl.serv.test**.

Start test

```
Sup.serv.req.1TR6
1TR6 SS test
←  +  ✓
```

```
SUP.serv.req.1TR6
Sperre +
AWS 1 - ↓
←  +
```

The test results are displayed automatically:

+ = suppl. service supported

- = suppl. service not supported

Using the <↓>, scroll through the test results

The ARGUS will return to the

Sperre	Blocking enabled for outgoing calls
AWS1	Call forwarding type 1 enabled (continuous)
AWS2	Call forwarding type 2 enabled (case by case)
Anschluss GBG	Access belongs to a Closed Users Group
Geb.anzeige	Advice of charge
Rufnummern- Id	Setup call number identifier - against malicious calls

10.1.2 Suppl.service interrogation in DSS1

```

Single tests
→Supp.serv.test
Service test ↓
┌───────────┴───────────┘
←           ↓           ✓

```

In the Single tests menu, Using the <↓>, **select** Supp.serv.test.

```

Numbers
Own number
0235190700
┌───────────┴───────────┘
←           DEL           ✓

```

Use the keypad to enter the "Own number" or select it (the number of the access under test) from the speed-dialing memory (see Page 197). The ARGUS will test the availability of the supplementary service (in part by placing a call to itself).

```

Select service
→Tel.ISDN
Fax G3 ↓
ABORT ↓ ✓

```

Using the <↓>, select the service which should be used for the supplementary services test.

```

B channel select
Active B ch.: 2
Ch.available !
┌───────────┴───────────┘
←           DEL           ✓

```

Confirm the service

Enter the B-channel on the keypad. By default, the channel last used will be suggested. If you enter an *, the ARGUS will choose any B-channel that is free.

```

SUPP. Serv. test
→TP test
HOLD test ↓
┌───────────┴───────────┘
←           ↓           ✓

```

Confirm the B-channel

Using the <↓> select the supplementary service (e.g. TP) that you want the ARGUS to check whether the access under test supports.

```

SUPP. Serv. test
TP test +
-----
┌───────────┴───────────┘
←           ↓           ✓


```


Start test


The ARGUS will automatically display the test results:

- + = suppl. service supported
- = suppl. service not supported

Using the <↓> scroll through the test results.

If you press the <  >, the ARGUS will return to the previous display (this applies for all displays)

Test	Comments
TP	The ARGUS tests the TP (Terminal Portability) supplementary service by making a self call.
HOLD	The ARGUS tests the HOLD supplementary service by making a self call.
CLIP (CLIP , CLIR , COLP , COLR)	<p>In this test, the ARGUS checks whether the 4 supplementary services CLIP, CLIR, COLP and COLR are supported. To do so, the ARGUS will setup as many as three calls to itself.</p> <p>CLIP: Will the calling subscriber's number be displayed at the called subscriber? (t = CLIP temporarily available p = CLIP permanently available)</p> <p>CLIR: Will the display of the calling subscriber's number at the called subscriber be suppressed or is it possible to temporarily suppress the display? If the ARGUS displays an *, it is not possible to determine the availability of the service, since no CLIP has been setup. (t = CLIR temporarily available p = CLIR permanently available)</p> <p>COLP: Will the call number of the subscriber who answered be displayed on the caller's phone?</p> <p>COLR: Will the display of the call number of the subscriber who answered be suppressed on the caller's phone or is it possible to temporarily suppress the display? If the ARGUS displays an *, it is not possible to determine the availability of the service, since no COLP has been setup.</p> <p></p> <p>The suppl. services pairs CLIP and CLIR as well as COLP and COLR will be tested. If CLIR or COLR is setup permanently, it is not possible to make a clear assessment.</p>
DDI	Can a caller directly dial in to an extension on the PBX access under test?
MSN	Is the supplemental service MSN available?


<p>CF (CFU, CFB, CFNR)</p> 	<p>In this test, the ARGUS checks the 3 supplementary services CFU, CFB and CFNR one after the other to determine whether they are supported on the access under test.</p> <p>CFU: Can this access immediately forward an incoming call?</p> <p>CFB: Can this access forward an incoming call when it is busy; in other words does it support Call Forwarding Busy?</p> <p>CFNR: Can this access forward an incoming call when it is not answered?</p> <p>The CF test attempts to setup a call diversion to the call number that is in the memory location for "remote call number 1" (see "Saving Call Numbers" on page 197). The CF test cannot be performed, if this location does not contain a valid call number to which it is possible to divert a call.</p>
CW	Does the access under test support call waiting?
CCBS	Will the access under test automatically recall a remote subscriber, if the number called was busy?
CCNR	Will the access under test automatically recall a remote subscriber if the call was not answered?
MCID	Does the access tested allow identification of malicious callers (call tracing)?
3pty	Does the access under test support a three-party conference call? For this test, you need the assistance of a remote subscriber, whose call number must be entered.
ECT	Is an explicit call transfer supported by the access under test? For this test, you need the assistance of a remote subscriber, whose call number must be entered.

AOC	The ARGUS checks whether the charges can be sent to the access under test. The test uses a call to oneself to check both AOC-D (AOC during a call) and AOC-E (AOC at the end of a call).
SUB	A call is made to oneself and answered to check the transfer of the sub-address in both directions. Are sub-addresses supported on the access under test?
UUS	Does the access under test support the transfer of user data?
CUG	The ARGUS then uses a self call to check whether the access under test belongs to a closed user group.

10.1.3 Error messages



If an error occurs during the Supplementary Services Tests or if it is not possible to setup a call, the ARGUS will display the corresponding error code (e.g. 28). Use the <↓> to scroll further.



In the example, the error belongs to the error class "wrong or invalid number".

In the table below, you will find that this is an error from the network and that it reports that the call number was incomplete or in the wrong call number format (see "CAUSE-Messages – DSS1 Protocol" on page 211.).

Distributing the error codes into error classes:

Error class	Description	Cause network			Cause ARGUS internal
		1 TR6	DSS1	(from DSS1)	
A	No or another access	—	—	—	201,204,205, 210,220
B	Wrong or invalid number	53, 56	1,2,3,18,21 22,28,88	—	152,161,162, 199
C	One or more B-channels busy	10,33,59	17,34,47	—	—
D	Wrong service	3	49,57,58,63 65,70,79	—	—

For further information regarding error codes: "ARGUS Error Messages" on page 215, "CAUSE-Messages – DSS1 Protocol" on page 211 and "CAUSE-Messages – 1TR6 Protocol" on page 213.

10.2 Service check

The ARGUS checks, which of the following services are supported by the access under test:

Service	Name in the ARGUS display / abbreviation
Language	Language / Lang
Unrestricted Digital Information	UDI 64kBit / UDI 64
3.1 kHz Audio	Tel.analog / Tel.
7 kHz Audio	7 kHz audio / 7 kHz
Unrestricted Digital Information with tones / Display	UDI+TA / UDI TA
Telephony	Tel.ISDN / Tel.
Facsimile Group 2/3	Fax G3 / FaxG3
Facsimile Group 4 Class 1	Fax G4 / FaxG4
Teletex service basis and mixed mode and facsimile service Group 4 Classes II and III	Mixed Mode / Mixed
Teletex Service basis mode	Teletex / Ttx64
International inter working for Videotex	Videotex
Telex	Telex
OSI application according to X.200	OSI
7 kHz Telephony	Tel.7kHz / Tel7k
Video Telephony, first connection	Videotel.1 / Vid.1
Video Telephony, second connection	Videotel.2 / Vid.2
Three user-specific services (optional) (see "Services" on page 182.)	Userspec.1 / Userspec.2 / Userspec.3 /

The test runs automatically.

For each service, the ARGUS will place a call to itself (to the access under test). However, the call will not be answered so no charges will be incurred.

```
Single tests
→Service test
  Bit error test↓
  ←      ↓      ✓
```

In the Single tests menu, use the <↓> to select **Service check**

```
Numbers
Own number
0235190700
  ←      DEL      ✓
```

Enter the **Own number** of the access under test



There are PBXs that use separate call numbers for incoming and outgoing calls.

In this case, for the Service checks, you can enter a “**remote**” call number that corresponds to the “own” number that is not stored in the ARGUS.

If the Service check should extend outside of the local exchange, it is possible to perform the Service check in an **end-to-end mode**.

In this case, you **must** enter the remote call number for a second terminal device.

The ARGUS will then automatically check whether the remote terminal can accept the call under the various services – in other words, whether it is “compatible” with these services.

In the test results, the second part (second +, - or *) refers to the answer from the **remote** exchange.

Test results:


```

Service check
Speech      ++
UDI 64 kBit++ ↓
  
```

The ARGUS will display the results of the test once it is done.

Use the <↓> to scroll through the test results.

The ARGUS makes a distinction between outgoing calls (the first +, - or *) and incoming calls (the second +, - or *).

+ = Service supported

- = Service not supported

* A definite statement cannot be given, see the adjacent error code for the reason.

Interpreting the test results:

Displayed	Description
+ +	The self call functions OK or the remote end can take the call for this service
+ -	Call was sent successfully, however, it was rejected on the remote end due to missing authorization. (Error class D in a B-channel message e.g. in a SETUP_ACK or CALL_SENT)
-	An outgoing call with this service is not possible (Error class D without a B-channel message)
+ *	Call was sent successfully, the call back or call to the remote end failed (e.g., remote end busy or no B-channel available for the call back). (Error class B, C or E in a B-channel message)
*	Wrong number, no B-channel available or other error (Error class B, C or E without a B-channel message)

If the outgoing call is not successful, it is **not** possible to make a statement about an incoming call. Therefore, you will never see “- +” or “- *” on the display.

Example:

```
Service check
Fax G3      ++*63
Fax G4      ++ ↓
┌───┬───┐
│   │   │
```

For outgoing, the Fax G3 service is OK. No statement is possible about incoming.

The error code 63 indicates the cause of the error which has occurred

(see tables in appendix).

In this case, it is recommended that you have someone place a call to the access under test using this service.

Fax G4 service is supported in both directions.

If an error of error class A occurs (see "Error messages" on page 98.) the Service test will be aborted.

An error of any other error class will coded in decimal (in the example above 63), assigned to the respective service and then displayed.

10.3 Bit error test

The bit error rate test (BERT = Bit Error Rate Test) serves to check the transmission quality of the access circuit.

As a rule, the network operator will guarantee an average error rate of 1×10^{-7} , in other words in long-term operation 1 bit error in 10 million transmitted bits. A higher bit error rate will be especially noticeable in transmitting data.

The application program detects the errors in the data blocks transmitted and requests that the remote partner send them again, which reduces the effective throughput of the ISDN connection.

In the bit error test, the tester establishes an ISDN connection to a remote tester or places a call to itself, sends a standardized (quasi-) random number string and compares the received data with that which was sent. The individual bit errors are summed and depending on the test procedure and equipment evaluated in accordance with the ITU Guideline G.821.

During the test, the ARGUS counts the bit errors and after the test is done it calculates the bit error rate and other parameters in accordance with G.821.

Since the bit error test checks both B-channels in both directions at the same time, both B-channels are required.

As a rule, the quality of the network operator's access circuits is quite good. Therefore, no bit errors should occur in a 1-minute test.

However, if an error occurs, the test should be repeated with a measurement time of 15 minutes to achieve higher statistical precision. The access circuit is heavily distorted, if more than 10 bit errors occur within a test period of 15 minutes.

Contact the network operator or the supplier of the PBX equipment and ask them to test your access circuit.

The BERT can be performed in three different ways:

1. BERT in an extended call to oneself

A remote number is not needed, since the ISDN connection is setup to oneself. In this case, the ARGUS requires two B-channels for the test.

2. BERT with a loopbox

A loopbox (e.g., another member of the ARGUS family of testers at the remote end) is required.

The test uses one B-channel.

3. BERT end-to-end

This test requires a waiting remote tester such as an ARGUS in the **BERT wait mode** (see Page 111). A bit pattern is sent to this tester.

Independent of the received bit pattern, the remote tester uses the same algorithm to generate the bit-pattern that it sends back.


Therefore, both directions are tested independently.

10.3.1 Start BERT

The following parameters are required for the BERT:

- **Duration of the BERT** (default setting = 1 minute)
- **Error level:** If the bit error rate exceeds this limit, the ARGUS will display the test result NO. If the bit error rate is less than this limit, the ARGUS will display an OK (default setting = 10^{-05})
- **HRX value** in % (hypothetical reference connection see ITU-T G.821) (default setting = 15%)
- **Bit pattern**, which will be sent during the test (default setting = $2^{15}-1$)

The parameters can be set individually and saved (see Configuration menu Page 184).



BERT start

```
BERT 2^15      B02
15:45:42      3
synchron LOS: 5
ABORT TM ERROR
```

After the ARGUS has setup the connection and synchronized the send and receive directions, it will display the bit pattern, the B-channel used (e.g. B02), the remaining test time in h:min:sec, the number of bit errors that have occurred (e.g. 3), the synchronicity of the bit pattern (synchronous or asynchronous) and the LOS-counter.

If you press **<ERROR>**, the ARGUS will generate an artificial bit error, which can be used to test the reliability of the measurement (in particular for end-to-end tests).

Using the **<TM>** **softkey**, Start Test Manager (see Page 144)

Press **<ABORT>** to stop the BERT

0 -Key: Restarts the bit error test. The test time and number of bit errors will be reset.



When a bit error is detected, this will be signaled by a brief alarm; in the event that the synchronisation is lost, a constant alarm will sound ((see page 196 Alarm bell)).

```
Call clearing
Active clearing
Loc.: user
CONT.
```

After the test time is over, the ARGUS will display the cause and the location which initiated the disconnect.

If the test ran normally, the ARGUS will display "Active clearing" on this line.

```
BERT 2^15      B02
Result: 10309Kb
      10 9,7E-07 OK
MENU  TM  MORE
```

The test results display:

The bit pattern (e.g. 2¹⁵),
B-channel used (e.g. 02),
Transferred data in KBit (e.g. 10309 KB, K= 1024* bits),

The number of bit errors (e.g.10),

The bit error rate (e.g. 9.7E-07 = 9.7·10⁻⁷ = 0.00000097),

The evaluation of the results depends on the error threshold (OK).

<MENU>: The ARGUS returns to the BERT menu.

```
BERT 2^15      B02
HRX G821: 15% OK
EFS : 93,75%↓
MENU  TM  SIMPLE
```

Display of other characteristic values (in accordance with ITU-T G.821)

All values are given in percentages.

The ARGUS evaluates whether the test results satisfy the limits specified in the CCITT G.821 with consideration of the reference connection HRX (displaying OK or NO).

↓ -Key: Scroll

```
BERT 2^15      B02
Result: 10309Kb
      10 9,7E-07 OK
MENU  TM  MORE
```

<MENU>: The ARGUS returns to the BERT menu.

HRX Defines the hypothetical reference connection

EFS *Error Free Seconds*

All the seconds in which no error occurred.

ES821 *Errored Seconds*

All the seconds in which one or more errors occurred.

SES821 Severely Errored Seconds

All the seconds in which the bit error rate is $>10^{-3}$.

In one second, 64,000 bits are transferred, thus

BitError = 10^{-3} equates to 64 bit errors.

US Unavailable Seconds

All the sequentially adjacent seconds (at least 9 sec) in which **BER** $>10^{-3}$.

AS Available Seconds

All the sequentially adjacent seconds (at least 9 sec) in which **BER** $<10^{-3}$.

DM Degraded Minutes

All the minutes in which the bit error rate is $>10^{-6}$. In one minute, 3,840,000 bits are transferred, thus a **BER** = 10^{-6} corresponds to 3.84 bit errors (3 errors = NO (no DMs), 4 errors = OK (DM)).

LOS Loss of Synchronisation

Synchronisation is lost at an error rate $>$ or $=$ 20% within a second. The absolute number of synchronisation losses will be shown.


10.3.2 BERT - saving

The ARGUS can store the results of several BERTs.

The ARGUS saves the results together with the date, time and call number of the access under test (if this number has been entered as the "own" number in the speed-dialing memory) under the next free record number (see Page 149).

If all of the records are used, the ARGUS will return to the Autom. Test dialog and request permission to overwrite the oldest test results.

```
BERT          B02
Result: 10309Kb
          10 9,7E-07 OK
MENU  TM  MORE
```


Press the  .

```
Save
result?
NO      YES
```

Press <YES> **BERT - saving**

```
save as:
AMP_5
ABORT DEL 3b>AB
```

Using the numeric keys enter the name under which the result should be saved (Default: AMP_1, AMP_2.... or the call number of the access under test if the number has been entered into the speed-dialing memory)

 -Key

When the right softkey is pressed it assumes a different meaning and thus influences the entries made from the keypad (letters or digits):

<12>ab> : entry of the digits 0 to 9 plus * and #

<ab>AB> : entry of the lowercase characters and @, /,- and .

(e.g. to enter a "c" press the "2" on the keypad three times)

<AB>12> : entry of the uppercase characters and @, /,- and .

```
Bit error test
->BERT start
BERT wait      ↓
←      ↓      ✓
```

To move the cursor right or left, use the ↑,↓-Keys.
Press to delete the digit before the cursor.

10.3.3 Displaying the stored results

```

ARGUS44pi BRI
→Automatic tests
Level measurin↓
←  ↓  ✓
    
```

Using the <↓> in the Main menu, select **Automatic Tests** .

```

Auto test
→ 1 0235190700
  2 907090 ↓
← NUMBER ✓
    
```

Use the <↓> to select the record with the saved BERT results

```

Auto test No.: 2
→Display result
Test data to P↓
←  ↓  ✓
    
```

Use the <↓> to select **Display result**.

```

Auto test No.: 2
B12
P-P TE DSS1
ABORT CONT.
    
```

The ARGUS will first display the status of the access under test.

```

BERT B02
Result: 10309Kb
10 9.7E-07 OK
MENU TM MORE
    
```

Display of the saved results
(see Page 155).

10.3.4 Bert wait

In **BERT wait** mode, the ARGUS will wait for the BERT at the remote end which is necessary for an end-to-end test:

```
Single tests
→Bit error test
X.31 test ↓
← + ✓
```

In the Single tests menu, using the <↓>, **select Bit error test.**

```
Bit error test
→BERT wait
B channel loop↓
← + ✓
```

Using the <↓>, **select BERT wait.**

```
BERT
Wait active
ABORT TM MENU
```

Activate "BERT wait"

The ARGUS first waits for a call and then sets up the connection.

During the connection, the received bit pattern will be evaluated and in addition another independent bit pattern will be sent.

If you press <MENU>, the ARGUS will return to the Main menu; the test "BERT wait" remains active. In the Main menu, if <TM> is pressed, the ARGUS will return to the display "BERT, Wait active", see Page 148.

<TM>: Calls the Test

**Operating
mode
BERT wait**

Manager (Page 144)

The ARGUS displays that will appear are the same as those in Chapter 10.3.1 Start BERT .

10.3.5 B-channel loop

B-channel loop mode is required in order to run a bit error test using a loopbox at the remote end as well as to test permanent circuits.

```
Bit error test
→B channel loop
-----↓
←  +  ✓
```

Using the <↓>, select **B-channel LOOP**.

Activate the "B-channel LOOP"

```
B-channel-LOOP
Wait active
ABORT TM MENU
```

The ARGUS will wait for a call. Any incoming call (regardless of the service) will be taken immediately.

The ARGUS will switch a loop back in the B-channel that is specified by the exchange and then send the received bit pattern back to the caller/sender.

**Operating mode
B-channel**

If you press <MENU>, the ARGUS will return to the Main menu; the test "B-channel-LOOP " remains active. In the Main menu, if <TM> is pressed, the ARGUS will return to "B-channel-LOOP, Wait active", see Page 148. From this menu, you can start a second B-channel loop connection (this is also possible using <TM>).

<TM>: Call the Test Manager

If the ARGUS takes a call, it will open the B-LOOP connect. window, which is similar to the normal connection window:

```
B-channel-LOOP
235190700 B01
to: 907070 ↓
ABORT TM MENU
```

The ARGUS will display the caller's number (e.g. 235190700) , the B-channel used (e.g. B01) and the number dialed (e.g. 907070).

↓ -Key: Display additional information (e.g. UUS...)

**B-channel loop
Connection
stop**
Operating mode
B-channel LOOP
still active

<TM>: Open the Test Manager

<Menu:> The ARGUS returns to the main menu.

10.4 X.31 Test

The ARGUS will either perform a “Manual X.31 Test” or an “Automatic X.31 Test”:

In the case of an automatic test, the ARGUS will first setup the D-channel connection and then begin setting up the X.31 connection. Afterwards, the ARGUS will automatically clear the connection and display the results.

In the case of a manual test, the ARGUS will setup a D-channel connection and an X.31 connection. The duration of this connection is determined by the user (or the opposing end). For the duration of the connection, the ARGUS will repeatedly send a predefined data packet. The ARGUS will count all of the data packets sent and received and will display (where possible) the contents of the data packets received.

Optional: Several parameters can be configured and saved in three different X.31 profiles for the X.31 test (Page 190). Depending on the test variant, the ARGUS will retrieve and use the stored parameters. Values such as TEI and LCN will be shown as default values in the display.

10.4.1 Automatic X.31-Test

There are three possible variants of the Automatic X.31 Test:

1) D-channel

The “X.31 Automatic, D-channel” test consists of two steps:

First step: The ARGUS tests whether it is possible to access the X.25 service via the D-channel on the BRI access under test.

The ARGUS sequentially checks all the TEIs from 0 to 63. All the TEIs with which the X.31 service is possible on Layer 2, will be displayed.

Second step: For each TEI with which X.31 is possible on Layer 2, a CALL_REQ packet will be sent and then the ARGUS will wait for an answer.

Beforehand, the ARGUS will request the entry of the X.25 access number, which will be saved in speed-dialling memory under **X.31 test**

number ("Saving Call Numbers" on page 197).
 With the entry of the X.25 access number, you can - if you wish - select a logical channel (LCN) other than the default.

```
Single tests
→X.31 test
  CF interrogat.↓
←      +      ✓
```

In the Single tests menu, use <↓> to select the **X.31 test**.

```
X.31 Profile
→.31 Profile 1
X.31 Profile 2 ↓
←      EDIT  ✓
```

Select the profile.
 Press <EDIT> to open the menu for editing the X.31 parameters in the profile (see Page 190).

```
X.31 test
→Automatically
  Manual ↓
←      +      ✓
```

Use <↓> to select **Automatically**.

```
X.31 automatic
→D channel
  B chan. case A↓
←      +      ✓
```

Using the <↓>, **select the D channel**.

```
X.31 test
TEI: 03 02 +
ABORT
```

Start test
 The test can take up to 4 minutes (a rotating bar will be displayed). Beginning on the left, the ARGUS will display the TEI currently being tested followed by the one previously tested and its result:
 + = X.31 is available for this TEI
 - = X.31 is not available for this TEI

```
X.31 test
TEI:02++
TEI:03+- 13 67
ABORT
```

After the test is completed, the ARGUS will show whether the X.31 service is available for Layer 3 for the TEIs found in Step 1. Using the <↓>, scroll through

the results.

Test results:

TEI 02 = the first valid TEI value is 02.

+ + = Both test steps were successful

+ - = the first test step was successful, the second step not In this case, the ARGUS will display the relevant X.31 cause for the failure (in the example above: 13) and an associated diagnostic code (in the example: 67), if there is one (see "X.31 Test – Error messages" on page 216.).

If the X.31 service is not supported, the ARGUS will report "x.31 (D) n. impl."

2) B-channel case A (optional)

For this X.31 test variant, the ARGUS requires the entry of a call number for the D-channel connection, a B-channel and the X.31 number ; The ARGUS will use the number saved in profile as the default value (see Page 190) and the "X.31 test number" from the speed-dialling memory (see Page 197).).

The ARGUS will first setup a D-channel connection and then attempt to set up a X.31 connection on the B-channel.

```
Single tests
→X.31 test
  CF interrosat.↓
←  +  ✓
```

In the Single tests menu, Use the <↓> to **select X.31 test**.

```
X.31 Profile
→.31 Profile 1
X.31 Profile 2 ↓
←  EDIT  ✓
```

Select the profile.

Press <EDIT> to open the menu for editing the X.31 parameters in the profile (see Page 190).

```
X.31 test
→Automatically
  Manual ↓
←  +  ✓
```

Use <↓> to select **Automatically**.

```
X.31 automatic
→B chan. case A
  B chan. case B↓
←  +  ✓
```

Using the <↓>, **select B chan. class A**.

```
Numbers
Dest. number 1
02351907070 ↓
←  DEL  ✓
```

Entry of the call number for the D-channel connection

```
B channel select
Active B ch.: 2
Ch.available !
←  DEL  ✓
```

Selecting a B-channel

```
LCN:
1
ABORT DEL ✓
```

The ARGUS displays the LCN stored in the profile. It is possible to edit the LCN from the keypad.

```
Numbers
X.31 test no.
08154711 ↓
←  DEL  ✓
```

Display of the X.31 number from in the speed-dialing memory. It can be edited from the keypad.

```
X.31 test
X.31 (B) avail.
ABORT
```

Start test

Test successfully completed In the event of an error, the X.31 cause and a diagnostic code will be displayed.

If the test fails, because the ARGUS cannot setup a D-channel connection, a corresponding message will be displayed.

3) B-channel case B (optional)

This test is identical with the “B chan. case A” test, except that it is not necessary to enter a D-channel call number.

The ARGUS will first setup a D-channel connection (via the service) and then attempt to set up a X.31 connection on the B-channel.

10.4.2 Manual X.31 Test

There are three possible variants of the Manual X.31 Test:

1) D-channel

In this test variant, the ARGUS first requests a TEI, LCN and an X.31 number (The ARGUS uses the values stored in the profile as default values - see Page 190).

If a " ** " is entered for the TEI, the ARGUS will automatically determine a TEI.

Using the first TEI with which X.31 is possible, the ARGUS will begin to setup a connection.

```
Single tests
→X.31 test
CF interrogat.↓
←  +  ✓
```

In the Single tests menu, use <↓> to select the **X.31 test**.

```
X.31 Profile
→.31 Profile 1
X.31 Profile 2 ↓
←  EDIT  ✓
```

Select the profile.

Press <EDIT> to open the menu for editing the X.31 parameters in the profile (see Page 190).

```
X.31 test
→Manual
-----↓
←  +  ✓
```

With the <↓>, select **Manual**.

```
X.31 manual
→D channel
B chan. case A↓
←  +  ✓
```

With the <↓>, select the **D-channel**.

```
TEI:
   02
(** = automat.)
ABORT DEL  ✓
```

The ARGUS displays the TEI stored in the profile.

You can edit the TEI from the keypad;

If you enter **, the ARGUS will automatically determine a TEI.

: Delete the TEI

```
LCN:
1
ABORT DEL ✓
```

The ARGUS displays the LCN stored in the profile. It is possible to edit the LCN from the keypad.

```
Numbers
X.31 test no.
08154711 ↓
← DEL ✓
```


Display of the saved X.31 number (speed-dialing memory). It can be edited from the keypad.

```
X.31 (D) Connect
LCN: 1 TEI: 2
026311000091258↓
ABORT STAT. DATA
```

Setup a X.31 connection

The ARGUS will display the LCN, TEI and X.31 number (e.g. 0263110 00091258).

<DATA> sends predefined data packets (The number depends on the parameter "Packet number" see Page 191)

-Key to display additional information (if made available by the exchange).

Use <STAT.> to display L1/L2/L3 statistics.

The display will begin with the L1 statistics.

Use <L2> or <L3> to scroll to the L2 or L3 statistics.

The connection will be maintained until the user or the opposing end clears it. When the X.31 connection is cleared, the ARGUS will automatically clear the D-channel connection.

```
X.31 (D) test
save?
NO YES
```

The ARGUS saves the results.

For information on displaying the saved test results, see Page 155.

2) B-Channel - Case A (optional)

For this test variant, a D-channel call number and a X.31 number must be entered.

The ARGUS will first setup a D-channel connection.

```
X.31 (B) Connect
LCN: 1 TEI: 2
026311000091258↓
ABORT HEX DATA
```

Once the D-channel connection has been setup, the ARGUS will setup a X.31 connection via a B-channel: Use the ↓ to scroll.

```
X.31 (D) Abort
Cause: 0
Diag: 0
CONT.
```

If the X.31 connection cannot be setup, the ARGUS will automatically clear the D-channel connection. In this case, the ARGUS will display the X.31 cause and the associated diagnostic code (see Page 216).

Once a connection has been successfully setup, the ARGUS will send the number of data packets that was set in the parameter "Packet number" Page 191.

The ARGUS will count all of the data packets sent and received and will display (where possible) the contents of the data packets received.

For instructions, see "1) D-channel" on page 113.

3) B-channel case B (optional)

This test is performed in the same way as the "B-Channel Case B" test, except that it is not necessary to enter a D-channel call number.

10.5 CF Interrogation

The ARGUS will check whether - for the access under test (BRI or U-Interface: optional) - a call diversion has been setup in the exchange.

The ARGUS will show the type of diversion (CFU, CFNR or CFB) and the call diversion's service. The display is limited to a maximum of 10 call diversions for all of the MSNs. The ARGUS will count any additionally setup call diversions.

Any call diversion setup in the exchange can be cleared with the ARGUS.

```
Single tests
*CF interrogat.
CF activation ↓
← + ✓
```

In the Single tests menu, use the <↓> to select **CF interrogat.**

Start CF interrogation.

The test can take several seconds.

```
CFU Spch 3/09
2351919658
14418 ↓
ABORT DEL NEW
```

The ARGUS displays the type (e.g. CFU) and service (e.g. Spch) of the call diversion, which in this example is the third of a total of nine found (3/09).

The number 2351919658 is diverted to 14418.

The ↓-Key is used to scroll through the display.

Press <NEW> to repeat the CF interrogation.

Delete call diversion

Security query

```
CFU Spch 3/09
2351919658
Delete CF?
ABORT YES ALL
```

Press <ALL> to delete all call diversions.

The ARGUS will delete the displayed number in the exchange.

```
Diversion/s
deleted!
CONT.
```

If the call diversion cannot be cleared, the ARGUS will report: "Call diversion not changeable!".



Some PBXs or exchanges do not permit the use of the mechanism used (by the ARGUS) for the interrogation of the call diversions for all MSNs or they return a negative acknowledgement of the interrogation of call diversions, implying that no call diversions have been setup.

In the event of a negative acknowledgement, the ARGUS will, therefore, request that the **Own** MSN be entered.

The call diversion interrogation will be repeated **MSN-specific**.

Naturally, in this case, the results of the interrogation of the call diversion only apply for the entered MSN and **not** for the entire access.

Abbreviations used for the services and service groups on the display:

Basic Service	Abbreviation
All services	All
Voice (speech)	Spch
Unrestricted digital information	UDI
Audio 3.1 kHz	A3k1H
Audio 7 kHz	A7khz
Telephony 3.1 kHz	Te131
Teletext	TTX
Fax Group 4	FaxG4
Video syntax based	ViSyB
Video Telephony	ViTel
Telefax Groups 2/3	FaxG3
Telephony 7 kHz	Te17
UDI 64 kBit	UDI
Unknown Basic Service	Unkno

10.6 CF - Activation

Using the ARGUS, call diversions can be setup in the exchange (BRI or U-Interface).

```
Single tests
→CF activation
CF delete ↓
← + ✓
```

In the Single tests menu, use the <↓> to select **CF activation**.

```
Select service:
*Spch
UDI ↓
← + ✓
```

Using the <↓>, select the service of the call diversion (e.g. SPch).

```
Select CFx type:
*CFU
CFB ↓
← + ✓
```

Using the <↓> select the type of call diversion (e.g. CFU).

```
Numbers
Own number
0235190700
← DEL ✓
```

Under "Own number", enter the number which should be diverted.

Press to delete the digit before the cursor.

```
Numbers
Dest. number 1
02351907070 ↓
← DEL ✓
```

Enter the number to which calls should be diverted.

```
Call diversion
activated
CONT.
```

Setup the call diversion

```
Single tests
→CF activation
CF delete ↓
← + ✓
```

The ARGUS returns to the Single tests menu.

10.7 CF - Delete

Using the ARGUS, selected call diversions can be deleted/cleared in the exchange (BRI or U-Interface: optional).

```
Single tests
→CF delete
  MSN interrogat↓
←  +  ✓
```

In the Single tests menu, use the <↓> to select **CF delete**.

```
Select service:
*Spch
  UDI ↓
←  +  ✓
```

Using the <↓>, select the service of the call diversion> (e.g. SPch).

```
Select CFx type:
*CFU
  CFB ↓
←  +  ✓
```

Using the <↓> select the type of call diversion>(e.g. CFU).

```
Numbers
Own number
0235190700
←  DEL  ✓
```

Under "Own number", enter the number which should no longer be diverted.
Press to delete the digit before the cursor.

Delete a call diversion

```
Diversion/s
deleted!
CONT.
```

```
Single tests
→CF delete
  MSN interrogat↓
←  +  ✓
```

10.8 MSN Interrogation (only BRI with DSS1)


On a P-MP access using the DSS1 protocol, the ARGUS will determine the MSNs of the access under test. It will display a maximum of 10 call numbers. Depending on the Type of Number (TON), the ARGUS will display the call numbers in different versions:

- only the MSN (without area code)
- with national area code without leading the "0"
- with country code without leading the "00"
- complete call number

In order to interrogate the MSNs, the access under test must support the supplementary service "Call Forwarding (CF)".

```
Single tests
→MSN interrogat.
Phone / connect↓
←   ↓   ✓
```

In the Single tests menu, use the <↓> to select **MSN interrogat..**



```
MSN          1/03
              2351919658
TON:national ↓
←   ↓   NEW
```

Start the MSN interrogation

In this example, the ARGUS displays the first MSN (2351919658) of a total of three found (1/03).

Using the <↓>, scroll through the results

Press <NEW> to repeat the MSN interrogation.



Due to differences in the protocol, some exchanges do not support MSN interrogation.

In this case, the ARGUS will report: MSN interrogation not possible!

10.9 Time measuring

The ARGUS measures three different times:

- **Connection setup time**
- **Propagation time of the data and**
- **Transit time differential (interchannel delay) of the data in two B-channels.**

Time measurements on a BRI or U-Interface access are only possible in TE mode.

10.9.1 Connection setup time

The ARGUS places an outgoing call and measures the time between sending the SETUP and receiving the ALERT or CONN. The ARGUS disconnects automatically as soon as the measurement is completed.

```

Single tests
→Time measuring
-----↓
←  +  ✓

```

In the Single tests menu, use the <↓> to select **Time measuring**.

```

Time measuring
→Conn.setup time
B-channel dela↓
←  +  ✓

```

Use the <↓> to select **Conn.setup time**.

```

Numbers
Own number
0235190700
←  DEL  ✓

```

Enter - or select from the speed-dialing memory - the call number for the outgoing call

```

Select service
→Tel.ISDN
Fax G3 ↓
ABORT +  ✓

```

Use the <↓> to choose **Select service**.

```

B channel select
Active B ch.: 2
Ch.available !
←  DEL  ✓

```

Enter the B-channel.

```

Conn. setup time
0.458 s ALERT
ABORT

```

Perform measurement

The ARGUS will display the connection setup time in seconds and the received L3 messages (end of connection setup).

If the ARGUS cannot perform the measurement (e.g. because the call number entered was wrong or no B-channel was free) the corresponding cause will be displayed.

10.9.2 Time measurement: B-channel delay

The ARGUS places a call to itself (self call) or to a remote loopbox and measures the propagation delay for the data in the selected B-channel.

The ARGUS disconnects automatically as soon as the measurement is completed.

```
Single tests
→Time measuring
-----↓
←  +  ✓
```

In the Single tests menu, use the <↓> to select **Time measuring**.

```
Time measuring
→B-channel delay
Interchan.dela↓
←  +  ✓
```

Use the <↓> to choose **Interchan.dela**.

```
Numbers
Own number
0235190700
←  DEL  ✓
```

Enter own number for self calls or remote number for connections to a remote loopbox.

```
Select service
→Tel.ISDN
Fax G3 ↓
ABORT ←  ✓
```

Use the <↓> to choose **Select service**.

```
B channel select
Active B ch.: 2
Ch.available !
←  DEL  ✓
```

Enter the B-channel on the keypad.

```
B-channel delay✓
avg: 0.63 ms
min: 0.63 ms ↓
ABORT ←
```

Perform measurement

The ARGUS displays the average (avg), the shortest (min) and the longest (max) B-channel delay in msec. as well as the average B-channel delay in bits (multiples


```

B-channel delay✓
ava: 0,63 ms
min: 0.63 ms ↓
ABORT →

```



```

B-channel delay
max: 0,63 ms
bit: 40
ABORT →

```



```

Time measuring
→B-channel delay
Interchan.delat
← → ✓

```

of the time required to send a bit at 64 kBit/s).
(The time for sending 1 bit at 64 kBit/s = approx. 15.26 μs.)

Use the <↓> to scroll.

The measurement will be repeated in cycles.

Press <ABORT> to stop the measurement.

The ARGUS will display the last measurement.

If the ARGUS cannot perform the measurement, e.g. because the call number entered was wrong or no B-channel was free, the corresponding cause will be displayed.

When it is connected to a loopbox, if the ARGUS does not receive the data back within 13 seconds, it will display the message "No LOOP".

10.9.3 Time measurement: Interchannel delay

The ARGUS establishes two separate connections to a remote loopbox. The loopbox sends the respective B-channel data back on the same channel. The ARGUS measures the propagation delay for the data on each of the B-channels and determines the difference between the two propagation delays (interchannel delay).

The ARGUS disconnects automatically as soon as the measurement is completed.

```
Single tests
→Time measuring
-----↓
←  +  ✓
```

In the Single tests menu, use the <↓> to select **Time measuring**.

```
Time measuring
→Interchan.delay
-----↓
←  +  ✓
```

Use the <↓> to select **Interchan.delay**.

```
Numbers
Dest. number 1
02351907070 ↓
← DEL ✓
```

Enter the remote call number of the loopbox - or select it from the speed-dialing memory.

```
Select service
→Tel.ISDN
Fax G3 ↓
ABORT + ✓
```

Use the <↓> to choose **Select service**.

```
interchan. dela✓
avg: 0.00 ms
min: 0.00 ms ↓
ABORT +
```

Perform measurement

The ARGUS displays the average (avg), the shortest (min) and the longest (max) interchannel delay in msec. as well as the average interchannel delay in bits (multiples of the time required to send a bit at 64 kBit/s) - it takes 15.26 µsec to send a bit at 64 kBit/s).

Use the <↓> to scroll. The measurement will be repeated in cycles (**continuous measurement**).

```
interchan. delay
max: 0.00 ms
bit: 0
ABORT +
```

Press <ABORT> to **stop the measurement**.

The ARGUS will display the last measurement.

```
Time measuring
→Interchan.delay
-----↓
←  +  ✓
```

If the ARGUS cannot perform the measurement (e.g. because the call number entered was wrong or no B-channel was free) the corresponding cause will be displayed.

When it is connected to a loopbox, if the ARGUS does not receive the data back within 13 seconds, it will display the message "No LOOP".

11 Connection

11.1 Setting up an ISDN connection

- a) The ARGUS can setup a connection for the following services:

Service	Name in the ARGUS display / abbreviation
Language	Language / Lang
Unrestricted Digital Information	UDI 64kBit / UDI 64
3.1 kHz Audio	Tel.analog / Tel.
7 kHz Audio	7 kHz audio / 7 kHz
Unrestricted Digital Information with tones / Display	UDI+TA / UDI TA
Telephony	Tel.ISDN / Tel.
Facsimile Group 2/3	Fax G3 / FaxG3
Facsimile Group 4 Class 1	Fax G4 / FaxG4
Teletex service basis and mixed mode and facsimile service Group 4 Classes II and III	Mixed Mode / Mixed
Teletex Service basis mode	Teletex / Ttx64
International inter working for Videotex	Videotex / Vidtx
Telex	Telex / Telex
OSI application according to X.200	OSI / OSI
7 kHz Telephony	Tel.7kHz / Tel7k
Video Telephony, first connection	Videotel.1 / Vid.1
Video Telephony, second connection	Videotel.2 / Vid.2


Additional three user-specific services (see "Services" on page 182.)

- b) The integrated handset can be used as a phone during a telephone connection.
- c) When an ISDN connection is setup, pressing the number keys (0-9) or the * or # will generate and send the corresponding DTMF tones.

Procedure for an Outgoing Call (ISDN)

1) Overlap sending:

In overlap sending, the digits entered for the call number are sent individually.



```

Connect.   Tel.
90700      B02
to: 01191
CLEAR TM

```

The connection is setup using B-channel 2.



The ARGUS will display additional information (if there is any)

```

Connect.   Tel.
SUB:808076
to: 01191
CLEAR TM

```

The ARGUS displays the sub-address of the caller (808076) and the destination number (01191).



```

Connect.   Tel.
UUI:HALLO
CLEAR TM

```

Display of the

- User-to-User Information
- Display Information
- Type of number (T.o.n.)
- Numbering Plan (NP)



```

Connect.   Tel.
AOC:
Units      24↓
CLEAR TM

```

- Advice of charges:
If the charges are not given in units, rather directly as currency, the ARGUS will display the current charges in currency. If, in DSS1, the call charges are not provided in accordance with the ETS 300 182 standard, rather in the form of the information element DISPLAY (DSP), the ARGUS will display the DISPLAY message's character string.



```

Call clearing
Normal clearing
Loc.: user
CONT. TM

```

Disconnect

The ARGUS displays the cause of the disconnect. (see page 139 Clearing down an ISDN connection)



Note regarding the entry of the call number


Separate the extension from the access number with a # (e.g. 02351 / 9070-20 is entered on the ARGUS as: 023519070 #20).


For an outgoing call, the ARGUS uses the entire call number (without #) as the number called (CDPN or DAD) and, for the calling number, only the extension (DSS1-CGPN or 1TR6-OAD).

A '#' at the beginning of a call number is treated as a valid character. A '#' at the end of the own call number instructs the ARGUS to not send the caller's number for outgoing calls (CGPN or OAD).



Simplified overlap signaling using the telephone key

If you press the -Key, the ARGUS will open the Connection/Overlap window directly regardless of the currently open menu.

Press the -Key again: A dial tone will be heard and once the call number is entered, the call will be setup.

2) Enblock

In en-bloc signalling, the ARGUS sends the entire dialing information in one block.

The number is dialed from the call number memory (see "Saving Call Numbers" on page 197.).


```
Single tests
+Phone / connec.
Time measuring↓
←  +  ✓
```

In the Single tests menu, use the <↓> to select **Phone / connec.**


```
Connection
+Enblock
-----↓
←  +  ✓
```

Use the <↓> to select **Enblock** signalling.

```
Numbers
Dest. number 1
02351907070 ↓
←  DEL  ✓
```

Use the -Key to select the number from the call number memory or reenter the number on the keypad.

Press to delete a digit.

If the -Key is pressed the ARGUS will open the **Connection** menu.

```
Select service
+Tel. ISDN
Fax G3 ↓
ABORT +  ✓
```

Using the <↓>, select the service to be used for the connection.

```
B channel select
Active B ch.: 2
Ch. available !
←  DEL  ✓
```

Enter the B-channel on the keypad.
(See Overlap sending for entries)

Start the dialing procedure

(for more displays and information see Overlap sending)

```
Outgo. call Tel.
90700 B02
to: 01191 ↓
CLEAR TM
```

Disconnect

The ARGUS displays the cause of the disconnect. (see page 139 Clearing down an ISDN connection)

```
Call clearing
Normal clearing
Loc.: user ↓
CONT. TM
```

Procedure for an Incoming Call (ISDN)

An incoming call can be taken at any time even when a test (e.g. BERT) is in process (see “Simultaneously Starting Several Tests” on page 145.).

The ARGUS will signal an incoming call with an audible tone and a message on the display.


On a P-MP access, you can use the **Call acceptance** (see “Call Acceptance” on page 183.) function to configure the ARGUS to only signal incoming calls which are addressed to the MSN that corresponds to your own call number. This function can only be used when your own call number has been entered into the ARGUS’s speed-dialing memory (see “Saving Call Numbers” on page 197.) and the incoming call has a destination MSN.

```
In.call Tel.
02351907070 B01
to: 90700 ↓
REJECT ACCEPT
```

Reject call

The ARGUS displays the service (Tel.), the number of the caller (02351907070), the B-channel used (B01) and the number called (90700).

The ARGUS will display the complete destination number (DDI), if the Alerting mode is set to manual (see Page 180).

-Key: View additional information (if available)

Accept the call

```
Connect. Tel.
02351907070 B01
to: 90700 ↓
CLEAR TM
```

Use the <TM> softkey to start the Test Manager. (see Page 144).

Use the <↓> to view additional information.

```
Call clearing
Normal clearing
Loc.: user ↓
CONT. TM
```

Clearing the connection

Charge information in NT mode (optional):

In NT mode, the ARGUS will – for incoming calls – send advice of charges in accordance with DSS1 as units and as currency (in Euro).

11.2 Clearing down an ISDN connection

```

Connect.   Tel.
02351907070 B01
to: 90700  ↓
CLEAR TM


```



```

Call clearing
Normal clearing
Loc.: user  ↓
CONT. TM

```



```


Single tests
→Phone / connec.
Time measuring↓
← ↓ ✓

```

To **clear down the connection**, press <CLEAR> or the

Press the -Key

The ARGUS will display the cause (see the table below) of the disconnect (e.g. Normal clearing) and the location where the cause occurred (e.g. subscriber).

-Key: View additional information (e.g. charges, if available)

<TM>: Open the Test Manager

The ARGUS returns to the Single tests menu.

The following causes are shown in clear text:

Cause	Display	Explanation
255	Active clearing	User actively initiated the disconnection
Long 0	Normal clearing	Cause element with Long 0 is mostly used by 1TR6
01	Unalloc. number	"No access under this call number" is signaled
16	Norm. clearing	Normal disconnect
17	User busy	The number called is busy
18	No user respond	No answer from the number called
19	Call.time	Call time too long
21	Call reject	The call is actively rejected
28	Wrong number	Wrong call number format or call number is incomplete

11 Connection

31	Norm. clearing	<i>Unspecified "normal class" (Dummy)</i>
34	No B-chan.avail.	<i>No circuit / B-channel available</i>
44	Req.chan.unavail	<i>Requested B-channel not available</i>
50	Req.fac.not subs	<i>Requested supplementary service (facility) not subscribed</i>
57	BC not authoriz.	<i>Requested bearer capability is not enabled</i>
63	Srv./opt.n.avail	<i>Unspecified for "Service not available" or "Option not available"</i>
69	Req.fac.not impl.	<i>Requested facility is not supported</i>
88	Incompat. Objectives	<i>Incompatible destination</i>
102	Timer expired	<i>Error handling routine started due to time-out</i>
111	Protocol error	<i>Unspecified for "protocol error class"</i>
127	Interworking err	<i>Unspecified for "interworking class"</i>

Other causes are not shown in clear text, rather as decimal codes (see Appendix C and D Page 211).

11.3 Operation on a POTS (analog) access

Procedure for an Outgoing Call (POTS)

The ARGUS sets up a connection to another terminal. If the terminal is a telephone, the handset integrated in the ARGUS can be used to hold a conversation.

```
ARGUS44Pi POTS
→Single tests
Automatic test↓
┌───┴───┘
```

In the Main menu, use the <↓> to select **Single tests**.

```
POTS telephony
to: 02351907070
-----
CLEAR  MEM  R
```

Setup the connection

Enter the number on the keypad. Each of the number's digits will be dialed individually.

The ARGUS will display the number dialed.

As soon as the remote party answers, a voice connection will be set up.

The ARGUS will display the charges, if the information is available for the access under test.

<R>: Generate a FLASH signal

<MEM>: Select the number from the call number memory or reenter the number on the keypad

```
Numbers
Dest. number 1
02351907070 ↓
┌───┴───┘
```

Use the <↓> to scroll. Press to delete a digit.

The last number dialed will always be used as the default (simplified last number

redial)

```
POTS telephony
to: 02351907070
-----
CLEAR MEM R
```

The ARGUS sends the complete dialing information together.


Disconnect



```
ARGUS44Pi POTS
→Single tests
Automatic test↓
⏪ ⏩ ✓
```



Simplified overlap signaling using the telephone key

If you press the -Key, the ARGUS will open the POTS telephony window directly from any menu. Once the call number is entered, the call will be setup.

Procedure for an Incoming Call (POTS)

The ARGUS signals an incoming call both audibly and on the display.

```

POTS call
02351907070
-----
ACCEPT

```

or press the



-Key

```

POTS telephony
02351907070
CLEAR      R

```

```

ARGUS44Pi POTS
*Single tests
Automatic test↓
←      +      ✓

```

If the access supports CLIP, the ARGUS will display the number of the caller (see "POTS CLIP" on page 188).

Accepting call

< R>: Generates a FLASH signal

Disconnect

12 Test Manager

The ARGUS can simultaneously start fully independent BRI access tests or “connections”.

As an example, a BERT can be run at the same time that you make a phone call. The individual tests or “connections” use resources.

All of the tests that have been started will be administered by the Test Manager. Using the Test Manager you can start new tests, switch between tests running in parallel or terminate all of the tests that are currently running.

```
ARGUS44#i BRI
>Test manager
Automatic test↓
← ↓ ✓
```

In the Main menu, use the <↓> to select the **Test Manager**.

```
Tests -/00 B--
>Cancel all
Start new one ↓
← ↓ ✓
```

Open the Test Manager



If the ARGUS is in the Connections or Single tests menu (or in a test), the Test Manager can be opened using the **6** -Key or via the <TM> softkey.

12.1 Simultaneously Starting Several Tests

Starting a new test or connection during an existing connection

```
Connect. Tel.
02351907070 B01
to: 90700 ↓
CLEAR TM
```

Example:

There is a connection on B-channel 1.

During this connection, the Test Manager can be started by pressing the **6**-Key or the <TM> softkey.

```
Tests -/01 B--
→Start new one
Outso. connect↓
← ↓ ✓
```

The ARGUS displays the number of existing connections (-/01).

Use the <↓> to select **Start new one**.

```
ARGUS44Pi BRI
→Single tests
Test manager ↓
← ↓ ✓
```

The ARGUS returns to the main menu.

Use the <↓> to select **Single tests**.

```
Single tests
→Bit error test
X.31 test ↓
← ↓ ✓
```

Use the <↓> to select the desired test (e.g. bit error rate test).

Start test
(Still connected)

```
BERT 2^15 B02
15:45:42 3
synchron LOS: 5
ABORT TM ERROR
```

For information on the operation of bit error tests, see Page 105

The ARGUS jumps to the Test Manager

```
Tests 1/02 B01
→Outso. connect.
-----↓
← ↓ ✓
```

Use the <↓> to select **Outgo.connect..**

The connection was started first (1/02), there are 2 connections / tests (1/02).

The connection uses B-channel 1 (B01).

```

Connect. Tel.
02351907070 B01
to: 90700 ↓
CLEAR TM

```

The ARGUS will return to the Connection window.

If a test (or connection) is cancelled/cleared, the ARGUS will return to the Test Manager if there is another test (or connection) running in the background.



Some tests use so many resources that they cannot be run in every combination with other tests. In this case, the ARGUS will display "Test not possible at this time".

Test/ Connection	Number of times that this test/connection can be started at the same time	It is possible to change to another test
Incoming call	2	Yes
Outgoing call	2	Yes
BERT	2	Yes
LOOP	2	Yes
Service Tests	1	No
Suppl.serv.test	1	No
Time measurement	1	No
X.31 Test	1	No
CF Interrogation	1	No
Auto. Test	1 When the Auto. Test is running all of the resources are in use and no other tests or connections are possible	No
BRI level	1	No
POTS voltage	1	No

Accepting an incoming call/connection when a test is running.

The ARGUS signals an incoming call both audibly and on the display (see page 132 Setting up an ISDN connection). The incoming call can be accepted without influencing the currently running test. If either the **B-channel loop** or **BERT wait** function is active, the call will be accepted automatically.

The manner that multiple connections are handled is illustrated in the following example of "Accepting an incoming call during a BERT", but it is identical for all other tests.

```
In.call Tel.
02351907070 B01
to: 90700 ↓
REJECT ACCEPT
```

While running a BERT, the ARGUS displays a incoming call in the display.

<REJECT>: To reject the incoming call. The ARGUS will return to the BERT.

Accept the call

```
Connect. Tel.
02351907070 B01
to: 90700 ↓
CLEAR TM
```

The BERT will continue in the background.

or

-Key

```
Tests 1/02 B02
→BERT outgoing
Incom. connect↓
← + ✓
```

Use the <↓> to select **BERT outgoing**.

The ARGUS jumps to the BERT

```
BERT 2^15 B02
15:45:42
synchron LOS: 5/3
ABORT TM ERROR
```

The connection is still active in the background, the handset is still switched to the connection.



If available, the internal handset will be assigned to the currently started (voice) connection. The assignment of the handset to a given connection is also retained in the background.

12.2 Switching Between Tests

Open the Test Manager.

```

Tests 2/02 B02
→BERT outgoing
Auto LOOP ↓
← ↓ ✓

```

Using the <↓>, select the Test (Connection) that you wish to switch to.

If you press the <✓>, the ARGUS will open the selected test.

If you press the <↑>, the ARGUS will return to the place from which the Test Manager was called (e.g. to a test running parallel). If no other test is running, the ARGUS will, reasonably enough, return to the Main menu.

12.3 Cancel All

Open the Test Manager.


Using the <↓>, select **Cancel all**.

```

Tests 0/02 B--
→Cancel all
Start new one ↓
← ↓ ✓

```

The ARGUS will cancel all of the currently running tests and/or connections and then return to the Main menu.



```

ARGUS44Pi BRI
→Single tests
Test manager ↓
← ↓ ✓

```

13 Automatic Test

The ARGUS performs an automatic test series and displays the test results.

Using the Intec software, WINplus or WINanalyse, the test results can also be saved on a PC, where they can be presented in a comprehensive measurement report and printed.

The ARGUS automatically performs the following sequence of tests:

On a BRI or U-interface access (ARGUS in TE Mode)

- Status
- Level Measuring
- Service Tests
- BERT in an extended call to oneself
- Supplementary Services Test
- CF Interrogation (Call Diversions)
- MSN Interrogation
- X.31 test

On a BRI or U-interface permanent circuit

- Status
- Level Measuring
- BERT in end-to-end mode (e.g. with a loopbox on the remote end)

On an ADSL access

- the ARGUS will determine all of the relevant line parameters of an ADSL connection.

The ARGUS saves the test results together with the date and time (from the internal clock of the ARGUS). Additionally, settings such as your own plus a remote call number will also be saved.

The test results are not lost when the ARGUS is switched off.



The ARGUS saves the results of multiple test series (records 1,2,3...).

Each function in the Automatic tests menu refers to one of

13 Automatic Test

the test series saved as a record.

Therefore, the first step will open a dialog in which you must select the desired data record.

```
ARGUS44Pi ADSL
→Automatic tests
Level measurin↓
←      +      ✓
```

Use the <↓> to select **Automatic tests.**

```
Auto test
→ 1 24.12. 17:45
   2 31.12. 23:5↓
←      NAME      ✓
```

Use the ↓-Key to select the record holding the saved test results. The ARGUS will display for each record number the associated name and corresponding date and time. Empty records are labeled as "free".

```
Auto test No.: 2
→ 1 AMP_1
   2 AMP_2      ↓
←      DATE      ✓
```

```
Auto test No.: 2
→Start
Display result↓
←      +      ✓
```

If the automatic test series is started by pressing function key 4 instead of via the Automatic tests menu, you must first enter a name for it to be saved under.

```

ARGUS44Pi BRI
B12      Level: OK
TEs P-MP BILING.
MENU RESTART

```

Press
numeric key 4

```

save as:
AMP_5
ABORT DEL  ab>AB

```

 -Key

Start the test series,
see Page 152

Start the automatic test

Using the numeric keys enter the name under which the result should be saved (Default: AMP_1, AMP_2.... or the call number of the access under test if the number has been entered into the speed-dialing memory)

When the right softkey is pressed it assumes a different meaning and thus influences the entries made from the keypad (letters or digits):

<12>ab> : entry of the digits 0 to 9 plus * and #

<ab>AB> : entry of the lowercase characters and @, /,- and .

(e.g. to enter a "c" press the "2" on the keypad three times)

<AB>12> : entry of the uppercase characters and @, /,- and .

To move the cursor right or left, use the \uparrow , \downarrow -Keys.

Press **** to delete the digit before the cursor.

If all of the records have been written, you must manually select a memory location (record).

13.1 Automatic Start test on a BRI access

Before starting the automatic test sequence, you should check the necessary parameters (on a BRI access, e.g. the measurement time and error level for a BERT see Page 184).

```
Auto test No.: 2
→Start
Display result↓
← + ✓
```

Use the <↓> to select **Start**.
(in the example, the new test is saved in record number 2)

```
Numbers
Own number
0235190700
← DEL ✓
```

Enter Own number - on accesses using the DSS1 protocol - also enter a **remote number**.

```
Select service
→Tel.ISDN
Fax G3 ↓
ABORT + ✓
```

Use the <↓> to select the service.
(required for the suppl.serv.test)

```
Service check ✓
6/12 Fax G3
ABORT
```

Start test

During the test series, the first three lines in the display will reflect the Single test currently being run.

To interrupt the test, press <ABORT>.

```
Auto test No.: 2
→Interrupt test
Stop cur. test↓
ABORT + ✓
```


Terminating the test (early):

```
Service check  ✓
6/12 Fax G3
ABORT
```

```
Auto test No.: 2
→Interrupt test
Stop cur. test↓
ABORT  +  ✓
```

```
Auto test No.: 2
→Start
Display result↓
←  +  ✓
```

The ARGUS is running an automatic test.

Interrupting a test

Use the <↓> to select **Interrupt test**. Press the <ABORT> softkey to restart the test.

Interrupt test, the test results will be lost. Any "old" data stored under this data record number from a prior test will be retained.

tests:

```
Service check  ✓
6/12 Fax G3
ABORT
```

```
Auto test No.: 2
→Stop cur. test
-----↓
ABORT  +  ✓
```

```
BERT 2^15      B02
15:45:42      3
synchron LOS:  5
ABORT TM ERROR
```

Skipping individual tests:

A single test can be skipped: In this example, the ARGUS is running a Service check.

Interrupt the Service check


Use the <↓> to select **Stop cur. test**. Press the <ABORT> softkey to restart the Service check.

The ARGUS will skip the Service check.

The next single test (e.g. BERT) will be started.

Resuming a test:

```
Service check /
6/12 Fax G3
ABORT
```



```
Auto test No.: 2
→Continue test
Interrupt test↓
ABORT + ✓
```



```
Service check /
6/12 Fax G3
ABORT
```

An interrupted Single test can be resumed:

In this example, the ARGUS is running a Service check.

Interrupting a test

Use the <↓> to select **Continue test**.

Press the <ABORT> softkey to restart the test.

The ARGUS repeats the “disturbed” single test (in the example: the Service check).

13.2 Display saved results

The saved results of the single tests run on a BRI or U-interface will be displayed in the following order:

For: **BRI or U-interface** **BRI or U-interface**
- Permanent circuit

- State State
- Level measuring Level measuring
- Service Check BERT
- BERT
- Suppl.serv.test
- X.31-Test
- CF Interrogation (Call Diversions)
- MSN Interrogation

```

ARGUS44Pi BRI
→Automatic tests
Level measurin↓
←      ↓      ✓
    
```

Use the <↓> to select **Automatic tests**.

```

Auto test
→ 2 31.12. 23:50
  3 11.01. 11:1↓
←  NAME  ✓
    
```

Use the ↓-Key to select the stored test.

```

Auto test No.: 2
→Display result
Test data to P↓
←      ↓      ✓
    
```

Use the <↓> to select **Display result**.

```

Auto test No.: 2
B12
P-P TE DSS1
ABORT CONT.
    
```

Display the test results:
The ARGUS will first display the status of the access under test.

```

Auto test No.: 2
UDI 64kBit+*123
3.1k audio++ ↓
ABORT ↓ CONT.
    
```

Display result of the next single test
e.g. display Service check.
Use the <↓> to scroll through the Single test results.
If you press <CONT.,> he ARGUS will display the results of the next single test.

Display for an ADSL access physical test:

```
Auto test No.: 2
*Display result
Test data to P↓
┌───┴───┐
└───┬───┘
```

Use the <↓> to select **Display result.**

```
Auto test No.: 2
G.DMT
Elapsed: 0:00:10↓
ABORT ─┬─ CONT.
```

Use the <↓> to scroll through the test results.

Bit distribution display



Measurement results on an ADSL access:
For the interpretation of the measurement data, see Page 49.

```
Auto test No.: 2
- Modem idle
10:25:00:000 ↓
ABORT ─┬─ CONT.
```

Press the ✓-Key or the softkey on the right to view the trace data

```
Auto test No.: 2
*Display result
Test data to P↓
┌───┴───┐
└───┬───┘
```

Close the results display.

Display for an ADSL access Ping test:

```

Auto test No.: 2
→Display result
Test data to P↓
┌──────────┴──────────┐
←         ↓         ✓

```

Use the <↓> to select **Display result.**

```

Auto test No.: 2
Sent:           10
Received:       10↓
ABORT → CONT.

```

Using the <↓,>scroll through the results of the Ping test.

```

Auto test No.: 2
G.DMT
Elapsed:0:00:10↓
ABORT → CONT.

```

ADSL Status display,
Test time,
ADSL line parameters
Use the <↓>to scroll.



Bit distribution display

```

Auto test No.: 2
- Modem idle
 10:25:00:000 ↓
ABORT → CONT.

```

Press the ✓-Key or the softkey on the right to view the trace data

```

Auto test No.: 2
→Display result
Test data to P↓
┌──────────┴──────────┐
←         ↓         ✓

```

Close the results display.

The other test results (e.g.Traceroute test) are displayed in the same manner.

13.3 Sending the results of a tests to a PC

To visualize and archive the test results on the PC, the data records can be transferred to the PC via the serial interface using the included cable (labeled as PC Interface) (connect the cable between the ARGUS "V.24" jack ---- PC's serial interface).

Connect the ARGUS to your PC and start the **ARGUS WINplus** program.

```

ARGUS44Pi ADSL
➔Automatic tests
Level measurin↓
  
```

Use the <↓> to select **Automatic tests**.

```

Auto test
➔ 1 24.12. 17:45
  2 31.12. 23:5↓
  
```

Use the ↓-Key to select the record (e.g. No. 2).

```

Auto test No.: 2
➔Test data to PC
Start ↓
  
```

Use the <↓> to select **Test data to PC**.

Start transfer of data to PC

13.4 Deleting the results of a test

```

ARGUS44Pi ADSL
→Automatic tests
Level measurin↓
←  +  ✓

```

Use the <↓> to select **Automatic tests**.

```

Auto test
→ 1 24.12. 17:45
  2 31.12. 23:5↓
←  NAME  ✓

```

Use the ↓-Key to select the record (e.g. No. 2).

```

Auto test No.: 2
→Delete
All tests to P↓
←  +  ✓

```

Use the<↓> to select **Delete**.

Delete record (No. 2)

```

Auto test
→ 2 empty
  3 empty ↓
←  ✓

```

For information on how to delete all **records**, please see on page 199 "Reset".

13.5 Sending the results of all tests to a PC

The ARGUS will send the results of all of the tests to the PC at one time.

```
ARGUS44Pi ADSL
→Automatic tests
Level measurin↓
↑ ↓ ✓
```

Use the <↓> to select **Automatic tests.**

```
Auto test
→ 1 24.12. 17:45
  2 31.12. 23:5↓
↑ NAME ✓
```

Use the ↓-Key to select any record .

```
Auto test No.: 2
→All tests to PC
-----↓
↑ ↓ ✓
```

Use the<↓> to select **All test to PC.**

Start transfer of data to PC

14 Level Measuring

14.1 Level measuring on a BRI access

Level measurement – connected line

The ARGUS measures the level of the received useful signal. In TE mode, it also measures the phantom feed. The measurement will be updated continuously.

```
ARGUS44Pi BRI
→Level measuring
L1 status ↓
← ↓ ✓
```

Use the <↓> to select **Level measuring**.

```
Level measuring
→Connected line
Other TE ↓
← ↓ ✓
```

Use the <↓> to select **Connected line**.

Start measurement

```
Level: 0,64V OK
Voltage:
38,2V OK NORM
ABORT R>ON NEW
```

The ARGUS will display the level of the useful signal (e.g. 0.64 V) and the level of the feed (e.g. 38.2 V).

<R>ON>: add 100Ω resistor

< R>OFF>: remove 100Ω resistor

Press <NEW> to setup Layer 1 again - to ensure a reasonable measurement.

Measurement results:

- Evaluation of the useful signal level:

<< level is too low

>> level is too high

OK Level is in order (0.75V ^{+20%} _{-33%} i.e. from 0.9 V to 0.5 V)

___ no voltage

- Evaluation of the level of the feed

- Display the type of feed:

NORM Normal feed (40V ^{+4.25%} _{-13.75%} i.e. from 41.7 V to 34.5 V)

REV_ inverted phantom feed

NONE no feed

Level measurement other TE

The ARGUS will measure the level of a terminal connected in parallel. In this case, the ARGUS is passive.

Layer 1 must be activated on the terminal.

The ARGUS updates its measurement continuously.



Use the <↓> to select **Level measuring**.



Use the <↓> to select **Other TE**.



The ARGUS will display the level of the useful signal (in the example 0.77 V).

<R>ON>: add 100Ω resistor
< R>OFF>: remove 100Ω resistor

Press <NEW> to setup Layer 1 again - to ensure a reasonable measurement.

Measurement of the voltage on a U-interface access (optional)



Use the <↓> to select **Level measuring**.



Start measurement

The ARGUS will display the level of the feed voltage. The measurement will be updated continuously.

14.2 Level measuring on a POTS access

The ARGUS measures the voltage level in both the normal case and when the line is "busy" (trunk line).

```
ARGUS44Pi POTS
+Level measuring
Configuration ↓
←   +   ✓
```

Use the <↓> to select **Level measuring**.

Start measurement

```
Polarity: a+ b-
Line open: 30,4V
Line busy: 13,6V
ABORT     NEW
```

The ARGUS will display the polarity of the 2-wire POTS line (red plug "a"; black plug "b") as well as the "on hook" and "off hook" voltage levels. Press <NEW> to repeat the measurement.

15 The L1 status of a BRI access

The ARGUS displays the current status of Layer 1: which signal is received from the remote end (Rx) and which signal does the ARGUS send (Tx).

```
ARGUS44pi BRI
* L1 status
  Configuration ↓
  ←      →      ✓
```

Use the <↓> to select **L1 status**.

```
L1 status
TE: info 4
NT: info 3
ABORT      NEW
```

The ARGUS displays the status of Layer 1 or of the signal, which is currently being sent (Info 0 Info 4). Press <NEW> to setup Layer 1 again if necessary.

16 Configuration

The ARGUS can be configured to suit your special requirements. The default (factory) settings can be restored by selecting "Reset" (see page 199 Reset).

16.1 Trace/Remote

The ARGUS remains active and passes the data from the D-channel (all of the D-channel messages sent to and received from the network) online directly to the connected PC. The Remote function is optional.

```
ARGUS44Pi BRI
*Configuration
Access ↓
← → ✓
```

In the Main menu, use the <↓> to **Select Configuration.**

```
Configuration
*Trace/remote
ADSL profile ↓
← → ✓
```

Use the <↓> to choose **Trace/remote.**

```
Trace mode
*Off
Auto PC sync. ↓
← → ✓
```

Auto PC sync.: even after it is switched on again, the ARGUS remains in Trace mode and passes D-channel data to the PC ("Trace" LED on continuously).

PC-conn.once: the ARGUS is set to Trace mode and will pass D-channel data to the PC until it is switched off. When it is switched on again, it will not return to Trace mode.

```
Configuration
*Trace/remote
ADSL profile ↓
← → ✓
```


Confirm the entry

If the ARGUS cannot send the data to the PC without errors, the "Trace" LED will flash at 5Hz (5 times per sec).

The currently active settings will be marked in the display with an *.


16.2 Configuring ADSL profiles

The ARGUS stores all of the parameters the various ADSL test varieties in the ADSL profiles. Up to 5 user-defined ADSL profiles can be created. An ADSL profile must be selected before an ADSL test run. Only those settings which are relevant will be used for the respective test situation.







ADSL settings:

Display Name on the ARGUS	Comment														
Physic. line:	The following ADSL line parameters are grouped under this heading:														
ADSL mode	<p>Different ADSL modes can be selected depending on the national variant of the ARGUS.</p> <p>The selected ADSL mode must be compatible to ATU-C (network-side).</p> <table data-bbox="678 712 1224 1064"> <tr> <td>ADSL Mode</td> <td>Standard</td> </tr> <tr> <td>- Annex B (DT)</td> <td>T-DSL (UR2)</td> </tr> <tr> <td>- Annex B (ETSI)</td> <td>ETSI DTS</td> </tr> <tr> <td>- Annex A auto</td> <td>automatic detection</td> </tr> <tr> <td>- ANSI T1.413</td> <td>ANSI T1.413 .2</td> </tr> <tr> <td>- G-Lite</td> <td>ITU-T G.992.2</td> </tr> <tr> <td>- G.DMT</td> <td>ITU-T G.992.1</td> </tr> </table> <p>If the ADSL mode “Annex A Auto” is selected, the ARGUS will automatically determine the configuration of the DSLAM (G.DMT or ANSI) and set itself accordingly.</p>	ADSL Mode	Standard	- Annex B (DT)	T-DSL (UR2)	- Annex B (ETSI)	ETSI DTS	- Annex A auto	automatic detection	- ANSI T1.413	ANSI T1.413 .2	- G-Lite	ITU-T G.992.2	- G.DMT	ITU-T G.992.1
ADSL Mode	Standard														
- Annex B (DT)	T-DSL (UR2)														
- Annex B (ETSI)	ETSI DTS														
- Annex A auto	automatic detection														
- ANSI T1.413	ANSI T1.413 .2														
- G-Lite	ITU-T G.992.2														
- G.DMT	ITU-T G.992.1														

Link-Up Time	<p>Once the connection to the DSLAM is setup (Sync-LED ON constantly), the ARGUS will continually measure the data for the selected period of time. During this ADSL link up time, the ARGUS will display "Showtime". Once the measurement time has elapsed, the connection will be automatically cleared.</p> <p>If the link-up time was set to "Continuous", the connection to the DSLAM must be cleared manually.</p> <p> When the link-up time is set to "Continuous", we recommend that you operate the ARGUS on the power supply to save the accumulators (rechargeable batteries).</p>
Rated value	Use the keypad to enter the upstream and downstream comparison value for ATM [Kb/s].

SNR margin DS	<p>Setting for the SNR margin DS.</p> <p>This parameter can be set to "6 dB" or "3 dB".</p> <p>In the activating phase the CPE-side (Argus) requests that the CO-side (DSLAM) reduce its transmit power until the Target Noise Margin of 6 dB or 3 dB is achieved.</p> <p>Some DSLAMs do not support this. Either they will not reduce the transmit power at all or only to a certain value, e.g. half the maximum transmit power. In this case, the current transmit power is less than the maximum. In this case the Noise Margin is still higher than the Target Noise Margin (e.g. 31 dB instead of 6 dB or 3 dB).</p> <p>The "max. dB" setting</p> <p>The max. dB setting on the CPE-side (Argus) does not influence the transmit power of the CO-side (DSLAM). The CO-side transmits at its maximum power and the Noise Margin also reaches its maximum possible value.</p>
Shutdown mode	<p>The type of disconnect used for the ADSL connection.</p>
Protocol:	<p>This setting is used to define which protocol should be used by the ARGUS in the ADSL test.</p>

PPP:		PPP parameter for the Internet connection
User name		<p>Entry of the assigned (by the network operator) user name.</p> <div data-bbox="395 421 791 566" style="border: 1px solid black; padding: 2px;"> <pre>User name 83910235190700#0 0010t-online.de ABORT DEL 3b>AB</pre> </div> <p>Use the keypad to enter the user name. When the right softkey is pressed it assumes a different meaning and thus influences the entries made from the keypad (letters or digits) :</p> <p><12>ab> : entry of the digits 0 to 9 plus * and #</p> <p><ab>AB> : entry of the lowercase characters and @, /,- and . (e.g. to a "c" press the "2" on the keypad three times)</p> <p><AB>12> : entry of the uppercase characters and @, /,- and .</p> <p>To move the cursor right or left, use the ↑,↓-Keys. Press to delete the digit before the cursor.</p> <p>✓ -Key: Save user name</p> <p><ABORT> : Do not save user name</p>
Password		<p>Entry of the assigned (by the network operator) password:</p> <div data-bbox="395 1249 791 1395" style="border: 1px solid black; padding: 2px;"> <pre>Password ***** ABORT DEL 3b>AB</pre> </div> <p>For instructions, see User name</p> <p>✓ -Key: Save password</p> <p><ABORT> : Do not save password</p>
PPTP:		PPTP parameter
Server address	IP	<p>Use the keypad to enter the Server IP address.</p> <p>To move the cursor right or left, use the ↑,↓-Keys.</p> <p>Press to delete the digit before the cursor.</p>

Ping:	
IP address	This is the address of the remote site. The ARGUS can save up to 10 IP addresses. The saved IP addresses are available to all of the profiles.
<pre>IP address 1/10 * 0. 0. 0. 0 0. 0. 0. 0 ← EDIT ✓</pre>	The ARGUS is displaying the memory location holding the first IP address of a maximum of 10 IP addresses (1/10). Press the <↓> to scroll to the next IP address..
	
<pre>IP address *As name -----↓ ← + ✓</pre>	Open the first IP address to edit it. The address can be entered as an IP address (number) and/or name.
	
<pre>IP address www.argus.info ABORT DEL ab>AB</pre>	Enter the name of the IP address. Use the keypad to enter the address. Use the softkey on the right to shift the keypad (the softkey on the right assumes a different meaning when pressed):
	
<pre>IP address 1/10 *www.argus.info 0. 0. 0. 0 ← EDIT ✓</pre>	<12>ab> : entry of the digits 0 to 9 plus * and # <ab>AB> : entry of the lowercase characters (e.g to enter a "c" press the "2" on the keypad three times) and @, /,- and . <AB>12> : entry of the uppercase characters and @, /,- and . Press to delete the digit before the cursor.
 ✓-Key	
<pre>IP address 1/10 *www.argus.info 0. 0. 0. 0 ← EDIT ✓</pre>	Press the <✓> to set the marked the IP address as the default address.

	<p>Use the keypad to enter the numbers of the IP address. To move the cursor right or left, use the \uparrow, \downarrow-Keys. Press to delete the digit before the cursor.</p>
<p>IP address: 123. 45. 7.255</p> <p>ABORT DEL ✓</p>	
<p>Number of pings</p>	<p>Enter the number of test packets that the ARGUS should send to the IP address. If you enter "0", the ARGUS will send packets continuously until the test is stopped manually.</p>
<p>Pause</p>	<p>This setting determines the amount of time that the ARGUS will wait between sending test packets.</p>
<p>Packet size</p>	<p>This setting determines the size of the test packets. By varying the size, it is possible to determine the maximum data packet size and the relationship between size and response time.</p>
<p>Fragmentation</p>	<p>This parameter sets the fragmentation: ON: Depending on the network (or router), test packets may be divided into multiple packets. OFF: Fragmentation is not permitted, i.e. the test packets may be rejected by the network (or router). In this case, the ARGUS will not receive a packet in reply. Auto: The ARGUS determines the maximum packet size for the path to the destination address (Path-MTU) and splits the test packet into smaller packets. These can then be sent with the minimum of delay (since the network/router need not fragment the test packet).</p>
<p>Traceroute:</p>	
<p>IP address</p>	<p>IP address of the destination node: This can be entered as an IP number or as a name (for instructions, see Ping/ IP address).</p>

max. HOPS	This sets the maximum number of hops that will be taken in the path to the destination node.
Probes	This sets the number of attempts that will be made to get a response from a network node.
Timeout	This sets the maximum amount of time that the ARGUS will wait for a response from a network node.
Download :	
Qty	This sets how often the ARGUS will download the data from the "Source" address.
Addresses	<p>Entry of the "Source" addresses: The ARGUS can save up to three HTTP/FTP addresses.</p> <p>Press the <↓> to select the type of "Source" address (http or ftp). Depending on the type of server and the data: for websites, http; for files http or ftp.</p> <p>The ARGUS displays the first (the first memory location) of three possible addresses. ↓ -Key: Scroll to the desired memory location [address].</p> <p>Entry or editing of the address (Caution - see Page 61 regarding the entry of alias www addresses) (for instructions, see Ping: IP address)</p> <p>Save address</p> <p>Press the <✓> to set the top address as the default.</p>

```
Addresses
*HTTP
FTP
← → ✓ ↓
```


```
HTTP address 1/3
*
ABORT EDIT ✓ ↓
```

```
Download address
argus.info
ABORT DEL ␣>AB
```

↓ ✓ -Key

```
HTTP address 1/3
*argus.info
ABORT EDIT ✓ ↓
```

VPI/VCI scan:	
VPI	This sets the VPI range, which the ARGUS should check with the VPI/VCI scan test.
VCI	This sets the VCI range, which the ARGUS should check with the VPI/VCI scan test.
Number of pings	This sets the number of test packets that the ARGUS will send. If you enter "0", the ARGUS will send packets continuously until the VPI/VCI scan test is stopped manually.
Timeout	This sets the maximum amount of time that the ARGUS will wait for a response from an ATM network node to a test packet (ping) which it sent.
ATM OAM ping:	
VPI / VCI	Entry of the VPI and VCI
Number of pings	This sets the number of test packets that the ARGUS will send. If you enter "0", the ARGUS will send packets continuously until the ATM Ping test is stopped manually.
Timeout	This sets the maximum amount of time that the ARGUS will wait for a response from an ATM network node to a test packet (ping) which it sent.
OAM cell type	F5 loopback seg (segmented) F5 loopback ete (end-to-end)
FTP upload:	
Upload profile:	A total of three user-defined server profiles can be created for the FTP upload test. Press <EDIT> to release selected server profile for editing.
Objectives	Entry of the upload destination (server address) to which the ARGUS should send the data.

Filename	Entry of the name of the file holding the data to be sent in the FTP upload test File will be saved on the server
File size	Sets the size of the file that the ARGUS will send in the FTP upload test
User name	Entry of the user name for the FTP server (see page 170 User name) Use the ✓ -Key to save the user name
Password	<p>Entry of the password for the FTP server:</p> <div data-bbox="395 786 791 931" data-label="Image"> </div> <p>For more information, see Page 170 ✓ -Key: Save password <ABORT> : Do not save password</p>
Qty	This sets how often the ARGUS will send the data to the destination.
Profile name	Entry of a profile name for the server profile
ATM BERT	
Duration	<p>You can use the keypad to enter measurement times ranging from 1 minute (default setting) to 99 hours and 59 minutes (= 99:59).</p> <p> If the time is set to 00:00 (=BERT with unlimited measurement time), the BERT will not stop automatically. In this case, the user must terminate the BERT by pressing the <ABORT> softkey.</p>
VPI / VCI	The identifier of the virtual channel in the ATM cells - Virtual Path (Channel) Identifier

Bit pattern	<p>This setting determines the bit pattern that the ARGUS will repeatedly send in an ATM BERT.</p> <p>There are several predefined bit patterns available.</p> <p>Additionally, it is also possible to enter a 16 bit long pattern of your choice in binary (see Page 186).</p>
Error level	<p>This is the level used to evaluate whether the BERT had an "acceptable" bit error rate.</p> <p>If the BERT has a bit error rate, which exceeds this error level, the ARGUS will display a "NO" as the test result.</p> <p>Using the keypad, this parameter can be set to any value from 01 (= 10^{-01}) to 99 (= 10^{-99}).</p> <p>The default threshold (error level) is 10^{-06}. That means that, in the event that the bit error rate is less than 10^{-06} (one error in $10^6 = 1,000,000$ sent bits), the bit error test will be evaluated as OK.</p>
HRX value	<p>The HRX setting (Hypothetical Reference Connections ITU-T G.821):</p> <p>Using the keypad, you can enter a value ranging from 0 to 100 %.</p>
Data rate	<p>Definition of the data rate</p> <p>To achieve meaningful results, the data rate must be the same as that set in DSLAM.</p> <p>Default setting: 32 kbit/s</p>
ATM:	
VPI / VCI	<p>The identifier of the virtual channel in the ATM cells - Virtual Path (Channel) Identifier</p>
Encapsulation	<p>This sets the encapsulation of the packets to be sent (LLC or VC-MUX).</p>


LAN:	
IP mode	This is used to set the assignment of IP addresses: Static IP: fixed IP addresses DHCP-Client: Assigned by the server DHCP-Server: Assigned by the ARGUS DHCP-Auto: The ARGUS will check whether there is a DHCP server in the network. If yes, the address will be assigned by this server. Otherwise, the ARGUS will assign the address.
Own IP address	This is the IP address (of the ARGUS) of the LAN side
IP network mask	LAN IP network mask
GW-IP	Gateway IP address in the LAN network
DHCP server	Settings for the DHCP server: Start and End IP addresses The period for which the IP addresses are reserved Domain Name
DHCP timeout	This sets the amount of time that a client should wait for an IP address (relevant for the IP mode DHCP client)
MAC address	This displays the LAN MAC address of the ARGUS.
WAN:	
IP mode	This is used to set the assignment of IP addresses.
Own IP address	This is the IP address (of the ARGUS) of the WAN side
IP network mask	WAN IP netmask
Remote IP address	Gateway IP address in the WAN network
DHCP timeout	This sets the amount of time that a client should wait for an IP address (relevant for the IP mode DHCP client)

MAC address

Display and editing of the WAN MAC address

The WAN MAC address can be changed via <EDIT>

```
WAN MAC address:
0050:08:5d:4a:22
ABORT EDIT ✓
```



Enter the new address on the keypad.


Press the ✓-Key to use the new address.

The new address is only saved temporarily and will not be available when the ARGUS is switched on again.

Router:	NAT ON or OFF
DNS server:	
DNS Server 1	IP address of the DNS server
DNS Server 2	IP address of the DNS server
Profile name:	Enter the profile names, which should later be displayed by the ARGUS.


16.3 Configuration: ISDN

The operation is the same for all configurations and will be illustrated with a single example:



Settings in ISDN:

Display Name on the ARGUS	Comment
L1 permanent?	On a BRI connection in NT mode, Layer 1 (L1) is permanently active.

Protocol	<p>As an alternative to automatic protocol determination (setting: Automatically), you can also set the Layer-3 D-channel protocol manually.</p> <p>This setting will be stored permanently and will also active when the tester is switched on again.</p>
Alerting mode	<p>You can specify whether, for an incoming call on a BRI point-to-point access, the ARGUS should only display the access number without extension or the complete number with extension.</p> <p>If it is set to "Manual", the ARGUS will display the extension (An incoming call will be signaled. The ARGUS will send the Layer 3 message "Alert" when it accepts the call. The digits of the extension that have been sent by this point will be displayed.).</p> <p> An incoming call in the Manual mode must be answered within 20 seconds or it will be lost. Furthermore, you should not that the remote subscriber will not hear a ringing tone.</p> <p>If it is set to Automatically, the ARGUS will only display the access number without extension or, depending on the configuration of the access in the exchange, it may not display the number called at all.</p>

Clock mode	<p>This parameter sets where the clock will be generated in the case of a BRI access.</p> <p>You can either specify that the ARGUS generates the clock (is Master) or that it is the slave of a clock generated at the other end (Slave).</p> <p>Default setting: NT mode: Master TE mode / Permanent circuit: Slave</p> <p>This setting is not saved and will be lost when the ARGUS is switched off and then back on again.</p>
BRI termination	<p>Independent of the operation mode (TE or NT), a terminating resistor can be switched-in on the BRI access. This setting will not be saved.</p> <p>Default setting: NT mode: Terminating resistor switched-in TE mode / Permanent circuit: no terminating resistor is switched in</p>

Call parameter	<p>Two different parameters can be set for (ISDN) calls generated on both the network-side (ARGUS in NT mode) and on the user-side (ARGUS in TE mode):</p> <p>1. Type of number (TON) for the CGN (=CGPN) or CDN (=CDPN) element of a SETUP signal</p> <p>Network-side: Net CGN TON / Net-CDN-TON</p> <p>User-side: User CGN TON / User CDN TON</p> <p>2. Numbering Plan for the CGN (=CGPN) or CDN (=CDPN) element of a SETUP signal</p> <p>Network-side: Net-CGN-NP/ Net-CDN-NP</p> <p>User-side: User CGN NP / User CDN NP</p> <p>Possible settings:</p> <p>For TON: unknown, international, national, network spec., subscriber, abbreviated.</p> <p>For NP: unknown, ISDN/telephony, data, telex, national stand., private</p>
Services	<p>Up to three user-specific services (user spec.1 to user spec.3) can entered and saved. For each "user spec. service", you must enter the info-elements BCAP, HLC and LLC in hexadecimal. To do so, use the keypad and the <A . . F> softkey (e.g. to enter a "C", press the softkey three times; for a "F", press it six times).</p>

Call Acceptance	<p>If the ARGUS is set to "only own MSN/DDI" and is in TE mode on a P-MP access, it will only signal those calls which placed to the MSN (on a P-P access the DDI) of the access under test.</p> <p>If set to "all MSN/DDI", the ARGUS signals all calls.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> - the "own" number must be entered in the call number memory under "own number" (see "Saving Call Numbers" on page 197) - the incoming call must have a destination MSN <p>The default setting is "all MSN/DDI". This setting is saved permanently.</p>
Voice coding	<p>There are two options for coding voice data in a B-channel:</p> <ul style="list-style-type: none"> - A-law (default) - μ-law <p>This parameter will be reset to the default setting when the ARGUS is switched off and back on again</p>
DTMF / Keypad	DTMF or keypad setting
Destination MSN	A destination number can be entered, which the ARGUS will use for MSN interrogation (default: 0043).

16.4 Configuration: BERT

The operation is the same for all configurations and will be illustrated with a single example:

```
ARGUS44Pi BRI
→Configuration
Access ↓
← → ✓
```

In the Main menu, use the <↓> to **Select Configuration.**

```
Configuration
→BERT
POTS ↓
← → ✓
```

Use the <↓> to select **BERT.**

```
BERT config.
→BERT time
Error level ↓
← → ✓
```

Use the <↓> to select, e.g. **BERT time.**

```
BERT time
00:12
ABORT DEL ✓
```

Use the keypad to enter the duration of the BERT.

: Delete the digit before the cursor

<ABORT> : The ARGUS returns to the BERT config. menu without changing the settings.


Confirm entry

```
BERT config.
→BERT time
Error level ↓
← → ✓
```

The ARGUS will return to the BERT config. menu.

Settings for the BERT:

Display Name on the ARGUS	Comment
BERT time	You can use the keypad to enter measurement times ranging from 1 minute (default setting) to 99 hours and 59 minutes (= 99:59).

	<p> If the time is set to 00:00 (=BERT with unlimited measurement time), the BERT will not stop automatically. In this case, the user must terminate the BERT by pressing the <ABORT> softkey.</p>
Error level	<p>This is the level used to evaluate whether the BERT had an "acceptable" bit error rate. If the BERT has a bit error rate, which exceeds this error level, the ARGUS will display a "NO" as the test result. Using the keypad, this parameter can be set to any value from 01 (= 10^{-01}) to 99 (= 10^{-99}).</p> <p>The default threshold (error level) is 10^{-06}. That means that, in the event that the bit error rate is less than 10^{-06} (one error in $10^6 = 1,000,000$ sent bits), the bit error test will be evaluated as OK.</p>
HRX value	<p>The HRX setting (Hypothetical Reference Connections, see the ITU-T G.821): Using the keypad, you can enter a value ranging from 0 to 100 %.</p>

Bit pattern BRI/U

This setting determines the bit pattern that the ARGUS will repeatedly send in a BERT.

There are several predefined bit patterns available.

(default setting = $2^{15}-1$).

Additionally, it is also possible to enter a 16 bit long pattern of your choice in binary.

```
Bit pattern
→User defined
-----↓
←  +  ✓
```



```
Bit pattern
Enter:
0011010000111001
ABORT ←  ✓
```

To move the cursor right or left, use the ↑,↓-Keys.

Press to change [toggle] the digit before the cursor (0 to 1, 1 to 0)




Saving the bit pattern

```
Bit pattern
→User defined
-----↓
←  +  ✓
```

16.5 Configuration: POTS

The operation is the same for all configurations and will be illustrated with a single example:



Settings on a POTS access:

Display on ARGUS	Comment
Analog dial mode	Selection of the dialing mode: DTMF or pulse dialing

POTS CLIP	<p>Select the transfer procedure used to pass the call number:</p> <p>FSK: CLIP via a procedure similar to a modem (for Germany and some other places in Europe)</p> <p>DTMF: CLIP via DTMF (for Scandinavia and the Netherlands)</p> <p>The ARGUS will automatically detect that a CLIP was sent using DTMF with the polarity reversal and will set itself accordingly (e.g. Netherlands).</p>
DTMF parameter	Settings for the three parameters Level, Duration and Interval of the DTMF signals generated during POTS (analog) operation.
Level	<p>Setting the DTMF level:</p> <p>The level can take any value ranging from -21dB to +12 dB and can be raised (<↑> or ↑-Key) or lowered (↓-Key) by 3 dB steps.</p> <p>Default setting: 0 dB</p>
Duration	<p>Setting the DTMF time:</p> <p>The duration of the signal can take a value between 40ms and 1 second (default: 80ms).</p> <p>The value can be raised or lowered using the ↑,↓-Keys:</p> <p>In the range 40 - 200ms in 10ms increments</p> <p>In the range 200 - 300ms in 20ms increments</p> <p>In the range 300 - 1000ms in 100ms increments</p> <p>When the upper limit is reached (1000ms), the softkey <↑> will automatically change to a <↓> and vice versa when the lower limit (40ms) is reached.</p>

DTMF interval	<p>Setting the interval between two DTMF characters:</p> <p>The interval between the characters can take a value between 40ms and 1 second (default: 80ms).</p> <p>The value can be raised or lowered using the \uparrow, \downarrow-Keys:</p> <p>In the range 40 - 200ms: in 10ms increments In the range 200 - 300ms: in 20ms increments In the range 300 - 1000ms: in 100ms increments</p> <p>When the upper limit is reached (1000ms), the softkey $\langle \uparrow \rangle$ will automatically change to a $\langle \downarrow \rangle$ and vice versa when the lower limit (40ms) is reached.</p>
Reset to	<p>Restores the default settings: Level = 0 dB, Time = 80 ms Interval = 80 ms</p>
FLASH time	<p>Sets the length of a FLASH.</p> <p>This setting is needed in order to use special features of a PBX.</p> <p>The FLASH time can take a value between 40ms and 1s.</p> <p>The value can be raised or lowered using the \uparrow, \downarrow-Keys:</p> <p>In the range 40 - 200ms: in 10ms increments In the range 200 - 300ms in 20ms increments In the range 300 - 1000ms: in 100ms increments</p> <p>When the upper limit is reached (1000ms), the softkey $\langle \uparrow \rangle$ will automatically change to a $\langle \downarrow \rangle$ and vice versa when the lower limit (40ms) is reached.</p>

16.6 Configuration: X.31 profile

The ARGUS stores all of the parameters the various X.31 test varieties in the X.31 profiles. Up to 3 user-defined X.31 profiles can be created.

```
ARGUS44pi BRI
→Configuration
Access ↓
← + ✓
```

In the Main menu, use the <↓> to select **Configuration**.

```
Configuration
→X.31 profile
Device ↓
← + ✓
```

Use the <↓> to select **X.31 profile**.

```
X.31 Profile
→.31 Profile 1
X.31 Profile 2 ↓
← EDIT ✓
```

Use the <↓> to select a profile (e.g. X.31 profile 1).

Edit profile 1

```
X.31
→Packet number
TEI ↓
← + ✓
```

Use the <↓> to select, e.g. Packet number

```
Packet number:
1
ABORT DEL ✓
```

Using the keypad, enter the number of packets.
<Press **ABORT**> and the ARGUS will return to the X.31 menu without making any changes.

```
X.31
→Packet number
TEI ↓
← + ✓
```

Confirm selection

Display on ARGUS	Comment
x.31 profile:	

Packet number	Number of packets sent
TEI	Entry (from the keypad) of the TEIs to be used in the X.31 test. If you enter **, the ARGUS will automatically select a TEI.
LCN	Entry (from the keypad) of the LCN to be used in the X.31 test.
Packet size	The size of the data packets (Packet size)
Agree PS	Negotiate with the network side (DCE) an agreement regarding the data packet size (Packet size). If the desired data packet size is larger than the default, this parameter should be set to on .
Window size	Window size of Layer 3
Agree WS	Negotiate between the terminal (DTE) and the network (DCE) an agreement regarding the window size.
Throughput	Data throughput in bits per second
Agree DS	Agreed data throughput

User data

Content of the user data:

- Format setting for the user data
- Entry of the ASCII data

There are three memory locations available.

```
User data
→ASCII data
  HEX data
┌──────────┴──────────┘
└──────────┬──────────┘
└──────────┬──────────┘
```

```
ASCII data 1/3
*Echo
Loop
┌──────────┴──────────┘
└──────────┬──────────┘
└──────────┬──────────┘
```

```
User data:
Echo
┌──────────┴──────────┘
└──────────┬──────────┘
└──────────┬──────────┘
```

Save ASCII data

✓-Key

Select one of the three available memory locations for the ASCII data (in this example, the first location 1/3)

Edit the value

Use the keypad to enter the ASCII data. When the right softkey is pressed it assumes a different meaning and thus influences the entries made from the keypad (letters or digits):

<12>ab> : entry of the digits 0 to 9 plus * and #

<ab>AB> : entry of the lowercase characters and @, /, - and .

(e.g. to enter a "c" press the "2" on the keypad three times)

<AB>12> : entry of the uppercase characters and @, /, - and .

To move the cursor right or left, use the ↑, ↓-Keys.

Press to delete the digit before the cursor.

<ABORT> : do **not** save ASCII data.

- Entry of the hex data:

```
User data
→HEX data
-----↓
←  ↓  ✓
```



```
HEX data          1/3
*23 56 89 56 32
 14 05           ↓
←  EDIT  ✓
```



```
X.31 hex values:
23 56 89 56 32
14 05
ABORT DEL A..F
```



✓-Key

Save hex value

Select one of the three available memory locations for the hex data (in this example, the first location 1/3)

Edit the value


Use the keypad to enter the hex value. To enter the values A...F, use the softkey <A..F> (e.g. to enter a C, press the softkey <A..F> three times). To confirm the entry of the hexadecimal characters A to F press <OK> (the softkey in the middle changes from to <OK>).

Press to delete the digit before the cursor.

CUG	Closed User Group: Yes No
CUG Index	Coding for Closed User Group
D bit	Local: The DCE acknowledges data packets, i.e. flow control on a local DTE-DCE path end-to-end: DTE -DTE flow control
Facilities	Coding for various supplementary services
Profile name	Enter the profile names, which the ARGUS will later display.



16.7 Configuration: ARGUS

The operation is the same for all configurations and will be illustrated with a single example:



Settings on the ARGUS:

Display on ARGUS	Comment
Menu language	Selection of the menu language

LCD contrast	<p>Setting the display contrast (The contrast can be changed in 16 steps).</p> 
	<p>Using the ↑,↓-Keys, the contrast can be increased or decreased. The display shows a vertical arrow, which shows the current setting on a scale from low to high contrast.</p>
Enter date / time	<p>Enter the date and time. (Initialisation of the internal clock) via the keypad.</p>  <p>Use the ↓ -Key to scroll to the next line. The entered time will be continuously updated by the ARGUS's real time clock as long as the power is not switched off. When the power is switched off (the ARGUS switched off without batteries), the clock will run a few more weeks on its internal supply. If the backup supply is exhausted, the time will be undefined and must be set again.</p>
Baud rate	<p>Sets the maximum Baud rate to be used by the ARGUS to communicate with a PC.</p>

Alarm bell	The ARGUS signals with an alarm in a variety of situations, e.g. when a bit error occurs in a BERT. When this parameter is set to "off", all audible alarms are suppressed.
Software option	To enable a software option (e.g. additional functions), you must first enter a software key via the keypad.

16.8 Saving Call Numbers

Ten call numbers with a maximum of 24-places can be entered in the speed-dialing memory.



The first speed-dial number **must** be the **own** call number of the access under test (this is especially important for the automatic Service test).

In the *Remote No.1-8* memory locations, you can save remote call numbers. In the memory location *X.31 test number*, the ARGUS expects the entry of the X.25 access number for the X.31 test (see Chap. 10.4 page 113).

```
ARGUS44fi BRI
→Configuration
Access ↓
← ↓ ✓
```

In the Main menu, use the <↓>

Select Configuration.

```
Configuration
→Numbers
Reset ↓
← + ✓
```

Open the Configuration menu

Use the <↓> to select **Numbers**.

```
Numbers
Own number
806790 ↓
← DEL ✓
```

Using the keypad, enter the number of the access under test.

Press to delete the digit before the cursor.

Using the <↓,> scroll through the speed-dialing memory.

```
Configuration
→Numbers
Reset ↓
← ↓ ✓
```

Save the call number.

When entering an own call number with an extension (operation of the ARGUS on a PBX access), observe the following:

The extension is separated from the access number by a #.

For outgoing calls, the ARGUS uses the entire call number (without #) as the number called (CDPN or DAD) and, for the calling number (DSS1-CGPN or 1TR6-OAD), only the

16 Configuration

number after the #, in other words the extension. A "#" at the beginning of a call number is treated as a valid character.

Example:

02351/9970-45 is entered as 023519970#45



If the "# " is at the end of a number, when the number is later dialed it will be done without CGPN or OAD. This is important for some PBXs.

16.9 Reset

The ARGUS will reset all of the parameters to their default values.



The speed-dialing memory with the call numbers, PPP user name, PPP password, IP addresses, Download addresses and all of the test results stored in the ARGUS (e.g. Automatic test sequence) will be deleted.

The following settings are possible:

	Default
Trace/Remote	Off
BERT time	1 min
BERT error level	10^{-06}
BERT bit pattern	$2^{11}-1$
BERT-HRX	15%
Bit pattern "freely-defined"	0000000000000000
L1 permanent?	No
Protocol	Automatic
Alerting mode	Automatic
BRI termination	TE mode: on NT mode: off
Call acceptance	All MSNs
Call parameter	depending on country version
Clock mode	TE mode: Slave NT mode, Permanent circuit: Master
Voice coding	A-Law
DTMF / Keypad	DTMF
Destination MSN	0043
POTS dialing mode	DTMF
POTS CLIP	FSK
POTS AOC pulse	depending on country version
POTS FLASH time	80 msec
DTMF parameter	80ms/80ms/-3dB
Menu language	depending on country version
LCD contrast	Average value
Date	1.1.2000 / 12:00
Baud rate	57.600
Alarm bell	Off

X.31 profile

Packet number	10
TEI	** (automatically)
LCN	1
Packet size	128 Bytes
Agree PS	No
Window size	2 Packets
Agree WS	No
Throughput	1200 bit/s
Agree DS	No
User data:	
Format	ASCII
ASCII data	Echo
Hex data	1/3: 01 00 00 00 45 43 48 4F 2/3: 01 00 00 00 30 30 47 47
CUG	No
CUG Index	1
D bit	Local
Profile name	X.31 profile 1

ADSL profile:

ADSL mode	depending on the country and type of device
Link-Up Time	10sec
Rated value	0/0
Protocol	PPPoE
PPTP server IP addr.	0.0.0.0
Ping IP address	1
Number of pings	10
Ping pause	1 sec.
Ping packet size	84 Bytes
Ping fragmentation	on
Traceroute IP address	1
Traceroute max. hops	30
Traceroute probes	3
Traceroute timeout	3000
Download number	3
Download address (Type)	http
Download address http (Index)	1
Download address ftp (Index)	1

VPI range in a VPI/VCI scan	0 to 8
VCI range in a VPI/VCI scan	32 to 48
Number of pings in a VPI/VCI scan	3
Timeout in a VPI/VCI scan	0.1 sec.
VPI in an ATM ping	1
VCI in an ATM ping	32
Number of pings in an ATM ping	3
Timeout in an ATM ping	1 sec.
OAM cell type	F5 loopbox seg
FTP upload filename	file
FTP upload file size	1000 Bytes
FTP upload number	3
ATM BERT time	1 min
ATM BERT VPI/VCI	1 / 32
ATM BERT bit pattern	$2^{11} - 1$
ATM BERT time	10^{-6}
ATM BERT HRX	30 %
ATM BERT data rate	32 kbit/s
ATM VPI/VCI	1/32
ATM Encapsulation	LLC
LAN IP mode	static
LAN own IP address	0.0.0.0
LAN IP network mask	255.255.255.0
LAN DW-IP	0.0.0.0
LAN DHCP-Server Start / End address	0.0.0.0 / 0.0.0.0
LAN DHCP-Server Domain	none
LAN DHCP-Server Reserv. time	10 hours
LAN DHCP-Server Timeout	20 sec.
WAN IP mode	static
WAN own IP address	0.0.0.0
WAN IP network mask	255.255.255.0
WAN remote IP address	0.0.0.0
WAN DHCP timeout	20 sec.
Router	NAT ON

DNS Server 1	0.0.0.0
DNS Server 2	0.0.0.0

```
ARGUS44pi BRI
➔Configuration
Access
┌───────────────────┐
│ ←  →  ✓           │
└───────────────────┘
```

In the Main menu, use the <↓> to **Select** Configuration.



```
Configuration
➔Reset
-----
┌───────────────────┐
│ ←  →  ✓           │
└───────────────────┘
```

Open the Configuration menu



```
Continue with
reset of all
parameters?
ABORT  YES
```

Use the <↓> to select **Reset**.

Security query



```
Configuration
➔Reset
-----
┌───────────────────┐
│ ←  →  ✓           │
└───────────────────┘
```

Reset to the default values

17 Accu servicing

Automatic recharging of the accumulators when the ARGUS is switched on

The ARGUS automatically recharges the accumulators, if the ARGUS is connected to the plug-in power supply and the accumulator voltage is less than 3.90 volts (only use the supplied accumulators).

```
Charge accu
U:4.03V
ABORT
```

The LED "Line Power" flashes while the accumulators are recharging.

If you press and hold the power switch, the ARGUS will switch off before the accumulators are recharged.

Otherwise, the ARGUS will switch itself off automatically as soon as the accumulators are recharged.

```
Charge accu
U:4.03V
aborted
CONT.
```

```
ARGUS44 3.1 D
Setting OK ?
S0 TE P-P
NO YES
```

Accu servicing

The ARGUS will display the current charge of the accumulators, if no power supply is connected.

When the power supply is connected, the accumulators in the ARGUS can be completely discharged or immediately (without being first discharged) recharged. The discharge procedure takes up to 6 hours. The ARGUS will automatically begin recharging the accumulators after a break of about 30 minutes (depending on the capacity of the accumulators, it can take up to 7 hours to recharge them).

```
ARGUS44Pi ADSL
→Accu servicing
-----↓
←      +      ✓
```

In the Main menu, use the <↓> to select **Accu servicing**.



```
Accu servicing ☐
→Charge
Discharge ↓
←      +      ✓
```

Open the **Accu servicing** menu

Use the <↓> to select, for example, **Charge**.



```
Charge accu ☐
U: 4.03V
ABORT
```

Start charging the accumulators (the plug-in power supply must be connected)

The ARGUS will display the level of the charge and the voltage while charging the

accumulators.

```
Discharge accu ☐
U: 3.87V
ABORT
```

Discharging the accumulators


The accumulators will first be fully discharged and then - after a brief pause - automatically recharged.

18 Testing Features with the Keypad

This feature is only relevant for a BRI access!

Some network operators do not support the standard DSS1 features, rather they expect the user to control the network via so-called keypad command sequences.

In these cases, the desired facility is usually activated by entering a series of characters and then sending these characters within a DSS1-specific protocol element. These so-called Keypad-Elements are imbedded in a SETUP message.

An outgoing call containing a keypad message is placed from the ARGUS by pressing the -Key.

To distinguish the call from a normal call, the first character sent is the '#'. Each step is acknowledged either acoustically (handset) or via special protocol elements (cause). These causes are displayed by the ARGUS.

To simplify the use of these functions, you can use the ARGUS's speed-dialing memory.

An example for an application:

Speed-dial number 0	4711	own number of the access under test
Speed-dial number 1	124527	tel. no. of own company
Speed-dial number 2	#*67#	Code for activating CFB
Speed-dial number 3	##67#	Code for deactivating CFB
Speed-dial number 4	##*67#	Code for querying CFB (interrogation)
Speed-dial number 5	##*21#	Code for querying CFU (interrogation)
Speed-dial number 6	##*61#	Code for querying CFNR(interrogation)
Speed-dial number 7		<i>free</i>
Speed-dial number 8		<i>free</i>
Speed-dial number 9		<i>free</i>

19 Appendix

A) ADSL Acronyms

ADSL	Asymmetric Digital Subscriber Line
ANT	ADSL Network Termination Unit
ANSI	American National Standards Institute
ATM	Asynchronous Transfer Mode (network-side transmission protocol)
ATU-C	ADSL Transceiver Unit - Central Office (network-side/DSLAM)
ATU-R	ADSL Transceiver Unit - Remote (ADSL modem)
BER	Bit Error Rate
CRC	Cyclic Redundancy Check (checksum)
CTRL-E	Control External
DMT	Discrete Multi-Tone
DRA	Dynamic Rate Adaptation
EOC	Embedded Operations Channel
ES	Errored Seconds
FEC	Forward Error Correction
HEC	Header Error Control
LOCD	Loss of Cell Delineation
LOF	Loss of Frame
LOP	Loss of Power
LOS	Loss of Signal
LT	Line Termination
ME	ADSL Management Entity
MIB	Management Interface Base
NIC	Network Interface Card (network adapter card)
NT	Network Termination (network-side)
OAM	Operations, Administration and Maintenance
OBC	On Board Controller
POTS	Plain Old Telephone Service (Analog)
PSD	Power Spectral Density
QOS	Quality of service
RA	Rate Adaptation
SAR	Segmentation and Reassembly Unit
SER	Severely Errored Seconds
SNR	Signal-to-Noise Ratio

B) Vendor identification numbers

0000	not allocated
0001	not allocated
0002	Westell, Inc.
0003	ECI Telecom
0004	Texas Instruments
0005	Intel
0006	Amati Communications Corp.
0007	General Data Communications, Inc.
0008	Level One Communications
0009	Crystal Semiconductor
000A	Lucent Technologies
000B	Aware, Inc.
000C	Brooktree
000D	NEC
000E	Samsung
000F	Northern Telecom, Inc.
0010	PairGain Technologies
0011	Paradyne
0012	Adtran
0013	INC
0014	ADC Telecommunications
0015	Motorola
0016	IBM Corp.
0017	Newbridge Network Corp.
0018	DSC
0019	Teltrend
001A	Exar Corp.
001B	Siemens Telecom Networks
001C	Analog Devices
001D	Nokia
001E	Ericsson Information Systems
001F	Tellabs Operations, Inc.
0020	Orckit Communications, Inc.
0021	AWA
0022	Alcatel Network Systems, Inc.
0023	National Semiconductor Corp.
0024	Italtel
0025	SAT - Société Anonyme de Télécommunications
0026	Fujitsu Network Trans. Systems
0027	MITEL

0028	Conklin Corp.
0029	Diamond Lane
002A	Cabletron Systems, Inc.
002B	Davicom Semiconductor, Inc.
002C	Metalink
002D	Pulsecom
002E	US Robotics
002F	AG Communications Systems
0030	Rockwell
0031	Harris
0032	Hayes Microcomputer Products, Inc.
0033	Co-optic
0034	Netspeed, Inc.
0035	3-Com
0036	Copper Mountain, Inc
0037	Silicon Automation Systems, Ltd
0038	Ascom
0039	Globespan Semiconductor, Inc.
003A	STMicroelectronics
003B	Coppercom
003C	Compaq Computer Corp.
003D	Integrated Technology Express
003E	Bay Networks, Inc.
003F	Next Level Communications
0040	Multi-Tech Systems, Inc.
0041	AMD
0042	Sumitomo Electric
0043	Philips M&N Systems
0044	Efficient Networks, Inc.
0045	Interspeed
0046	Cisco Systems
0047	Tollgrade Communications, Inc.
0048	Cayman Systems
0049	FlowPoint Corp.
004A	I.C.COM
004B	Matsushita
004C	Siemens Semiconductor
004D	Digital Link
004E	Digitel
004F	Alcatel Microelectronics
0050	Centillium Corp.
0051	Applied Digital Access, Inc.

0052 Smart Link, Ltd.

C) CAUSE-Messages – DSS1 Protocol

Dec. Cause	Description
01 Unallocated (unassigned) number	No access under this call number
02 No route to specified transit network	Transit network not reachable
03 No route to destination	Wrong route or routing error
06 Channel unacceptable	B-channel for the sending system not acceptable
07 Call awarded and being delivered in an established channel	Call awarded and connected in an already existing channel (e.g., X.25 SVC)
16 Normal call clearing	Normal disconnect
17 User busy	The number called is busy
18 No user responding	No terminal equipment answered (Timer NT303 / NT310 time-out)
19 No answer from user (user alerted)	Call time too long
21 Call rejected	Call rejected (active)
22 Number changed	Call number has been changed
26 Non-selected user clearing	Incoming call not awarded to this terminal
27 Destination out of order	Destination / access out of order
28 Invalid number format (address incomplete)	Wrong call number format or call number incomplete
29 Facility rejected	The facility is not offered
30 Response to STATUS ENQUIRY	Response to status enquiry
31 Normal, unspecified	Unspecified for "normal class" (Dummy)
34 No circuit / channel available	No circuit / B-channel available
38 Network out of order	Network not operational
41 Temporary failure	Network is temporarily not operational
42 Switching equipment congestion	Switching equipment is overloaded
43 Access information discarded	Access information could not be transferred
44 Requested circuit / channel not available	Requested circuit / B-channel is not available
47 Resources unavailable, unspecified	Unspecified for "resource unavailable class" (Dummy)
49 Quality of service unavailable	The requested quality of service is not available
50 Requested facility not subscribed	Requested service attribute is not subscribed
57 Bearer capability not authorized	The requested bearer capability is not enabled
58 Bearer capability not presently available	The requested bearer capability is not currently available

19 Appendix

63	Service or option not available	“Service unspecified or option not available class” (Dummy)
65	Bearer capability not implemented	Bearer capability is not supported
66	Channel type not implemented	Channel type is not supported
69	Requested facility not implemented	Requested facility is not supported
70	Only restricted digital information bearer capability is available	Only limited bearer capability is available
79	Service or option not implemented, service unspecified or option not implemented class” (Dummy)	Unspecified
81	Invalid call reference value	Invalid call reference value
82	Identified Channel does not exist	Requested channel is invalid
83	A suspended call exists, but this call identity does not	The call identity entered is the wrong one for the parked call
84	Call identity in use	The call identity is already in use
85	No call suspended	No call has been parked
86	Call having the requested call identity has been cleared	The parked call has been cleared
88	Incompatible destination	Incompatible destination
91	Invalid transit network selection	Invalid format for the transit network identifier
95	Invalid message, unspecified	Unspecified for “Invalid message class” (Dummy)
96	Mandatory information element is missing	Mandatory information element is missing
97	Message type non-existent or not implemented	This type of message is in this phase not permitted, not defined or not supported
98	Message not compatible with call state or message type non-existent or not implemented	The content of the message is in this phase not permitted, not defined or not supported
99	Information element non-existent or not implemented	The content of the information element is in this phase not permitted, not defined or not supported
100	Invalid information element contents	Invalid content in information element
101	Message not compatible with call state	Message not valid in this phase
102	Recovery on timer expired	Error handling routine started due to time-out
111	Protocol error, unspecified	Unspecified for “protocol error class” (Dummy)
127	Interworking, unspecified	Unspecified for “interworking class” (Dummy)

D) CAUSE-Messages – 1TR6 Protocol

Dec. Cause	Description
01 Invalid call reference value	Invalid call reference value
03 Bearer service not implemented	The service is not available in the central office or at another location in the network or the service has not been subscribed.
07 Call identity does not exist	Unknown call identity
08 Call identity in use	Call identity is already assigned to a "suspended" connection.
10 No channel available	No further B-channel is free on the subscriber's access. (only significant locally)
16 Requested facility not implemented	The entered FAC-Code is unknown in this network.
17 Requested facility not subscribed	The requested facility is not available, because the initiating or the remote subscriber is not authorized.
32 Outgoing calls barred	Outgoing calls are not possible due to the barring
33 User access busy	If the sum of the number of free B-channels, the number of occupied B-channels, the number of awarded B-channels and the number of calls without B-channel assignment equals four, new incoming calls will be cleared from the network. The calling subscriber receives a DISC with the cause "user access busy"(= first busy) and a busy signal.
34 Negative CUG comparison	Connection not possible due to negative CUG comparison
35 Non-existent CUG	This CUG (GBG) does not exist
37 Communication link as SPV not permitted	A connection is not possible, since for example, the RFNR-test was negative
53 Destination not obtainable	A connection cannot be made due to a wrong destination, service or supplementary services.
56 Number changed	Subscriber-B's call number has changed.
57 Out of order	The remote terminal is not ready.
58 No user responding	No terminal has answered the incoming SETUP or the subscriber call was disconnected, it is assumed that someone is present (Time-out for ringing T3AA).
59 User busy	Subscriber-B is busy
61 Incoming calls barred	Subscriber-B has blocked incoming calls or the requested service is not supported by Subscriber-B.

62	Call rejected	<p>To Subscriber-A: The requested connection is actively rejected by Subscriber-B (by sending a DISC as answer to the incoming SETUP). Another terminal is in the setup phase with the incoming call: The call has already been accepted by another terminal on the bus.</p>
89	Network congestion	Network congested, e.g., switching equipment congestion, no conference set free, ...
90	Remote user initiated	Rejected or disconnected by remote end (subscriber or exchange).
112	Local procedure error	<p>Sent in a REL Disconnect due to local errors (e.g., not valid messages or parameters, time-out, ...).</p> <p>Sent in a SUSP REJ Due to another already active supplementary service, the connection may not be "suspended".</p> <p>Sent in a RES REJ There is no "suspended" connection.</p> <p>Sent in a FAC REJ No further supplementary service request is possible, since there is still one being processed or the supplementary service requested is not available in the current state of the connection.</p>
113	Remote procedure error	Caused by error at remote end.
114	Remote user suspended	Connection at the remote end is in the "hold" or "suspend" state.
115	Remote user resumed	Connection at the remote end is no longer in the "hold" or "suspend" or "conference" state.
127	User Info discarded locally	<p>The message USER INFO is rejected locally. The cause is given in the message CON CON. Length entry (=0)</p> <p>Normal disconnect (e.g., in REL as answer to a DISC from subscriber or a change of service in a DISC): Command to the terminal to release the B-channel.</p>

E) ARGUS Error Messages

Fault Number	Fault Class	Cause	Description
0	E	Network	The network is not in a state defined for DSS1 or 1TR6. It may be that this state is normal for a PBX.
1 to 127	B,C,D,E	Network	DSS1 or 1TR6 causes
150	E	ARGUS	An error occurred during the supplementary service test. Frequent cause: No response from network
152	B	ARGUS	The CF-Test was started with the wrong own number.
153	E	ARGUS	no HOLD is available, but HOLD is required to test the supplementary service (ECT, 3pty)
154	E	ARGUS	CLIR or COLR could not be tested, since CLIP or COLP is not available
161	B	ARGUS	The party called did not answer within the prescribed time (approx.10 sec)
162	B	ARGUS	A call was setup to a remote subscriber, instead of being setup – as was expected – to your own number.
163	E	ARGUS	The Auto-Test could not setup a connection and therefore the AOC/D supplementary service could not be tested.
199	B	ARGUS	A call number was entered.
201	A	ARGUS	Network did not confirm acceptance of the call (CONN sent, no CONN_ACK received from network)
204	A	ARGUS	- Layer 2 connection was cleared-down - No response to SETUP (call setup) - Layer 2 connection could not be setup
205	A	ARGUS	Reestablish the Layer 2 Connection

210	A	ARGUS	No response to the clear-down (REL sent, no REL_CMP/REL_ACK received from network)
220	A	ARGUS	Remote end signaled that it is in State 0.
245	E	ARGUS	Keypad sent via ESC, but no response was received from network
250	E	ARGUS	FACility was sent, but no response was received from network

X.31 Test – Error messages

X.31 Causes

0 to 255	Network	See ISO 8208: 1987(E) Table 5- Coding of the clearing cause field in clear indication packets, page 35
257	ARGUS	no response from network (for a CALL-REQUEST or CLEAR-REQUEST)
258	ARGUS	Unexpected or wrong answer from network (no CALL-CONNECTED or CLEAR-INDICATION as response to a CALL-REQUEST)
259	ARGUS	The network has indicated in a DIAGNOSTIC message that the logical channel is invalid. Origin: No (=1) or a wrong LCN was set.
260	ARGUS	The Layer 2 connection was interrupted e.g. by pulling the BRI plug.
512	ARGUS	It was not possible to determine an internal or external cause. Origin: Layer 2 could not be setup or remote end does not support X.31
65535	ARGUS	X.31 Layer 3 test was not performed. The error can only occur in a test log.

X.31 Diagnostic (only for a cause less than 256)

0 to 255	Network	See ISO 8208: 1987(E) Figure 14A page 121 Figure 14B page 123 et seq. And/or CCITT Recommendation X.25, Annex E
-----------------	---------	---

F) Error message: ADSL connection

ARGUS Error Message	Meaning of the Error Message
Incomp.linecon.	Incompatible line conditions: One or more of the following conditions could not be met on the line: ATM data rate, signal-to-noise ratio or transmit power.
No lock possib.	No lock possible: A connection to ATU-C is not possible.
Protocol error	An error occurred during the activation phase.
Message error	During the activation, a message arrived from the ATU-C side that could not be understood. (possibly the wrong format or a CRC error)
Spuri. ATU det.	Spurious ATU detected: This error will be displayed when: 1. An activation signal has been detected on the line, but it is not from the ATU-C. (Fault on the line) 2. An error occurred before the ARGUS received a complete message with a correct CRC sum..
Forced silence	The idle (silent) phase (1 minute) initiated by the ATU-C side was not kept. During this period, an activation may not be initiated.
Unsel.op.mode	Unselectable operation mode: Operation mode not supported.
Cancelled	The test was interrupted or timed out.

G) Error message: PPP connection

Display ARGUS on	Description
No error	No PPPD error occurred.
Fatal error	Fatal PPPD error occurred. Possible cause: System or memory error
Option erro	The PPPD options are faulty: Wrong parameters for PPP setup
PPP: Not root	The PPPD must be called by the Linux "root" user.
No PPPD support	Operating system does not support PPP connections.
Rec.sig.error	The PPP setup was canceled by a SIGINT, SIGTERM or SIGHUP signal, e.g. canceled by the user or because the waiting time has elapsed.
PPP: Port open error	PPPD communications error Serial port could not be locked.
PPP: Port open error	PPPD communications error. Serial port could not be opened.
Con.script err.	Error when calling the connection script.
PPP: Command erro	Not possible to start with the PPPD's pty option
Negotiation err	Cannot negotiate the network protocol for PPPD, so the remote site is not reachable.
Idle release	Connection was terminated, since there was no activity.
Time out rel	Connection was terminated, since the maximum connection time elapsed.
PPP Callback	Callback was initiated, an incoming call is expected soon.
PPP: Echo req. error	Remote site did not answer echo requests so the connection has been terminated. (PPP connections are tested at regular intervals by sending echo requests to the remote site.)
Hanging up rel	Disconnected by remote site.
Loopback erro	The setup of the PPP connection was cancelled, since a loopback was detected.
Init script err.	Error caused by the PPPD's init script.
Authent. Error	Authentication error: Wrong user name or password - rejected by remote site.

PADO timeout	No PADO packet received.
PADS timeout	No PADS packet received.

H) Error message: Download test

Display ARGUS	on	Description
Download OK		No error occurred.
Buffer overflow		Buffer overflow when using base64 encoding.
Process error		Error when setting up the Exit handler.
Buffer too small		Buffer too smallBuffer too small for the extra_header.
Continue error		Download cannot be continued without specifying a file.
File fstat error		File system error when calling fstat().
Http redir.error		Fault: Too many HTTP redirects.
Http no response		No answer from HTTP server.
Http serv.error		HTTP server has returned an error. (for details see the table below "HTTP Error Messages")
Http encod.error		Due to an encoding problem, data transfer with HTTP is not possible.
Ftp open error		Error when opening the FTP connection.
Ftp login error		FTP login error: Wrong user name or password or anonymous login not supported.
Ftp passiv err.		FTP server does not support passive transmission mode.
Ftp rec. error		FTP receive error.
File write error		File system error when calling fwrite().
Network error		Network error
Ftp error		General FTP error.
URL error		Fault: No HTTP or FTP URL specified.
Socket error 1		Error when opening a socket.
Socket error 2		Error when connecting a socket. The server's HTTP service is not available.
FDopen error		Error when opening a file.
Http Head.error		Error in the header of the requested HTTP file.
Ftp no file		FTP download error: No such file or directory found.

Unknown address	Unknown host address. Possible cause: Error in the address entered, DNS resolution not working or network not accessible.
Unknown dl error	Unknown download error

HTTP Error Messages

Display on ARGUS: Code No.	Meaning
100	Client should continue its request.
101	The protocol is being changed at the Client's request.
200	The Client's request has succeeded.
201	The Client's request that a new document be created was successful.
202	The Client's request has been accepted for processing.
203	The Client's request will be answered with information from a source other than the server.
204	The Client's request was successful. The server sends [no content] only the HTTP header.
205	The Client's request was successful. The server [resets content] sends a new HTTP body.
206	The Client's request was successful. The server sends only part of the requested document [partial content].
300	The request was not precise enough so multiple documents have been returned.
303	The requested resource has been found at a different URI and should be retrieved from there.
304	The requested document has not been changed in the interim.
305	The requested document must be retrieved from a proxy instead of from the server.

307	The requested resource has been temporarily relocated to a different URI [temporary redirect].
400	Syntax error in the Client's request [Client error].
401	The request requires user authentication.
402	Payment is required to process this request.
403	The Client's request has been refused. (e.g. because authentication failed.)
404	The requested document was not found (e.g. because of an error in the URL entered or while the document is no longer available).
405	The method specified by the Client in its request is not allowed by the server.
406	The requested document in a format that is not supported by the Client.
407	The request requires that the Client authenticate itself with a proxy.
408	The Client did not place its request within the time allowed by the server [Request Timeout].
409	Due to a conflict (e.g. another request) the Client's request cannot be completed by the server.
410	The requested URL is [gone] no longer available on the server.
411	The Client sent data to the server without a defined Content Length.
412	The preconditions in the Client's request could not be satisfied by the server.
413	The Client's request has been refused by the server because the request entity is too large.
414	The Client sent a URL to the server that is too large. (e.g. because of the form values contained.)
415	The Client's data is not supported by the server.
416	The range (in a document) requested by the Client [is not satisfiable] does not exist.

417	The server could not (or did not wish to) satisfy the Client's expectation given in the Expect request header field.
424	For aesthetic reasons, the requested document will not be sent by the server.
500	Due to an unexpected condition, the server cannot fulfill the Client's request (e.g. faulty configuration, missing or wrong CGI program).
501	The server does not support the function required to fulfill the Client's request.
502	The server received an invalid response from an upstream server or proxy which it accessed in attempting to fulfill the request.
503	The server is currently unable to handle the request due to a temporary overloading of the server.
504	The Client's request (of a gateway or proxy) did not receive a response within the specified time.
505	The server does not support the HTTP protocol version that was used in the Client's request.

I) General Error Messages

Display ARGUS on	Description
Mode not supp.	Mode currently not supported. The following modes are supported: PC_REPLACEMENT_MODE, PC_MODEM_REPLACEMENT_MODE, MODEM_REPLACEMENT_MODE
Prot. not supp.	The protocol (IP, PPPoE, etc.) is not supported in the selected mode.
Test not supp.	The test (Ping, Traceroute, etc.) is not supported for the selected mode and protocol.
Unknown error	Unknown error occurred.
No PPP connec.	No PPP connection can be setup. (for details see Page 218)
Test aborted	Test aborted by user.
Pingstart error	Error when starting the Ping test.
Fault: Unexp. IP down	Unexpected termination of the PPP connection. (for details see Page 218)
Unexp. PING end	Unexpected termination of the Ping test.
Interface error	Error while starting/terminating the network interface. (for details see the error codes of the interface script)
Fault: TR Start	Error when starting the Traceroute test.
Fault: TR Packet	The test timed out since the traceroute answer packet did not arrive within the specified time.
DHCP timeout LAN	DHCP Client timeout (LAN)
DHCP NAK err LAN	The DHCP server refused the DHCP client (LAN)
Download timeout	Error when starting the Download test.
No DL answer	Error while performing the Download test (for details see Page 220).
MASQ error	Error while starting/terminating the routing rules. (for details see the error codes of the routing rules)

TR unreachable	The destination host cannot be reached with UDP packets from traceroute. Possible cause: Router or firewall is discarding UDP packets
DHCP timeout WAN	DHCP client timeout (WAN)

J) ARGUS Messages - Script Errors

Display ARGUS Error Code	Description
0	No error occurred.
33	Wrong parameter. Possible parameters: PRE_UP, UP or DOWN
44	Mode not supported for selected parameter.
55	Protocol not supported for selected parameter and mode.
66	Selected modem replacement mode is not supported. Possible modes: BRIDGE or ROUTER

K) ARGUS Messages - Routing Rules

Display ARGUS Error Code	Description
0	No error occurred.
77	Wrong parameter. Possible parameters: START and STOP
88	Packet filter mode is not supported. Possible modes: STRICT and ALL
99	Error in the selection of dynamic or static. Possible selections: DYNAMIC or STATIC

